

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sunnydaze](#) /

› [Sunnydaze 44-Inch Folding Outdoor Wood Privacy Screen Instruction Manual](#)

### Sunnydaze LAM-683

# Sunnydaze 44-Inch Folding Outdoor Wood Privacy Screen Instruction Manual

Model: LAM-683

## INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Sunnydaze 44-Inch Folding Outdoor Wood Privacy Screen. Please read this manual thoroughly before use to ensure proper setup and to maximize the product's lifespan.

The Sunnydaze Folding Outdoor Wood Privacy Screen is designed to offer privacy and conceal unsightly items in outdoor spaces such as patios and decks. Constructed from durable meranti wood with a teak oil finish, it is built to withstand outdoor elements while enhancing the aesthetic of your environment.

## Constructed Of Meranti Wood

Has a teak oil finish that enhances the natural beauty of the material while also adding extra durability against the outdoor elements



Image: The Sunnydaze 44-inch folding outdoor wood privacy screen, illustrating its four panels, 44-inch height, meranti wood construction, and its utility for concealing items like trash cans and utility boxes.

## SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not climb on or lean heavily against the screen.
- Place the screen on a flat, stable surface to prevent tipping.
- In strong winds, consider securing the screen or folding it for storage to prevent damage or injury.
- Keep children and pets away from the screen during assembly.

## PACKAGE CONTENTS

Verify that all parts are present before beginning assembly:

- 4 Meranti Wood Panels
- Connecting Poles (0.5" diameter x 40.25" H)
- Hardware (Hooks/Grommets for connection)

- 1 Durably constructed from meranti wood with a teak oil finish
- 2 Freestanding privacy fence is easy to assemble
- 3 Use as a privacy fence or divider in any outdoor space



Image: An illustration showing the components and basic assembly steps for the privacy screen, highlighting the connection points between panels.

## SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all panels and hardware from the packaging.
2. **Attach Connecting Hardware:** Screw the provided hooks into the pre-drilled holes on the sides of each panel. Ensure they are tightened securely.
3. **Connect Panels:** Align the panels and insert the connecting poles through the hooks to link them together. The poles should slide easily through the grommets.
4. **Position the Screen:** Place the assembled screen in your desired outdoor location. The screen is freestanding and can be configured in various shapes (e.g., straight line, L-shape, U-shape) to best fit your space. For

optimal stability, especially in windy conditions, configure the screen with slight curves or angles.



Image: A close-up view of the metal hooks and connecting pole used to join two panels of the privacy screen, demonstrating the assembly mechanism.

## OPERATING INSTRUCTIONS

The Sunnydaze Folding Outdoor Wood Privacy Screen is designed for flexible use:

- **Configuration:** The hinged design allows for various configurations. You can arrange the panels in a straight line, an L-shape, a U-shape, or other custom angles to suit your privacy needs or to define specific areas.
- **Portability:** The screen is lightweight and can be easily moved to different locations as needed.
- **Storage:** For compact storage, the screen can be folded flat by removing the connecting poles and collapsing the panels.



Image: The privacy screen positioned on an outdoor patio, demonstrating its use in a real-world setting to provide privacy or define a space.

## MAINTENANCE

To ensure the longevity and appearance of your wood privacy screen:

- **Cleaning:** Wipe the wood panels with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals.
- **Wood Care:** The meranti wood is treated with a teak oil finish. To maintain its natural beauty and weather resistance, it is recommended to reapply teak oil periodically, especially if the screen is exposed to direct sunlight and rain frequently. Follow the instructions on your chosen teak oil product.
- **Winter Storage:** During harsh winter conditions or prolonged periods of non-use, it is advisable to store the screen indoors or in a covered area to protect the wood from extreme weather.
- **Inspection:** Periodically check all hardware and connections for tightness. Tighten any loose screws or hooks as necessary.

## TROUBLESHOOTING

Issue	Possible Cause	Solution
Screen is unstable or tips easily.	Uneven ground; panels configured in a straight line in windy conditions.	Ensure placement on a level surface. Configure panels with slight angles or curves for increased stability. Consider additional anchoring in very windy areas.
Wood appears faded or dry.	Exposure to sun and weather has diminished the teak oil finish.	Clean the wood surface and reapply a suitable teak oil finish according to product instructions.
Panels are difficult to connect.	Hardware not aligned correctly; debris in holes.	Check alignment of hooks and poles. Clear any obstructions from the holes. Ensure hooks are fully screwed in.

## SPECIFICATIONS

Feature	Detail
Model Number	LAM-683
Overall Dimensions (Unfolded)	8' 11" W x 1.75" D x 44" H (107" L x 1.75" D x 44" H)
Individual Panel Width	Approximately 23.5 inches
Item Weight	35.4 lbs
Material	Meranti Wood with Teak Oil Finish
Color	Brown
Assembly Required	Minimal (Hardware attachment)



Image: A diagram illustrating the detailed dimensions of the privacy screen, including overall width, height, and individual panel measurements.

Model Height: 5'7"



Image: The privacy screen shown next to a human figure (model height 5'7") for scale, indicating its 44-inch height.

## WARRANTY AND SUPPORT

Sunnydaze Decor provides a **1-year manufacturer's warranty** on this product. For warranty claims, replacement parts, or any product-related inquiries, please contact Sunnydaze Decor customer service.

For additional support and resources, you may refer to the official user guide available for download [Download User Guide \(PDF\)](#)

Contact information for Sunnydaze Decor can typically be found on their official website or through your retailer.