

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [High Street TV](#) /
- › [Power XL Grill Air Fryer Combo - User Manual](#)

High Street TV MFC-AF-6

Power XL Grill Air Fryer Combo User Manual

Model: MFC-AF-6 | Brand: High Street TV

INTRODUCTION

The Power XL Grill Air Fryer Combo is a versatile 12-in-1 electric multicooker designed to provide a wide range of cooking functions in a single countertop appliance. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read all instructions thoroughly before first use and retain this manual for future reference.



Image: The Power XL Grill Air Fryer Combo, showcasing its sleek design and digital control panel.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not immerse the main unit housing in water or other liquids.
- Ensure the appliance is placed on a stable, heat-resistant surface away from walls and other appliances.
- Do not operate the appliance with a damaged cord or plug.
- Keep hands and face away from the steam vent when the appliance is in use.
- Always unplug the appliance when not in use and before cleaning.
- Allow the appliance to cool completely before handling or cleaning parts.
- This appliance is for household use only.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the various parts of your Power XL Grill Air Fryer Combo.

- **Main Unit:** Houses the heating elements and control panel.
- **Digital Easy-Touch Panel:** For selecting functions, adjusting time and temperature.
- **Removable Non-Stick Grill Plate:** For grilling and easy cleaning.
- **Tempered Glass Lid:** For slow cooking, steaming, and simmering functions.
- **Serving Ladle:** Included for convenience.
- **Inner Pot:** The main cooking vessel.

POWER XL AIR FRYER GRILL COMBO INCLUDES:



POWER XL AIR FRYER GRILL COMBO



TEMPERED GLASS LID



REMOVABLE GRILL PLATE



SERVING LADLE



DIGITAL RECIPE BOOK

Image: An illustration detailing the main unit and its accompanying accessories, including the tempered glass lid, removable grill plate, and serving ladle.

SETUP

1. Unpack all components and remove any packaging materials.
2. Wash the removable grill plate, inner pot, and tempered glass lid with warm, soapy water. Rinse thoroughly and dry completely.

3. Wipe the exterior of the main unit with a clean, damp cloth.
4. Place the appliance on a stable, level, heat-resistant surface. Ensure there is adequate ventilation around the unit.
5. Insert the inner pot into the main unit.
6. Plug the power cord into a grounded electrical outlet. The display will illuminate.

OPERATING INSTRUCTIONS

The Power XL Grill Air Fryer Combo features 12 pre-set functions for versatile cooking. The digital easy-touch panel allows for simple selection and adjustment.



Healthier
Cooks with
little or no oil

70% Faster
than a
conventional
oven

12 pre-set
Functions
and quick-
touch display

Image: The digital control panel, showing options for Air Fry, Slow Cook, Steam, Sauté, Grill, Bake, Roast, Rice, Simmer, Sous Vide, Fry, and Keep Warm, along with timer and temperature controls.

General Operation:

1. Ensure the appliance is plugged in.

2. Place food into the inner pot or on the grill plate as appropriate for your chosen function.
3. Select your desired cooking function from the 12 pre-set options on the digital panel.
4. Adjust the cooking time and temperature using the dedicated buttons if needed.
5. Press the 'Start' button to begin cooking.
6. The appliance will automatically shut off when the cooking cycle is complete.

12-in-1 Cooking Functions:

This appliance offers a wide range of cooking methods:

- **Air Fry:** For crispy results with little to no oil (e.g., fries, chicken wings).
- **Slow Cook:** Ideal for tender meats and stews.
- **Steam:** For healthy vegetables and seafood.
- **Sauté:** For browning ingredients or cooking stir-fries.
- **Grill:** Achieve char-grilled marks and flavors (e.g., steaks, burgers).
- **Bake:** For cakes, breads, and casseroles.
- **Roast:** Perfect for whole chickens or larger cuts of meat.
- **Rice Cooker:** For perfectly cooked rice.
- **Simmer:** Gentle cooking for sauces and delicate dishes.
- **Sous Vide:** Precision cooking for consistent results.
- **Fry:** Traditional frying method.
- **Keep Warm:** Maintains food temperature after cooking.

Features of Power XL Grill Combo

DIGITAL EASY-TOUCH PANEL

12 PRE-SET FUNCTIONS

DISHWASHER SAFE PARTS

TIMER WITH AUTO SHUT OFF

UP TO 200°C/400°F COOKING



Image: A visual representation of the 12 distinct cooking functions offered by the Power XL Grill Air Fryer Combo, from air frying crispy fries to grilling steaks and baking pies.

Dual Therm Technology:

The appliance utilizes Dual Therm Technology, cooking from both above and below. The vortex whirlwind technology superheats air up to 200°C (400°F) for top-down cooking, while a powerful high-temperature element cooks from below, allowing for searing, simmering, and more.

Dual Therm Technology

cooks from above and below



Image: An open view of the appliance demonstrating the top heating element and the cooking chamber, highlighting the dual heating capability.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. The removable non-stick grill plate, inner pot, and tempered glass lid are dishwasher safe for quick and easy cleanup.
3. For manual cleaning, wash these parts with warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely.
4. Wipe the exterior of the main unit with a clean, damp cloth. Do not use abrasive cleaners or scouring pads.
5. Never immerse the main unit housing in water or any other liquid.
6. Ensure all parts are dry before storing the appliance.

Removable Non-stick grill plate

makes clean up super quick and easy



Image: The removable non-stick grill plate, designed for easy food handling and simplified cleaning after use.

TROUBLESHOOTING

If you encounter issues with your Power XL Grill Air Fryer Combo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; unit not assembled correctly.	Ensure power cord is securely plugged into a working outlet. Check if inner pot is correctly seated.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time setting.	Do not overcrowd the cooking area. Adjust temperature and time as per recipe. Stir or flip food halfway through cooking.
Smoke coming from the unit.	Excess oil/grease; food residue.	Ensure grill plate and inner pot are clean. Remove excess fat from food before cooking.

Problem	Possible Cause	Solution
Digital display not responding.	Temporary electronic glitch.	Unplug the unit from the power outlet, wait 1 minute, then plug it back in.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

- **Model Number:** MFC-AF-6
- **Brand:** High Street TV
- **Capacity:** 5.7 Liters
- **Power / Wattage:** 1500 watts
- **Voltage:** 115 Volts
- **Color:** Silver
- **Material:** Aluminum Plastic
- **Item Weight:** 9.6 Kilograms
- **Special Features:** Temperature Control, Digital Easy-Touch Panel, 12 Pre-set Functions, Dishwasher Safe Parts, Timer with Auto Shut Off, Dual Therm Technology.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact High Street TV customer service. Keep your proof of purchase for any warranty claims.

For further assistance, visit the official High Street TV website or contact their customer support line.