

[Manuals.plus](#) /

› [Easytry123](#) /

› User Manual for Easytry123 Replacement Air Conditioner Remote Control

Easytry123 SG-PAC-08E3, SG-PAC-08E4, GH-PAC-10E5, GM-TTW-10ESE, GM-TTW-12ESE, SG-PAC-10E5, KY-100E5, GB-PAC-08E4, SG-PAC-10E2, GM-T

User Manual for Easytry123 Replacement Air Conditioner Remote Control

Compatible with Soleus Air Models: SG-PAC-08E3, SG-PAC-08E4, GH-PAC-10E5, GM-TTW-10ESE, GM-TTW-12ESE, SG-PAC-10E5, KY-100E5, GB-PAC-08E4, SG-PAC-10E2, GM-TTW-14, GM-TTW-12ESEZ

1. INTRODUCTION

Thank you for choosing the Easytry123 Replacement Remote Control. This manual provides essential information for the proper setup, operation, and maintenance of your new remote control. This remote is designed as a direct replacement for various Soleus Air conditioner models, offering convenient control over your unit's functions. Please read this manual thoroughly before use to ensure optimal performance and longevity of your remote.

2. PRODUCT OVERVIEW

The Easytry123 replacement remote control is designed for ease of use, featuring clearly labeled buttons and a digital display for mode and setting indications.



Figure 2.1: Front view of the remote control, displaying the screen and control buttons.

Remote Control Buttons and Display Indicators:

- **ON/OFF Button:** Powers the air conditioner unit on or off.
- **MODE Button:** Cycles through available operating modes:

- *AUTO*: Automatically selects cooling or fan mode based on room temperature.
- *COOL*: Activates cooling function.
- *SAVE*: Energy-saving mode.
- *FAN*: Operates the fan only, without cooling.
- *DRY*: Dehumidification mode.
- **+/- Buttons**: Adjusts temperature settings (up/down) or timer settings.
- **FAN Button**: Controls fan speed settings.
- **I FEEL Button**: Activates the 'I FEEL' function, which senses the temperature at the remote's location for more precise comfort control.
- **SLEEP Button**: Initiates sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **TIMER Button**: Used to set the auto-on (T-ON) or auto-off (T-OFF) timer for the unit.

The display screen shows the current mode, set temperature, fan speed, and timer status (T-ON, T-OFF).

3. SETUP

3.1 Battery Installation

Before using the remote control, you must install the batteries. This remote requires two (2) AA batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: Back view of the remote control with the battery compartment.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

3.2 Initial Use

This remote control is a direct replacement and typically does not require any programming or pairing. Once batteries are installed, point the remote directly at the air conditioner unit's receiver and begin operation.

4. OPERATING INSTRUCTIONS

Ensure the remote control is pointed directly at the air conditioner unit's infrared receiver for proper communication.

- **Power On/Off:** Press the **ON/OFF** button to turn the air conditioner on or off.
- **Changing Modes:** Press the **MODE** button repeatedly to cycle through the available operating modes: AUTO → COOL → SAVE → FAN → DRY. The selected mode will be displayed on the remote's screen.
- **Adjusting Temperature:** In COOL or DRY mode, use the **+** or **-** buttons to increase or decrease the desired temperature.
- **Controlling Fan Speed:** Press the **FAN** button to adjust the fan speed. Options typically include Auto, Low, Medium, and High.

- **Using I FEEL Function:** Press the **I FEEL** button to activate this feature. The unit will then adjust its operation based on the temperature detected by the sensor in the remote control, providing more localized comfort.
- **Activating Sleep Mode:** Press the **SLEEP** button to engage sleep mode. This mode typically adjusts the temperature gradually and reduces fan speed for quiet, comfortable operation during sleep.
- **Setting Timers:** Press the **TIMER** button to set the auto-on (T-ON) or auto-off (T-OFF) timer. Use the **+** or **-** buttons to set the desired time, then press **TIMER** again to confirm.

5. MAINTENANCE

5.1 Cleaning the Remote Control

To maintain the appearance and functionality of your remote control:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

5.2 Battery Replacement

Replace batteries when the remote's range decreases, the display dims, or the remote stops responding. Refer to Section 3.1 for battery installation instructions. Always replace both batteries at the same time with new ones of the same type.

6. TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AA batteries, ensuring correct polarity.
Remote has short range.	Weak batteries; Obstruction between remote and AC unit.	Replace batteries. Ensure a clear line of sight to the AC unit's receiver.
Display is dim or blank.	Low battery power.	Replace batteries.
AC unit does not respond to specific functions.	Remote may not support all original functions; AC unit issue.	Verify if the function is supported by this replacement remote. Consult your AC unit's original manual for troubleshooting unit-specific issues.

7. SPECIFICATIONS

- **Brand:** Easytry123

- **Compatible Devices:** Air Conditioner (Soleus Air models: SG-PAC-08E3, SG-PAC-08E4, GH-PAC-10E5, GM-TTW-10ESE, GM-TTW-12ESE, SG-PAC-10E5, KY-100E5, GB-PAC-08E4, SG-PAC-10E2, GM-TTW-14, GM-TTW-12ESEZ)
- **Connectivity Technology:** Infrared
- **Controller Type:** Button Control
- **Batteries Required:** 2 x AA (not included)
- **Special Feature:** Ergonomic design
- **Country of Origin:** China

8. WARRANTY AND SUPPORT

Specific warranty information for this replacement remote control is not provided in the product details. For any issues or support inquiries, please refer to the seller or the platform where the purchase was made. It is recommended to retain your purchase receipt for any potential claims.