



[Manuals.plus](#) /

> [AVENT](#) /

> Philips Avent Natural Baby Bottles with Natural Response Nipples (Medium Flow, Flow 3), 9oz, 4-Pack, SCY903/04 Clear 4 Count (Pack of 1) Natural 9oz User Manual

AVENT SCY903/04

Philips Avent Natural Baby Bottles User Manual

Model: SCY903/04 | Brand: AVENT

PRODUCT OVERVIEW

The Philips Avent Natural baby bottles are designed to support your baby's natural drinking rhythm, mimicking breastfeeding. The unique Natural Response nipple releases milk only when your baby actively drinks, allowing them to control the pace of the milk flow. This design helps prevent spills and reduces colic and discomfort by keeping air away from your baby's tummy.



Image: Philips Avent Natural Baby Bottles, 9oz, 4-Pack.

Key Features:

- Natural Response Nipple: Baby controls milk flow, just like breastfeeding.
- No-Drip Design: Prevents spills and lost milk.
- Anti-Colic Valve: Reduces colic and discomfort.
- Wide, Soft, Breast-Shaped Nipple: Facilitates easy combination of breast and bottle feeding.
- Ergonomic Shape: Comfortable for parents to hold and easy for baby to grasp.
- BPA-Free Material: Made from polypropylene for safety.

ASSEMBLY AND INITIAL SETUP

Before first use, disassemble all parts and clean them thoroughly. To assemble the bottle, insert the Natural Response nipple into the screw ring until it clicks into place. Then, screw the assembled nipple and ring onto the bottle securely.



Uniquely designed opening & tip
Releases milk only when baby actively drinks



Image: Components of the Philips Avent Natural Baby Bottle.

USAGE INSTRUCTIONS

The Natural Response nipple is designed to work with your baby's natural feeding rhythm. Milk is released only when your baby actively sucks, and flow stops when they pause to swallow and breathe, similar to breastfeeding. This allows your baby to control the pace of feeding.



**Baby controls
the pace, just
like breastfeeding**

Image: Baby feeding comfortably from the Philips Avent Natural bottle.

Choosing the Right Nipple Flow Rate:

Philips Avent Natural bottles offer various nipple flow rates to match your baby's growth and feeding style. While age is a guide, observe your baby's feeding cues to determine the appropriate flow:

- **Start with the nipple that comes with the bottle (Medium Flow, Flow 3).**
- **Try a lower flow:** If milk is leaking from your baby's mouth or your baby is gulping.
- **Try a higher flow:** If your baby is playing with the nipple instead of drinking or seems frustrated.



Natural Response Nipple

Baby drinks, swallows, and breathes using their natural rhythm

Just like breastfeeding

When baby pauses to swallow and breathe, no milk flows

Image: Guide to Philips Avent Natural Response Nipple flow rates.

CLEANING AND CARE

For hygiene, it is crucial to clean all bottle parts after each use. The Philips Avent Natural bottles are designed for easy cleaning.

Cleaning Instructions:

- Disassemble all parts: bottle, screw ring, and nipple.
- Wash all components with warm, soapy water using a bottle brush. Ensure all milk residue is removed.
- Rinse thoroughly with clean water.
- The bottles are dishwasher safe (top rack recommended).
- For sterilization, you can use boiling water (immerse for 5 minutes), a steam sterilizer, or a microwave sterilizer.



No-drip nipple design
helps prevent lost
milk from the tip

Image: The no-drip nipple design, which also aids in easy cleaning.

TROUBLESHOOTING COMMON ISSUES

- **Milk not flowing easily from a new bottle:** It is completely natural for your baby to take 2-3 tries to get milk flowing from a new Natural Response bottle. This is part of adapting to the controlled flow.
- **Bottle leaking:** Ensure all parts (nipple, screw ring, and bottle) are assembled correctly and tightened securely. A loose connection can cause leaks.
- **Baby struggling with flow (too fast/too slow):** Refer to the