

[Manuals.plus](#) /

› [Music Sound](#) /

› Music Sound BREEZE Wireless Bluetooth Earbuds User Manual

Music Sound BTMSTWSBREEZEB

Music Sound BREEZE Wireless Bluetooth Earbuds User Manual

Model: BTMSTWSBREEZEB

INTRODUCTION

Thank you for choosing the Music Sound BREEZE Wireless Bluetooth Earbuds. These earbuds are designed to provide a free and uninterrupted listening experience, perfect for music, calls, and podcasts. Featuring an ergonomic capsule design, touch controls, and a long-lasting battery, your BREEZE earbuds offer comfort and convenience.

PACKAGE CONTENTS

Please ensure all items are present in your package:

- Music Sound BREEZE Wireless Earbuds
- Charging Case
- USB-C Charging Cable
- User Guide




Image: Music Sound BREEZE Package Contents, showing the two earbuds, the charging case, a USB-C charging cable, and the user guide.

PRODUCT OVERVIEW

Touch Controls

The BREEZE earbuds feature intuitive touch controls for easy management of music, calls, and voice assistant functions without needing to access your smartphone.




Image: Close-up of a Music Sound BREEZE earbud highlighting the touch control area and an LED battery level indicator.

Extended Playtime

Enjoy up to 20 hours of total playtime with the included charging case. A single charge provides approximately 5 hours of listening.

ALL DAY PLAY-TIME!

22

HOURS

with
charging
case



5

HOURS

single charge

Image: Music Sound BREEZE earbuds in their open charging case, with text indicating '22 HOURS with charging case' and '5 HOURS single charge'.

Comfortable and Portable Design

The ergonomic capsule design ensures a balanced sound and optimal comfort for extended use. The compact charging case makes the earbuds highly portable.



**COMFY AND
PERFECT FIT**

Image: A person smiling while wearing a Music Sound BREEZE earbud, illustrating a comfortable and secure fit.



Image: A hand placing the Music Sound BREEZE charging case into the back pocket of a pair of jeans, emphasizing its compact and portable nature.

SETUP

1. Charging the Earbuds and Case

1. Before first use, fully charge the earbuds and the charging case.
2. Connect the provided USB-C charging cable to the charging port on the case and to a USB power source.
3. The LED indicator on the case will show the charging status. Once fully charged, the indicator will change or turn off.
4. Place the earbuds into the charging case. They will automatically begin charging.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "Music Sound BREEZE" from the list.
4. Once connected, the earbuds will automatically pair with your device in the future when taken out of the case.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for 5 seconds.

Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long-press on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).

MAINTENANCE

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid exposing the earbuds to extreme temperatures, humidity, or liquids.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Do not attempt to disassemble or modify the product.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Music Sound BREEZE" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, then open it again. Ensure both earbuds are charged.
No sound	Check device volume. Ensure earbuds are connected to your device. Try re-pairing.
Charging case not charging	Check USB-C cable connection and power source. Try a different cable or power adapter.

SPECIFICATIONS

- **Brand:** Music Sound
- **Model Name:** BTMSTWSBREEZEB
- **Color:** Blue (Azzurro)
- **Ear Placement:** In-ear
- **Form Factor:** True Wireless

- **Noise Control:** Passive Noise Cancellation
- **Connectivity Technology:** Bluetooth (Wireless)
- **Included Components:** Earbuds, Charging Case, USB-C Charging Cable
- **Battery Life (Earbuds):** Up to 5 hours (single charge)
- **Battery Life (with Charging Case):** Up to 20 hours total

SAFETY INFORMATION

- Do not use the earbuds at high volume for extended periods to prevent hearing damage.
- Exercise caution when using earbuds in situations requiring awareness of your surroundings.
- Keep the product away from children and pets.
- Dispose of the product and its battery responsibly according to local regulations.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Music Sound website or contact their customer service. Keep your proof of purchase for warranty claims.

Visit [Music Sound Store](#) for more information.