

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [cellularline](#) /

› [cellularline KEY PRO In-Ear Earphones User Manual](#)

cellularline BTKEYPROTWSK

cellularline KEY PRO In-Ear Earphones User Manual

Model: BTKEYPROTWSK

INTRODUCTION

The cellularline KEY PRO In-Ear Earphones are designed to provide clear audio and versatile connectivity. Featuring Environment Noise Cancelling (ENC) with 4 integrated microphones, these earphones ensure crisp call quality by reducing background noise. With Multipoint Technology, you can connect to two devices simultaneously, and the advanced LED display provides real-time battery status for both the charging case and individual earbuds. Enjoy up to 30 hours of total playtime and intuitive touch controls for managing calls, music, and volume.

1. SETUP

1.1. What's in the Box

- cellularline KEY PRO In-Ear Earphones
- Wireless Charging Case
- User Manual

1.2. Initial Charging

Before first use, fully charge the earphones and the charging case. Place the earphones into the charging case. Connect the charging case to a power source using a compatible USB cable. The LED display on the case will indicate the charging status.



Image: The earphones and charging case. The image highlights a total playtime of 30 hours and a charger time of 6 hours, indicating battery life and charging duration.

A full charge provides approximately 30 hours of total playtime, with the charging case contributing to this extended battery life.

1.3. Pairing with a Device

Autopairing: Once removed from the charging case, the earphones will automatically connect to each other and enter pairing mode. Look for "cellularline KEY PRO" in your device's Bluetooth settings.

Multipoint Technology: These earphones support simultaneous connection to two devices. To connect a second device, ensure the earphones are already connected to the first device. Then, put the earphones back into pairing mode (refer to your device's Bluetooth settings or the earphones' touch control guide for specific instructions, if available). Connect the second device. The earphones will intelligently switch between the two connected devices as needed.



Image: The cellularline KEY PRO earphones are shown alongside a smartphone and a laptop, demonstrating their ability to connect to multiple devices simultaneously via Multipoint Technology.

2. OPERATING INSTRUCTIONS

2.1. Touch Controls

The KEY PRO earphones feature intuitive touch controls for managing various functions. Specific gestures (single tap, double tap, long press) on either earphone will control playback, calls, and voice assistance.




Image: A visual representation of the touch control functions on the earphone, including icons for managing calls, playing/pausing music, adjusting volume, skipping tracks, and activating voice assistance.

- **Call Management:** Answer, end, or reject calls.
- **Music Playback:** Play, pause, skip tracks.
- **Volume Control:** Adjust audio volume.
- **Voice Assistance:** Activate your device's voice assistant.

Refer to the detailed control scheme in the included quick start guide for precise gesture commands.

2.2. Environment Noise Cancelling (ENC)

The KEY PRO earphones are equipped with ENC technology and 4 microphones (2 per earphone) to reduce ambient noise during calls. This ensures your voice is transmitted clearly to the recipient, even in noisy environments.



Image: Two earphones are depicted with sound wave patterns, symbolizing the active noise cancellation feature during calls, enabled by the four integrated microphones.

2.3. LED Display

The charging case features an advanced LED display that shows the battery status of both the case and each individual earphone (Left 'L' and Right 'R') in real-time percentage. This allows for easy monitoring of remaining charge.



Image: A detailed view of the charging case's LED display, showing the battery levels for the left (L) and right (R) earphones, providing an instant battery-life check.

3. MAINTENANCE

3.1. Cleaning

Regularly clean your earphones and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe the surfaces. For ear tips, gently remove them and clean with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching. Avoid using harsh chemicals or abrasive materials.

3.2. Storage

When not in use, store the earphones in their charging case to protect them from dust, dirt, and physical damage. Store the case in a cool, dry place, away from direct sunlight and extreme temperatures.

3.3. Water Resistance

The cellularline KEY PRO earphones are designed to be waterproof. While they can withstand splashes and sweat, avoid submerging them in water for extended periods or exposing them to high-pressure water jets. Ensure the earphones are dry before placing them back in the charging case to prevent damage.

4. TROUBLESHOOTING

4.1. Earphones Not Pairing

- Ensure both earphones are charged.
- Place earphones back in the case, close the lid, then open it again to re-initiate autopairing.
- Turn off and on your device's Bluetooth.
- Forget the earphones from your device's Bluetooth list and attempt to pair again.

4.2. No Sound or Low Volume

- Check the volume levels on both your connected device and the earphones.
- Ensure earphones are properly seated in your ears.
- Clean any debris from the earphone speakers and ear tips.
- Reconnect the earphones to your device.

4.3. Charging Issues

- Verify the charging cable and power adapter are working correctly.
- Ensure the charging contacts on both the earphones and the case are clean and free of obstruction.
- Make sure the earphones are correctly seated in the charging case.

4.4. Call Quality Issues

- Ensure the microphones are not obstructed.
- Move to a quieter environment if ENC is struggling with excessive background noise.
- Check your device's network connection.

5. SPECIFICATIONS

Brand	cellularline
Model Name	BTKEYPROTWSK
Color	Nero (Black)
Ear Placement	In-ear
Form Factor	True Wireless
Noise Control	Environment Noise Cancelling (ENC)
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3

Control Method	Touch
Average Battery Life	30 Hours (Total Playtime)
Frequency Range	20 Hz - 20,000 Hz
Audio Driver Type	Balanced Armature Driver
Water Resistance Level	Waterproof
Compatible Devices	Mobile Phones, Laptops, Tablets
Included Components	Earphones, Wireless Charging Case, User Manual
Manufacturer	Cellularline S.p.A.
Country of Origin	China

6. WARRANTY INFORMATION

The cellularline KEY PRO In-Ear Earphones come with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in the packaging or visit the official cellularline website.

7. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your cellularline KEY PRO earphones that are not addressed in this manual, please contact cellularline customer support. You can typically find contact information on the official cellularline website or through the retailer where you purchased the product. For further assistance, please visit: www.cellularline.com