



Manuals.plus /

› Westinghouse /

› Westinghouse Contractor's Choice 52-inch Ceiling Fan Model 7303800 Instruction Manual

Westinghouse 7303800

Westinghouse Contractor's Choice 52-inch Ceiling Fan Instruction Manual

Model: 7303800

Brand: Westinghouse

1. INTRODUCTION

Thank you for choosing the Westinghouse Contractor's Choice 52-inch Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

2. SAFETY INFORMATION

- **Electrical Safety:** Always disconnect power at the main circuit breaker before attempting any installation, maintenance, or repair. Ensure all wiring connections comply with local electrical codes. If you are unsure about wiring, consult a qualified electrician.
- **Mounting:** The ceiling fan must be mounted to a securely supported outlet box or a building structure capable of supporting the fan's weight (approximately 15.8 pounds).
- **Blade Clearance:** Ensure there is adequate clearance between the fan blades and any obstacles, including walls and furniture, to prevent injury or damage.
- **Moving Parts:** Avoid placing objects in the path of the fan blades while the fan is operating.
- **Installation Environment:** This fan is designed for indoor use only. Do not install in damp or wet locations.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Housing
- 5 Fan Blades
- Mounting Bracket
- Downrod (for combo mount installation)

- Pull Chain for Speed Control
- Hardware Pack (screws, washers, wire nuts)



Figure 3.1: Overview of the Westinghouse Contractor's Choice 52-inch Ceiling Fan in black finish. This image displays the main components including the motor housing and five matte black blades.

4. SPECIFICATIONS

| Feature | Specification |
|------------------------|-----------------------------------|
| Model Number | 7303800 |
| Blade Span | 52 inches |
| Number of Blades | 5 |
| Finish | Black (Fan), Matte Black (Blades) |
| Dimensions (D x W x H) | 52" x 52" x 10.25" |
| Item Weight | 15.8 pounds |
| Air Flow Capacity | 4098.96 Cubic Feet Per Minute |
| Wattage | 65 watts |
| Voltage | 120 Volts |
| Noise Level | 20 Decibels |
| Control Type | Pull Chain |
| Installation Type | Combo Mount |
| Indoor/Outdoor Usage | Indoor |

5. SETUP AND INSTALLATION

This section outlines the general steps for installing your ceiling fan. For detailed, step-by-step instructions, refer to the separate installation guide included with your product packaging. Always ensure power is disconnected at the circuit breaker before starting.

5.1 Pre-Installation

- Turn off power at the circuit breaker.
- Ensure the existing electrical box is suitable for fan support or install a fan-rated support brace.
- Unpack all components and verify against the package contents list.

5.2 Mounting the Fan

The fan supports combo mount installation, allowing for standard downrod or flush mount options. Follow the specific instructions in your installation guide for your chosen mounting method.



Figure 5.1: A detailed view of the fan's motor housing and the attachment points for the blades, illustrating the robust design.



Figure 5.2: This image provides another perspective of the fan's construction, highlighting the blade arms and their connection to the central unit.

5.3 Wiring Connections

Connect the fan's electrical wires to the household wiring according to the provided wiring diagram in your installation guide. Ensure all connections are secure and properly insulated with wire nuts.

5.4 Attaching Blades

Securely attach the five fan blades to the motor housing using the provided screws. Ensure all blades are firmly fastened to prevent wobble during operation.



Figure 5.3: The Westinghouse Contractor's Choice ceiling fan seamlessly integrated into a modern living space, demonstrating its aesthetic appeal and functional placement.

6. OPERATING INSTRUCTIONS

Your Westinghouse Contractor's Choice ceiling fan is operated using a pull chain for speed control and a reverse switch for seasonal functionality.

6.1 Speed Control

The fan features multiple speed settings. Pull the chain once to turn the fan on at its highest speed. Subsequent pulls will cycle through lower speeds and then turn the fan off. Adjust the speed to your comfort level.

6.2 Reverse Function (Seasonal Use)

A slide switch on the fan's motor housing controls the direction of blade rotation. This allows for optimal air circulation throughout the year:

- **Summer Operation:** Set the switch to make the blades rotate counter-clockwise, creating a downward breeze that cools the room.
- **Winter Operation:** Set the switch to make the blades rotate clockwise, drawing warm air up towards the ceiling and distributing it evenly without creating a direct draft.

Note: Always turn off the fan and wait for the blades to stop completely before changing the direction of rotation.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Checking Connections:** Annually, inspect all screws and connections to ensure they are secure. Loose connections can cause noise or wobble.
- **Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

8. TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| Fan does not start | No power to the fan; Loose wire connections; Blown fuse or tripped circuit breaker. | Check circuit breaker/fuse box; Ensure all wire connections are secure; Verify power supply. |
| Fan wobbles | Loose blade screws; Unbalanced blades; Loose mounting hardware. | Tighten all blade screws; Use a blade balancing kit (sold separately) if needed; Ensure mounting bracket and downrod are securely fastened. |
| Noisy operation | Loose screws; Motor housing rubbing against ceiling; Incorrect blade installation. | Check and tighten all screws; Ensure canopy is not touching the ceiling; Re-install blades, ensuring they are flush and secure. |
| Insufficient airflow | Fan running in reverse for the season; Fan speed too low. | Check reverse switch for correct seasonal setting; Increase fan speed using the pull chain. |

9. WARRANTY AND SUPPORT

Your Westinghouse Contractor's Choice 52-inch Ceiling Fan is backed by a **Limited Lifetime Motor Warranty** and a **Two-Year Warranty** on all other parts. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or replacement parts, please contact Westinghouse customer support. Keep your proof of purchase for warranty validation.

For further information or to explore other Westinghouse products, visit the official Westinghouse website or authorized retailers.