

momcozy 140 cm x 83 cm

Momcozy Retractable Baby Safety Gate (140 cm x 83 cm), Grey

Model: 140 cm x 83 cm | Brand: Momcozy

IMPORTANT SAFETY INFORMATION

WARNING: Incorrect installation can be dangerous!

- Always read and follow all instructions carefully before installation and use.
- This safety gate is designed for children from 0 to 24 months.
- Never leave children unattended.
- Do not install the gate between stair treads.
- Do not install at the top of stairs without ensuring the gate opens away from the stairs.
- Do not install the gate on windows.
- Ensure the gate is installed between two rigid surfaces, such as a wall or solid wood. Avoid installing on drywall without proper wood support.
- Regularly check all fittings and components to ensure they are secure and in good working order.



A baby's hand reaching for a door handle, highlighting the importance of securing areas.

PRODUCT OVERVIEW

The Momcozy Retractable Baby Safety Gate provides a secure barrier for various openings in your home. Its retractable

design allows for flexible use and space-saving storage when not needed. This gate is suitable for both children and small to medium-sized pets.

Key Features:

- **Retractable Design:** The mesh barrier extends up to 140 cm and fully retracts when not in use, offering a space-saving solution.
- **One-Handed Operation:** Easily lock or unlock the gate with a simple push and turn of the knob, convenient when carrying a child.
- **Double Locking System:** Ensures enhanced security for children and pets. The durable mesh prevents injuries from accidental bumps.
- **Relocatable:** Includes two sets of mounting hardware, allowing the gate to be easily moved and used in multiple locations.
- **Versatile Installation:** Can be installed in doorways, stairways, or hallways, suitable for both indoor and outdoor environments.



A grey Momcozy retractable safety gate installed at the base of a staircase, providing a secure barrier.

SETUP & INSTALLATION

Follow these steps for proper installation of your Momcozy Retractable Baby Safety Gate. Ensure you have all components and tools before beginning.

Components Included:

- Retractable Gate Unit
- Mounting Brackets (2 sets)
- Screws
- Wall Anchors (for hard walls)
- Spacers (for baseboards)
- Drilling Guides/Templates

Recommended Tools:

- Drill
- Pencil
- Measuring Tape
- Level
- Screwdriver

Installation Steps:

1. **Choose Location:** Select a suitable location (doorway, hallway, or stairs) and ensure the mounting surfaces are rigid (solid wood or hard wall).
2. **Position Templates:** Use the provided drilling templates to mark the positions for the upper and lower mounting brackets on both sides of the opening. Ensure the gate unit is positioned correctly (e.g., the retractable side on one wall, the latch side on the opposite).
3. **Drill Holes:** Drill pilot holes at the marked positions. For hard walls, insert wall anchors. For wood, drill directly.
4. **Attach Brackets:** Securely attach the upper and lower mounting brackets using the provided screws. Use spacers if necessary to clear baseboards.
5. **Mount Gate Unit:** Attach the main retractable gate unit to its brackets.
6. **Attach Latch Side:** Attach the latch receiver brackets to the opposite wall, ensuring they align correctly with the gate's latch mechanism.
7. **Test Operation:** Fully extend and retract the gate several times to ensure smooth operation and secure locking.




Diagram showing suitable mounting surfaces: wood, hard wall, and caution for drywall.

Installation Videos:

Video: Step-by-step installation guide for the safety gate.

Video: Demonstrating versatile installation and relocation options.

OPERATING INSTRUCTIONS


The Momcozy Retractable Baby Safety Gate is designed for easy, one-handed operation.

To Open the Gate:

1. **Press and Push:** Gently press down on the knob located on the top of the gate handle.
2. **Turn to Unlock:** While pressing, turn the knob to the unlock position.
3. **Retract:** Guide the mesh barrier back into the main unit.

To Close and Lock the Gate:

1. **Extend Mesh:** Pull the mesh barrier across the opening until it reaches the latch receiver.
2. **Engage Latch:** Hook the gate handle into the latch receiver.
3. **Turn to Lock:** Press down on the knob and turn it to the lock position to secure the gate.



Visual guide for operating the gate's locking mechanism.

Operation Videos:

Video: Showcasing the retractable operation and safety features.

Video: Demonstrating convenient one-handed operation and compact design.

MAINTENANCE

Proper maintenance ensures the longevity and continued safety of your gate.

- **Cleaning:** Wipe the mesh and plastic components with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals.
- **Inspection:** Regularly inspect all parts for wear, damage, or loose connections. Pay close attention to the mesh, locking mechanism, and mounting brackets.
- **Lubrication:** If the retraction mechanism becomes stiff, a small amount of silicone-based lubricant can be applied to the moving parts, avoiding contact with the mesh.
- **Storage:** If storing the gate for an extended period, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter issues with your Momcozy Retractable Baby Safety Gate, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Gate does not retract smoothly.	Obstruction in the mechanism; dirt buildup; lack of lubrication.	Check for any obstructions. Clean the mechanism. Apply a small amount of silicone lubricant.
Gate does not lock securely.	Latch not fully engaged; knob not turned to lock position; misalignment of brackets.	Ensure the handle is fully seated in the latch receiver and the knob is turned to the locked position. Check bracket alignment and adjust if necessary.
Mesh appears loose at the bottom.	Improper installation; gate not fully extended or locked.	Ensure the gate is fully extended and locked. Verify that the bottom mounting points are secure and the gate is installed correctly according to instructions.
Gate is difficult to open/close.	Mechanism stiff; misalignment.	Apply lubricant to moving parts. Check for proper alignment of the gate and brackets.

SPECIFICATIONS

Feature	Detail
Brand	Momcozy
Model	Retractable Baby Safety Gate
Dimensions (L x H)	150 cm x 85.5 cm (Extended)
Maximum Opening Width	140 cm
Color	Grey
Material	Aluminum (frame), Durable Mesh (barrier)
Mounting Type	Door Frame Mounting (screw-in)
Closure Type	Retractable with Double Locking System
Age Range (Description)	Baby
Target Species	Child, Small to Medium Pets

WARRANTY AND SUPPORT

Momcozy products are manufactured to high-quality standards. For warranty information, product support, or to report any issues, please refer to the contact information provided with your purchase or visit the official Momcozy website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0967DHL9N>

More documents and user manuals: <https://manuals.plus/>