

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Reginox R34583

Reginox R34583 PALM Brushed Stainless Steel Mixer Tap

USER MANUAL

Introduction

Thank you for choosing the Reginox R34583 PALM Brushed Stainless Steel Mixer Tap. This high-quality single-lever kitchen faucet is designed for durability and ease of use, featuring a convenient pull-out spout and a sleek brushed stainless steel finish. This manual provides essential information for the safe installation, operation, and maintenance of your new faucet.

Safety Information

- Always turn off the main water supply before beginning any installation or maintenance work.
- Ensure all connections are secure to prevent leaks. Do not overtighten.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep small parts out of reach of children.
- Protect the faucet's finish from abrasive cleaners or tools.

Package Contents

Please verify that all components are present before beginning installation:

- Reginox R34583 PALM Mixer Tap (1 unit)
- Mounting hardware (nuts, washers, gaskets)
- Flexible connection hoses
- Pull-out sprayer with hose and counterweight
- User Manual (this document)

Specifications



Figure 1: Reginox R34583 PALM Mixer Tap, showcasing its brushed stainless steel finish and integrated pull-out sprayer.

Technical Specifications

Feature	Detail
Model Number	R34583
Material	Stainless Steel
Finish	Brushed
Installation Type	Single Hole, Deck Mount
Handle Type	Single Lever
Special Feature	Pull-Out Sprayer
Included Components	Sprayer




Figure 2: Detailed technical drawing showing the dimensions and installation requirements for the Reginox R34583 PALM Mixer Tap. Key dimensions include a total height of approximately 292mm and a spout reach of 220mm. The mounting hole diameter required is approximately 30mm.

Installation

This faucet is designed for single-hole, deck-mount installation. Refer to Figure 2 for precise dimensions and hole requirements.

- 1. Prepare the Sink/Countertop:** Ensure the mounting hole on your sink or countertop is clean and has a diameter of approximately 30mm (as indicated in Figure 2).
- 2. Install the Faucet:**
 - Place the rubber gasket on the base of the faucet.

- Insert the faucet body through the mounting hole.
- From underneath the sink, slide the metal washer and then the mounting nut onto the threaded shank.
- Tighten the mounting nut securely using a basin wrench or appropriate tool. Do not overtighten.

3. Connect Water Supply Lines:

- Connect the hot and cold flexible supply hoses to the corresponding water supply valves. Ensure the hot water line connects to the hot inlet on the faucet (usually marked with red or 'H') and the cold water line to the cold inlet (blue or 'C').
- Hand-tighten the connections, then use a wrench for a final quarter turn. Avoid overtightening.

4. Install Pull-Out Sprayer and Counterweight:

- Feed the pull-out sprayer hose through the faucet body and down into the cabinet.
- Attach the counterweight to the pull-out hose at a point that allows the sprayer to retract smoothly and fully.
- Connect the pull-out hose to the designated connection point on the faucet's underside.

5. Test for Leaks:

- Slowly turn on the main water supply.
- Check all connections for leaks. If leaks are present, tighten the connections slightly until they stop.
- Run water through the faucet for a few minutes to flush out any debris.

Operation

The Reginox R34583 PALM features a single lever for controlling both water flow and temperature, and a pull-out spout for extended reach.

- **Water Flow:** Lift the lever upwards to increase water flow. Push it downwards to decrease and turn off the water.
- **Temperature Control:** Move the lever to the left for hot water and to the right for cold water. Adjust the position between hot and cold to achieve the desired temperature.
- **Pull-Out Sprayer:** Gently pull the spout head away from the main faucet body to extend the sprayer hose. After use, guide the sprayer back into place; the counterweight will assist in retraction.

Maintenance

Proper care will ensure the longevity and appearance of your brushed stainless steel faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for stainless steel. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Avoid:** Do not use abrasive cleaners, scouring pads, steel wool, or cleaners containing ammonia, bleach, or acid, as these can damage the brushed finish.
- **Aerator Maintenance:** If water flow becomes restricted, the aerator at the tip of the spout may be clogged. Unscrew the aerator, clean any debris, and rinse it before reattaching.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Water leaks from base of faucet	Loose mounting nut or damaged gasket.	Tighten mounting nut. Check and replace gasket if damaged.

Water leaks from spout	Worn cartridge.	Contact Reginox support for a replacement cartridge.
Low water flow	Clogged aerator or debris in supply lines.	Clean aerator. Flush supply lines by disconnecting them and running water into a bucket.
Sprayer does not retract fully	Counterweight improperly positioned or obstructed hose.	Adjust counterweight position. Clear any obstructions around the hose under the sink.

Warranty and Support

Reginox products are manufactured to high standards and are designed for durability. For specific warranty information regarding your Reginox R34583 PALM Mixer Tap, please refer to the warranty card included with your purchase or visit the official Reginox website. For technical support, spare parts, or any other inquiries, please contact Reginox customer service directly.

Note: Spare parts availability information was not provided at the time of this manual's creation. Please contact the manufacturer for current details.

© 2023 Reginox. All rights reserved. Information in this manual is subject to change without notice.

Documents - Reginox – R34583

[\[pdf\]](#)

REGINOX 2021 4 luik ECK Brio 02 10 — QUEEN 60 INCL RESTENBAKJE Kastmaat 600 mm Diepte 160 130 Afmeting spoelbak 330 x 400 300 Totale afmeting 595 470 Reginox Programma engels be CataGH III COLORADO COMFORT Kastmaat 450 mm Diepte 160 mm Afmeting spoelbak 403 x 353 mm Totale afmeting ... SO RVS Artikelnummer R34590 114,50 LOGAN RVS Artikelnummer R31797 179,50 PALM RVS Artikelnummer **R34583** 136,50 SOMO RVS Artikelnummer R34569 125,50 OXON RVS Artikelnummer R34606 125,50 NEW Y...

lang:tl score:16 filesize: 1.88 M page_count: 2 document date: 2021-02-09

