

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Automatic Mechanical Watch Model O-S-G6675HP-BB User Manual

OLEVS O-S-G6675HP-BB

OLEVS Automatic Mechanical Watch Model O-S-G6675HP-BB User Manual

Comprehensive instructions for your OLEVS timepiece.

INTRODUCTION

This manual provides detailed instructions for the operation, maintenance, and care of your OLEVS Automatic Mechanical Watch, Model O-S-G6675HP-BB. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your watch.



Image: Front view of the OLEVS Automatic Mechanical Watch, Model O-S-G6675HP-BB, featuring a square silver-tone case, white dial with Roman numerals, moon phase, day, and date subdials, and a visible tourbillon mechanism. The watch is fitted with a black leather strap.

SETUP AND INITIAL OPERATION

Your OLEVS automatic mechanical watch is powered by the motion of your wrist and does not require a battery. For initial setup or after a period of inactivity, follow these steps:

1. **Initial Winding:** If the watch has stopped, gently rotate the crown clockwise approximately 30-40 times while it is in

the normal operating position (position 0). This will provide enough power reserve to start the movement.

2. **Setting the Time:** Pull the crown out to position 2. Rotate the crown to set the hour and minute hands. Push the crown back to position 0 when finished.
3. **Setting the Date:** Pull the crown out to position 1. Rotate the crown clockwise to adjust the date. Push the crown back to position 0 when finished. *Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.*
4. **Setting the Day of the Week:** Use the dedicated button on the side of the watch (typically located at the 2 o'clock position) to advance the day of the week. Press repeatedly until the correct day is displayed.
5. **Setting the Moon Phase:** Use the dedicated button on the side of the watch (typically located at the 4 o'clock position) to advance the moon phase indicator.
6. **Band Adjustment:** The watch comes with a leather strap. If adjustment is needed, use the provided bracelet adjustment tool to modify the strap length for a comfortable fit.



Image: Diagram illustrating the functions of the OLEVS watch. Labels point to the "Adjust Week Button" (top right), "Adjust the time and handle" (middle right, crown), and "Adjust Date Button" (bottom right). Insets show the 24-hour moon phase, date pointer, hollow flywheel (tourbillon), and week pointer locations on the dial.

OPERATING YOUR WATCH

Once set, your automatic watch will continue to run as long as it receives sufficient motion. Regular wear is recommended to maintain its power reserve.

- **Automatic Movement:** The watch is powered by an automatic mechanical movement. It winds itself through the natural motion of your arm. If worn daily for 8-10 hours, it should maintain its power reserve. If not worn for an extended period, it may stop and require manual winding as described in the "Setup" section.
- **Luminous Function:** The hands and markers feature a high-definition luminous coating. To activate the luminescence, expose the watch to a light source for approximately 30 seconds. This allows for clear time reading in low-light conditions.
- **Water Resistance (30M):** This watch is water-resistant to 30 meters (3 ATM). This means it is suitable for daily life waterproofing, such as hand washing, light rain, or accidental splashes. *It is not suitable for swimming, diving, or hot baths/showers, as steam and hot water can compromise the seals. Do not operate the crown or pushers while the watch is wet.*



Luminous Function

High definition luminous coating, short absorption and strong luminescence
Easy time control during the day and night






Image: The OLEVS watch dial in darkness, showcasing its activated luminous hands and hour markers, allowing for visibility in low-light conditions.



30M waterproof

Easily cope with the challenge of water spray and enhance the anti fog function
(All watches cannot be protected against warm water or hot water)

Mechanische Bewegung, Fusionszeitpunkt (Der Mond entspricht einer Vielzahl komplexer Funktionen und dem Quadratzei) zwischen den Handgelenken können Sie die Weisheit und Erfahrung der Uhrmacher





Image: The OLEVS watch submerged in water, illustrating its 30M water resistance feature. Water droplets splash around the watch.

Your browser does not support the video tag.

Video: A demonstration of the OLEVS 6675-Black strap watch, highlighting its fashion style, exquisite workmanship, luminous features, high-quality movement, soft leather strap, and buckle. The video also shows different color variants of the watch.

MAINTENANCE AND CARE

Proper care will help preserve the appearance and functionality of your OLEVS watch.

- **Cleaning:** Wipe the watch case and strap with a soft, dry cloth regularly to remove dust and oils. For the leather strap, avoid excessive moisture and harsh chemicals.
- **Storage:** When not wearing the watch, store it in a cool, dry place, away from direct sunlight and strong magnetic fields. The original gift box is suitable for storage.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures (hot or cold), sudden impacts, and strong vibrations.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones) as these can affect the accuracy of the mechanical movement.

TROUBLESHOOTING

If you encounter any issues with your watch, refer to the following common troubleshooting tips:

- **Watch Not Running or Stopping:**
 - Ensure the watch is sufficiently wound. Manually wind the crown 30-40 times clockwise.
 - Wear the watch regularly (8-10 hours daily) to allow the automatic movement to maintain its power reserve.
- **Time Inaccuracy:**
 - Check if the watch has been exposed to strong magnetic fields. If so, a professional watchmaker may need to demagnetize it.
 - Ensure the watch is fully wound.
- **Fog or Water Droplets Inside the Dial:**
 - This indicates a breach in water resistance. Immediately contact OLEVS customer service for maintenance to prevent internal damage. Do not attempt to dry it yourself.

SPECIFICATIONS

Brand	OLEVS
Model Number	O-S-G6675HP-BB
Movement Type	Automatic Mechanical
Display Type	Analog
Dial Diameter	42 mm
Dial Thickness	10 mm
Weight	110g
Band Width	22mm
Strap Length	22 cm (8.66 inches), adjustable
Water Resistance	30M (3 ATM) - Splash/rain resistant, not for swimming/diving/hot water.
Features	Moon Phase, Day, Date, Skeleton Tourbillon, Luminous Hands/Markers

WARRANTY AND SUPPORT

OLEVS is committed to providing high-quality products and customer satisfaction. If you have any questions or concerns regarding your watch, please contact our customer service team.

If you receive a watch that is unsatisfactory, please contact us immediately before leaving feedback or initiating a return. We are dedicated to providing 100% satisfaction and service to resolve any issues you may encounter.

For support, please refer to the contact information provided with your purchase or visit the official OLEVS website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question