Nerf F2694

Nerf Elite Disrupter Blaster F2694 Instruction Manual

Model: F2694

Introduction

This manual provides essential instructions for the safe and effective use of your Nerf Elite Disrupter Blaster. Please read all instructions carefully before operating the blaster. The Nerf Elite Disrupter Blaster features a 6-dart rotating drum, allowing for rapid dart firing. It supports both single-dart firing and slam-fire action.

Safety Information

Ages 8 and up
TO AVOID EYE INJURY: WARNING: Do not aim at eyes or face. Use of eyewear recommended for players and people within range. Use only official Nerf darts. Other darts may not meet safety standards. Do not modify darts or blaster. WARNING: CHOKING HAZARD - Small parts may be generated. Not for children under 3 years.

What's in the Box

- 1 x Nerf Elite Disrupter Blaster
- 6 x Official Nerf Elite Darts
- Instruction Manual



Image: The Nerf Elite Disrupter Blaster shown alongside its brown, recyclable packaging.

Setup

1. **Load Darts:** Insert one Official Nerf Elite dart into each of the six chambers in the rotating drum. Ensure darts are fully seated.



Image: A child's hand demonstrating how to load a dart into the front of the blaster's rotating drum.

Operating the Blaster

1. **Prime the Blaster:** Pull back the priming slide located on top of the blaster until it clicks into place. A visual indicator will confirm it is primed.
2. **Single-Dart Firing:** Aim at your target. Press the trigger to fire one dart.
3. **Slam-Fire Action:** For rapid firing, hold down the trigger continuously. While holding the trigger, repeatedly move the priming slide back and forth to unleash all six darts quickly.



Image: A child wearing safety glasses, holding the Nerf Elite Disrupter Blaster in an aiming position.



Image: A close-up of a child's hand positioned on the trigger and grip of the Nerf Elite Disrupter Blaster.

Maintenance

- **Cleaning:** Wipe the blaster with a dry or slightly damp cloth. Do not submerge in water.
- **Dart Care:** Keep darts clean and dry. Avoid bending or damaging darts, as this can affect performance.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight.



Image: The Nerf Elite Disrupter Blaster resting on a white table, with several darts placed nearby.

Troubleshooting

- **Darts not firing or jamming:**
  - Ensure the blaster is fully primed by pulling the slide back until it clicks.
  - Check that only Official Nerf Elite darts are being used and that they are not damaged or bent.
  - Verify darts are fully inserted into the drum chambers.
- **Reduced firing range:**
  - Ensure darts are in good condition and not worn out.
  - Confirm the blaster is properly primed before each shot.

Specifications

Feature	Detail
Model Number	F2694
Product Dimensions	14.25 x 3.11 x 7.64 inches
Item Weight	12.3 ounces
Manufacturer Recommended Age	8 years and up
Dart Capacity	6 Darts (Rotating Drum)

Feature	Detail
Firing Modes	Single-shot, Slam-fire

Warranty and Support

This product is manufactured by Hasbro. For information regarding warranty, product support, or replacement parts, please visit the official Nerf website or contact Hasbro customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, please refer to the contact information provided on the product packaging or the official brand website: Visit the Nerf Store on Amazon

© 2025 Nerf / Hasbro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question