Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney 38121

Disney Junior Fire Rescue Mickey Mouse Action Figure User Manual

Model: 38121

Introduction

The Disney Junior Fire Rescue Mickey Mouse figure is designed for imaginative play, allowing preschoolers to engage in exciting firefighting adventures. This poseable action figure comes equipped with accessories to enhance the play experience.

What's in the Box

- Mickey Mouse figure (6 inches tall)
- Backpack with water cannon
- "Water" ball projectile



Image: The complete Disney Junior Fire Rescue Mickey Mouse figure set, including the 6-inch Mickey figure, the detachable backpack with water cannon, and the blue "water" ball projectile, shown both in and out of its original packaging.

Setup

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all listed items are present.
2. **Attach Water Cannon:** Connect the water cannon to the backpack accessory. The backpack then attaches to the Mickey Mouse figure.
3. **Load "Water" Ball:** Insert the blue "water" ball into the front of the water cannon.



Image: A close-up view of the Fire Rescue Mickey Mouse figure, demonstrating how the water cannon accessory is attached to the figure's back, ready for play.

Operating Instructions

Figure Articulation

- The Mickey Mouse figure features 6 points of articulation, allowing for various poses.
- To activate the torso rotation and arm swing action, gently squeeze Mickey's legs together. This simulates a water-spraying motion.



Image: The Mickey Mouse figure with arrows indicating the leg-squeezing action that causes the torso to rotate and arms to swing, simulating a firefighting motion.

Water Cannon Operation

- Ensure the "water" ball is properly loaded into the cannon.
- Press the button located on the water cannon to launch the "water" ball projectile.



Image: A dynamic shot of the Mickey Mouse figure's water cannon launching the blue "water" ball, with text overlay "SHOOTS 'WATER' BALLS!".

Maintenance

- Clean the figure and accessories with a soft, damp cloth. Do not submerge in water.
- Avoid exposing the toy to extreme temperatures or direct sunlight for prolonged periods.
- Store the "water" ball in a safe place when not in use to prevent loss.

Troubleshooting

Problem	Solution
"Water" ball does not launch.	Ensure the "water" ball is fully inserted into the cannon. Check for any obstructions in the launching mechanism.
Figure's articulation is stiff.	Gently manipulate the joints to loosen them. Avoid excessive force.
Backpack/cannon detaches easily.	Ensure the accessory is securely snapped into place on the figure's back.

Specifications

Product Dimensions: 7 x 4 x 9 inches

Item Weight: 9.2 ounces

Model Number: 38121

Manufacturer: Just Play

Recommended Age: 36 months - 8 years

Articulation: 6 points



Image: The Fire Rescue Mickey Mouse figure standing upright, with a graphic overlay indicating its approximate height of 6 inches.

Safety Information

WARNING: This product contains small parts and a small ball, which may pose a choking hazard. Not suitable for children under 3 years of age. Adult supervision is recommended during play.

Warranty and Support

For any questions regarding this product, please contact the manufacturer, Just Play, directly. Specific warranty details may be included with the product packaging or available on the manufacturer's official website.

© 2024 Disney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B096BMS5J1

More documents and user manuals: **https://manuals.plus/**