

FYOUNG TYX-586B

FYOUNG 2.4Ghz Mini QWERTY Keyboard for Xbox Series X/S and Xbox One/S Controllers

Model: TYX-586B
Brand: FYOUNG

INTRODUCTION

This manual provides instructions for the FYOUNG 2.4Ghz Mini QWERTY Keyboard, designed to enhance your gaming experience on Xbox Series X/S and Xbox One/S controllers. This accessory allows for easy text input during gameplay, facilitating communication and navigation.

PRODUCT OVERVIEW AND FEATURES

The FYOUNG Mini QWERTY Keyboard is a compact and efficient accessory for your Xbox controller. Key features include:

- **Compatibility:** Specifically designed for Xbox Series X/S and Xbox One/S controllers. It functions correctly after controller software updates.
- **Full QWERTY Keyboard:** Provides a complete QWERTY layout with firm buttons for typing text, emails, and entering codes, ideal for in-game chat.
- **No External Charging Required:** The keyboard utilizes a 2.4G protocol for data transfer and draws power directly from the controller, eliminating the need for an additional charging cable.
- **Dual Audio Jack:** Features both the original earphone jack and an additional 3.5mm audio jack port for Xbox Series X/S, allowing you to use headphones or earphones without removing the keyboard.
- **Ultra-Compact Design:** Constructed with silica gel on the key surface and a metal dome switch at the bottom for improved tactile feedback and a compact form factor.



Figure 1: Labeled components of the FYOUNG Mini QWERTY Keyboard.

Universal Compatibility

For X- One



For X- One S/ X- Series X/S



Figure 2: Universal compatibility with Xbox One and Xbox Series X/S controllers.

SETUP INSTRUCTIONS

1. **Attach the Keyboard to the Controller:** Align the keyboard with the bottom port of your Xbox Series X/S or Xbox One/S controller. Gently push until it clicks securely into place. Ensure the audio jack adapter on the keyboard aligns with the controller's audio port.
2. **Connect the 2.4G Receiver:** Locate the 2.4G USB receiver stored within the keyboard. Insert this receiver into an available USB port on your Xbox console.
3. **Power On and Pair:** Turn on your Xbox console and controller. The keyboard should automatically connect. If it does not connect automatically, press the "Code matching key" on the keyboard to initiate pairing.

It can be perfectly placed on your controller and is easy to install or remove



47-in-1 controller keyboard

Figure 3: Attaching the keyboard to the Xbox controller.



Figure 4: Inserting the 2.4G USB receiver into the console.

Video 1: Demonstration of attaching the keyboard to the controller and connecting the USB receiver to the console for use.

OPERATING INSTRUCTIONS

Once the keyboard is successfully connected, you can use it for text input:

- **Typing:** Use the QWERTY keys to type messages, search queries, or enter codes within your Xbox interface or compatible games.
- **Special Characters:** Access numbers and symbols using the designated keys.
- **Audio Functionality:** Connect your headset or earphones to either the original controller's audio jack (if accessible) or the 3.5mm audio jack on the keyboard for in-game audio and chat.

Full Keyboard At Your Fingertips



Figure 5: Using the keyboard for text input during gameplay.

MAINTENANCE

To ensure the longevity and optimal performance of your FYOUNG keyboard:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the ports.
- **Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the keyboard or subjecting it to strong impacts. Do not attempt to disassemble the device.

TROUBLESHOOTING

If you encounter issues with your FYOUNG keyboard, please refer to the following:

- **Keyboard Not Responding:**

- Ensure the 2.4G USB receiver is securely plugged into a USB port on your Xbox console.
- Verify the keyboard is correctly attached to the controller and fully seated.
- If automatic connection fails, press the "Code matching key" on the keyboard to re-pair it with the receiver.
- Check if your Xbox controller's software is up to date.

• **Audio Issues:**

- Ensure your headset or earphones are properly plugged into the 3.5mm audio jack on the keyboard or controller.
- Check your Xbox audio settings to ensure the correct output device is selected.

• **Keys Not Functioning:**

- Clean the keyboard surface to remove any debris that might be obstructing the keys.
- Restart your Xbox console and controller, then re-attach the keyboard and receiver.

SPECIFICATIONS

Model Number	TYX-586B
Manufacturer	FYOUNG
Connectivity	2.4Ghz Wireless
Compatibility	Xbox Series X/S, Xbox One/S Controllers
Audio Ports	Original Headset Jack Passthrough, 3.5mm Audio Jack
Power Source	Controller-powered (no external battery required)
Item Weight	2.82 ounces (approximately 80 grams)
Package Dimensions	7.13 x 2.52 x 1.93 inches (approximately 18.1 x 6.4 x 4.9 cm)

SPACE-SAVING DESIGN

Small size, easy to carry.



Figure 6: Product dimensions.

SAFETY INFORMATION

Please read and follow these safety guidelines:

- Keep the device away from water and other liquids.
- Do not expose to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to open or repair the device yourself. Refer to qualified service personnel.
- Dispose of electronic waste responsibly according to local regulations.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official FYOUNG website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B096D6GGTT>

More documents and user manuals: <https://manuals.plus/>