

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MCombo](#) /

› [MCombo Power Lift Recliner Chair Model 7519 User Manual](#)

MCombo 7519

MCombo Power Lift Recliner Chair User Manual

Model: 7519



Image: The MCombo Power Lift Recliner Chair, Model 7519, in black faux leather.

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your MCombo Power Lift Recliner Chair, Model 7519. Designed for comfort and ease of use, this chair features power lift assistance, heat and massage functions, USB charging ports, and convenient cup holders. Please read this manual thoroughly before use to ensure safe and proper operation.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, and injury, please adhere to the following safety guidelines:

- Always consult your doctor before using the product if you have any health concerns.
- Ensure the chair is placed on a level surface.
- Keep children and pets away from the chair's moving parts, especially during operation.
- Do not allow anyone to sit on the footrest when it is extended.
- Avoid placing hands or feet near the mechanism under the chair.
- Unplug the chair from the power outlet before cleaning or performing any maintenance.
- Do not operate the chair if the power cord or plug is damaged.
- Do not use the chair in a damp or wet environment.
- The maximum weight recommendation for this chair is 320 pounds. Do not exceed this limit.

PACKAGE CONTENTS

Your MCombo Power Lift Recliner Chair is delivered in two boxes. Please verify that all components are present before beginning assembly.

- Backrest
- Base
- Left Armrest
- Right Armrest
- Accessories Box (includes power adapter, remote control, etc.)
- Manual

What's Inside Each Box




Image: Contents of each box, illustrating the main components: Base, Right Armrest, Backrest, Left Armrest, Manual, and Parts Box.

ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is designed to be straightforward and typically takes about 20 minutes for a novice. No additional tools are required.

1. **Step 1: Attach the Backrest.** Align the metal slots on the backrest with the corresponding posts on the chair base. Push down firmly until the backrest locks into place.
2. **Step 2: Attach the Armrests.** Slide the left and right armrests onto their respective side rails on the chair base. Ensure they are securely seated.
3. **Step 3: Connect the Wiring.** Locate the electrical cables extending from the backrest, armrests, and base. Connect them according to the color-coded or labeled connectors. Ensure all connections are secure.
4. **Step 4: Connect Power.** Plug the power adapter into the chair's power input, then plug the adapter into a standard wall outlet.
5. **Step 5: Test Functions.** Use the remote control to test the lift, recline, massage, and heat functions to ensure proper operation.



Lumbar Heat



8 Vibrating Nodes




Image: Visual guide for chair assembly, detailing the connection points for the backrest and armrests.

OPERATING INSTRUCTIONS

Power Lift and Recline Functions

The chair features a counter-balanced lift mechanism and smooth reclining. Use the two-button remote control to adjust the chair's position.


- **To Recline:** Press and hold the **down arrow** button on the remote. The chair will smoothly recline to your desired position, up to a maximum angle of 140°. The footrest will extend as you recline.
- **To Lift/Stand:** Press and hold the **up arrow** button on the remote. The chair will gently lift and tilt forward, assisting you to a standing position.
- **TV Position:** Release the button at an intermediate position for a comfortable viewing angle with the footrest extended.



Reclined



TV



UP

2 Buttons
3 Positions



Image: Remote control and illustrations of the three primary chair positions: Reclined, TV, and Lift (UP).

Massage and Lumbar Heating Functions

The chair is equipped with full-body vibration massage and a lumbar heating function, controlled by a separate remote.

- **Power On/Off:** Press the "POWER" button to activate or deactivate the massage and heat functions.
- **Intensity:** Adjust massage intensity (HIGH/LOW) using the "INTENSITY" button.
- **Mode:** Select from various massage modes (PULSE, PRESS, WAVE, AUTO, NORMAL) using the "MODE" button.
- **Vibrating Points:** Choose specific vibrating areas (BACK, LUMBAR, THIGHS, LEGS) by pressing the corresponding buttons.
- **Heating:** Press the "HEAT" button to activate the lumbar heating function. The heating function works independently of vibration but can be used simultaneously.

- **Timer:** The massage and heat functions can be timed for specific durations. Refer to the massage remote's specific instructions for timing options.



Lumbar Heat

8 Vibrating Nodes

4.7" Extended Footrest

Image: Illustration of the chair's lumbar heat and 8 vibrating nodes, accompanied by the massage remote control with various settings.

Convenient Features

- **USB Ports:** Two USB charging ports are integrated into the chair for convenient charging of mobile devices.
- **Cup Holders:** Two cup holders are provided for beverages.
- **Side & Front Pockets:** Multiple pockets are available for storing remote controls, magazines, or other small items.
- **Extended Footrest:** The 4.7-inch extended footrest provides full leg support, preventing feet from dangling and improving circulation.

Expect more Get more.

2 Anti-falling Ropes

2 USB Charge Ports

2 Cup Holders

2 Side & Front Pockets



Image: Detailed view of the chair's armrest, highlighting the USB charging ports, cup holders, and storage pockets.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your MCombo recliner chair.

- Cleaning:** The faux leather upholstery is easy to clean. Wipe with a dry or damp lint-free cloth. Avoid using harsh chemicals or abrasive cleaners.
- Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- Mechanism:** Periodically check all bolts and screws to ensure they are tight. Do not lubricate the reclining mechanism.
- Power Cord:** Inspect the power cord regularly for any signs of damage. If damaged, discontinue use and contact customer support.
- Placement:** Avoid direct sunlight exposure and proximity to heat sources to prevent material degradation.

TROUBLESHOOTING

If you encounter issues with your MCombo Power Lift Recliner Chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not operate (no movement, no power).	<ul style="list-style-type: none">◦ Power cord not plugged in.◦ Loose connection in wiring.◦ Power outlet not functioning.◦ Remote control issue.	<ul style="list-style-type: none">◦ Ensure power cord is securely plugged into the chair and a working wall outlet.◦ Check all internal wiring connections (refer to assembly steps).◦ Test the outlet with another appliance.◦ Ensure the remote control cable is securely connected to the chair.
Massage or heat function not working.	<ul style="list-style-type: none">◦ Massage remote not connected or powered on.◦ Specific function not selected.	<ul style="list-style-type: none">◦ Ensure the massage remote is properly connected and the "POWER" button is pressed.◦ Verify that the desired massage mode or heat function is selected on the remote.
Chair makes unusual noises.	<ul style="list-style-type: none">◦ Loose hardware.◦ Mechanism friction.	<ul style="list-style-type: none">◦ Check and tighten all visible bolts and screws.◦ If noises persist, contact customer support. Do not attempt to lubricate the mechanism yourself.

If the problem persists after attempting these solutions, please contact MCombo Customer Support.

SPECIFICATIONS

Feature	Detail
Brand	MCombo
Model Name	7519 (also 6160-7519)
Color	Black (for this specific variant)
Product Dimensions (D x W x H)	36.6"D x 33.5"W x 42.5"H
Recommended Height	5'1" - 5'9"
Maximum Weight Recommendation	320 Pounds
Material	Faux Leather (Finish Type), Foam (Fill Material)

Feature	Detail
Reclining Angle	Max 140°
Extended Footrest Length	4.7 inches
Special Features	Power Lift Assistance, Heat, Massage (8 vibrating nodes), 2 USB Ports, 2 Cup Holders, Side & Front Pockets
Item Weight	113.5 pounds
Assembly Time (Approx.)	20 minutes

Ideal Height : 5'1-5'9 Model : 7519







Image: Dimensional drawing of the MCombo recliner, showing key measurements for height, width, depth, and seat/backrest dimensions.

WARRANTY INFORMATION

MCombo provides a **2-Year Limited Manufacturer Warranty** for this product. This warranty covers:

- Reclining and Lift Mechanism
- Electrical Parts
- Upholstery Material
- Cushions
- Wood and Metal Frame

Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your accessories box or contact MCombo Customer Support.


CUSTOMER SUPPORT

For any questions, concerns, or assistance with your MCombo Power Lift Recliner Chair, please contact MCombo Customer Support. You can typically find contact information on the MCombo official website or through your purchase platform.

For more information and to explore other MCombo products, visit the official MCombo Store [MCombo Store on Amazon](#).

© 2023 MCombo. All rights reserved.

Related Documents - 7519

	<p>Mcombo Lift Recliner Owner's Manual: Assembly, Operation, and Care</p> <p>Comprehensive owner's manual for the Mcombo Lift Recliner, covering assembly instructions, operating procedures, care and maintenance, troubleshooting, warranty, and return policy. Includes model numbers 6160-7893, 6160-7679, 6160-7680.</p>
	<p>Mcombo Lift Chair 6160-7040DB Assembly and Operation Guide</p> <p>Comprehensive assembly and operation guide for the Mcombo Lift Chair 6160-7040DB, detailing parts, assembly steps, remote control functions, and troubleshooting tips.</p>
	<p>Massage Recliner Assembly Instructions and User Guide</p> <p>Comprehensive assembly instructions and FAQ for the Mcombo Massage Recliner, detailing setup, operation of the remote control, reclining functions, and troubleshooting common issues.</p>
	<p>MCombo Lift Recliner Owner's Manual - Assembly, Operation, and Care Guide</p> <p>Comprehensive owner's manual for the MCombo Lift Recliner (Model 6160-7666), covering safety guidelines, assembly instructions, operating procedures, care and maintenance, troubleshooting, warranty, and return policy.</p>

	<p>MCombo 6160-7040 Recliner Sofa Assembly Instructions</p> <p>Comprehensive assembly instructions for the MCombo 6160-7040 Recliner Sofa, covering installation, operation of remote controls for massage and standing-up aid, and customer support information.</p>
	<p>MCombo Power Lift Recliner Owner's Manual - Model 6160-7287</p> <p>Comprehensive owner's manual for the MCombo Power Lift Recliner, model 6160-7287. Includes detailed parts list, step-by-step assembly instructions, remote operation guide, and warranty information.</p>

Documents - MCombo – 7519



[**MCombo Lift Recliner Owner's Manual - Model 6160-7519/7529**](#)

Comprehensive owner's manual for the MCombo Lift Recliner (Medium-Regular), model 6160-7519/7529. This guide covers essential safety guidelines, detailed assembly instructions, operating procedures for lift and massage functions, care and maintenance tips, troubleshooting common issues, disassembly steps, warranty information, and the return/replacement policy. Includes product parameters and customer support contact details.

lang: score:36 filesize: 5.06 M page_count: 16 document date: 2025-03-03

[pdf] User Manual Owner's Manual Instructions Diagram

6160 7519 Owner Manual Power Lift Recliner Chair with Massage and Heat Faux Leather Red Barrel Studio® w000491397 W000491397Red 0845356AB19F473C97F5B05D48806FF6 1BEE92571DF64DA28679460DB5E1BCCC 3524528712A04B53BB6AF185CDE9016F 63422A366EF24AF5A0FBF5291928827A A7B9F635D4E14DB89E0A4894F3B60CD46160 owner s manualsecure img1 ag wfcdn dm document ff915c41 805b 4460 9d3a 11a0a5a1433c manual W000491397Owner Reclining Fabric Newacme LLC ndck1357 7529Red A7B9F635D4E14DB89E0A4894F3B60CD4Newacme 7529BG6160 manual6160 ndck1400 Latitude Run® ndck1469 W008395916Owner 75296160 OWNER S MANUAL Upholstered Heated MCombo ndck1468 7529NB6160 ndck1502 7539NBLRed A7B9F635D4E14DB89E0A4894F3B60CD4Red A7B9F635D4E14DB89E0A4894F3B60CD4Latitude 5F520EB279194A74953CF47CD8E6B175Newacme 7529BGMCombo 7529NBMCombo 7539NBL6160 Northshire 34 6 Wide Assist Standard Massager Hokku Designs ndck1612 W011289919Owner 7529Owner ndck1712 W1002727916160 ndck1775 7519RED6160 ndck1707 7529WN6160 7539NBLHokku 3F7CECD672C647738A91BC0C3619AC31Red 7529BGLatitude 137A5DF8A985452881A682816B7805A7 555B9E9C16E847C4B5C9CCBDE76D46EF 5C028E01ED2648B4B76A4119B7F78980 CD04D625B682442EAFFF7751359A8D19 F804ABC12D642DAA99E6D6455539617Newacme 7519REDMCombo 7529WNMCombo w008395916 44977E7BDCA541A3B813F7BAD886D6E7 5F520EB279194A74953CF47CD8E6B175 9E82616B03194A5CBB1FD902D2D4C060 C133EB1FDED7417F904D92F3FB17425C D6DB0C9677AF48839853ED4BF27724C3Latitude 7539NBLOwner w011289919 W011289919Hokku 7539NBLw011289919 3F7CECD672C647738A91BC0C3619AC316160 W011289919Installation And AssemblyHokku 3F7CECD672C647738A91BC0C3619AC31Latitude Reviews Wayfair6160 manualassets ||| Lift Recliner Assembly Instructions Backrest STEP 1 B2 B1 X2 Armrests Base Lift Remote Power Cord STEP 2 X2 Parts X4 Parts Massage Remote B2 B1 - 01 - Lift Recliner Assembly Instructions STEP 3 Schematic diagram of wiring connection for the Lift Recliner Assembly Instructions Backrest STEP 1 B2 B1 X2 Armrests Base Lift Remote Power Cord STEP 2 X2 Parts X4 Parts Massage Remote B2 B1 - 01 - Lift Recliner Assembly Instructions STEP 3 Schematic diagram of wiring connection for the chair. - 02 - Lift Recliner Assembly Instruct...

lang:en score:17 filesize: 3.9 M page_count: 5 document date: 2023-04-13

