

Remington EC9001

Remington PROLUXE HydraCare Hair Dryer (Model EC9001) Instruction Manual

1. SAFETY INFORMATION

Please read all instructions carefully before using the Remington PROLUXE HydraCare Hair Dryer. Keep this manual for future reference.

- Keep out of reach of children.
- Do not rinse or submerge the appliance in water.
- Keep the power plug and cord away from heated surfaces.
- Do not use the hair dryer while bathing or in a wet environment.
- Allow the hair dryer to cool before storing.
- Follow the directions provided with the product for safe operation.

2. PRODUCT OVERVIEW

The Remington PROLUXE HydraCare Dryer is designed to provide efficient hair drying with advanced heat protection. It features innovative technologies to help maintain hair health and achieve desired styles.



Figure 1: Front view of the Remington PROLUXE HydraCare Hair Dryer.

Key Features:

- **HydraCare Sensor:** Continuously regulates air temperature to protect against heat damage.
- **Powerful Digital Motor:** Delivers high airspeed for faster drying.
- **Ionic Conditioning:** Distributes millions of ions for a smooth, shiny finish.
- **Moisture Lock Conditioning Technology:** Releases micro-conditioners to help preserve moisture balance.
- **Multiple Heat & Speed Settings:** Three heat and two speed settings with LED indicators for personalized styling control.

Expert Results. No Added Heat Damage*



*Drying with HydraCare™ Sensor on vs. air-dried hair
in third party lab tests.

Figure 2: Hair dryer shown with the diffuser attachment.



HydraCare™ Sensor

ULTIMATE PROTECTION
AGAINST HEAT DAMAGE*

Drying with HydraCare™ Sensor on vs. air-dried hair in third party lab tests.

Figure 3: Detail of the HydraCare Sensor, which regulates air temperature.



Powerful Digital Motor for Ultra Fast Drying

Figure 4: View of the powerful digital motor for ultra-fast drying.

3 Heat/2 Speed Settings with LED Indicators

PERSONALIZE STYLING
CONTROL



Figure 5: Controls for heat and speed settings, indicated by LEDs.



Figure 6: Moisture Lock Conditioning Technology helps preserve hair's natural moisture balance.

3. SETUP

Before first use, ensure the hair dryer is clean and free from any packaging materials.

Attaching Accessories:

1. Select the desired attachment (wide concentrator, slim concentrator, or diffuser).
2. Align the attachment with the nozzle of the hair dryer.
3. Gently push the attachment onto the nozzle until it clicks securely into place.
4. To remove, pull the attachment straight off the nozzle.



Figure 7: The hair dryer comes with a diffuser and two concentrator nozzles.

4. OPERATING INSTRUCTIONS

Follow these steps for effective and safe use of your hair dryer:

1. Plug in the hair dryer to a suitable power outlet.
2. Select your preferred heat and speed settings using the control switches. LED indicators will illuminate to show the selected settings.
3. For a smooth finish, activate the 'Ionic Conditioning' feature if available.
4. To preserve moisture balance, utilize the 'Moisture Lock Conditioning Technology' by selecting the appropriate setting.
5. Dry your hair while continuously moving the hair dryer to avoid concentrating heat in one area and prevent heat damage.
6. For curls and waves, attach and use the diffuser.
7. Once drying is complete, use the cold shot setting to set and lock in your style.
8. Unplug the appliance after use.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your hair dryer.

Cleaning the Air Filter:

1. Ensure the hair dryer is unplugged and completely cool before cleaning.
2. Locate the rear air filter cover.
3. Gently twist or pull to remove the filter cover.
4. Remove any accumulated dust or hair from the filter using a soft brush or cloth.
5. Replace the filter cover, ensuring it is securely reattached.

Storage: Allow the hair dryer to cool completely before storing. Store in a dry place, away from moisture and direct sunlight. Do not wrap the cord tightly around the appliance, as this can cause damage.

6. TROUBLESHOOTING

If you encounter any issues with your Remington PROLUXE HydraCare Hair Dryer, refer to the following common solutions:

- **Appliance does not turn on:** Check if the power cord is securely plugged into a working outlet. Ensure the power switch is in the 'ON' position.
- **Reduced airflow or overheating:** The air filter may be clogged. Refer to the 'Maintenance' section for instructions on cleaning the air filter.
- **Hair feels dry or frizzy:** Ensure the HydraCare Sensor and Moisture Lock Conditioning Technology settings are activated. Adjust heat and speed settings to a lower level if necessary.
- **Attachments do not stay on:** Ensure the attachments are correctly aligned and pushed firmly onto the nozzle until they click into place.

If the problem persists after trying these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Number	EC9001
Brand	Remington
Power Source	Corded Electric
Wattage	1875 watts
Color	Pearl White/Gray
Material	Pearl
Product Dimensions	5.8 x 4 x 12.9 inches
Item Weight	3.79 Pounds
UPC	074590555981

8. WARRANTY AND SUPPORT

This Remington PROLUXE HydraCare Hair Dryer is covered by the manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Remington Customer Service. Contact information can typically be found on the Remington website or in your product documentation.