

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AudioRange](#) /

› [AudioRange ITE-1000 Wireless TV Headset User Manual](#)

AudioRange ITE-1000

AudioRange ITE-1000 Wireless TV Headset User Manual

Model: ITE-1000

INTRODUCTION

The AudioRange ITE-1000 Wireless TV Headset is designed to provide crystal clear audio from your television directly to your ears, without disturbing others. Ideal for seniors and individuals with mild to moderate hearing loss, this system offers personalized volume control and enhanced voice clarity. It features a lightweight, comfortable design and is universally compatible with most TVs and streaming services.



Figure 1: AudioRange ITE-1000 Wireless TV Headset on its charging dock.

WHAT'S IN THE BOX

Your AudioRange ITE-1000 Solo Bundle includes the following components:

- 1 Wireless TV Headset
- 1 Fast-Charging Headset Dock (with extra charging slot for a second headset)
- 3 Sets of Uniquely Shaped Earbuds (for maximum comfort)
- Digital Optical Audio Cable
- Analog Audio Cables (RCA and 3.5mm)
- Power Adapter
- Extra Battery
- Balance Adjustment Screwdriver

IMPORTANT! Check your TV for Compatibility

Your TV must have one of these connections available



Your TV's audio format must be changed to **"PCM"** or **"Stereo"** for headphone use. Not doing so will result in no sound or static noise.



Must be labeled "Audio Out" or "Audio Output". A sequence of yellow, white and red connections will not function.



Depending on your TV, this may disable audio from the TV Speakers for private listening.



WARNING: consult your doctor or physician if you have a pacemaker before purchasing.

Figure 2: The three different sets of eartips included for personalized comfort.

SETUP GUIDE

Follow these steps to set up your AudioRange ITE-1000 Wireless TV Headset:

1. **Charge the Headset:** Place the headset onto the fast-charging dock. Ensure the prongs on the headset align with the charging contacts on the dock. The headset will begin charging automatically.
2. **Connect to TV Power:** Plug the charging dock's power adapter into a wall outlet.
3. **Connect to TV Audio:** The AudioRange ITE-1000 is compatible with most TVs. Choose the appropriate audio cable based on your TV's available output ports:
 - **Digital Optical Audio Out (Recommended for best quality):** Use the included optical cable. Connect one end to your TV's "Digital Audio Out (Optical)" port and the other end to the "Optical" input on the charging dock. *Note: Your TV's audio format may need to be changed to "PCM" or "Stereo" for headphone use. Consult your TV manual if needed.*
 - **RCA L/R Audio Out:** Use the included RCA cables (red and white). Connect them to the "Audio Out" (red and white) ports on your TV and the corresponding "Audio In (Stereo)" ports on the charging dock. *Ensure these are "Audio Out" ports, not "Audio In".*
 - **3.5mm Headphone Jack:** Use the included 3.5mm audio cable. Connect one end to your TV's headphone jack and the other end to the "Audio In (Stereo)" port on the charging dock. *Note: This connection may disable audio from your TV speakers for private listening.*
4. **Power On:** Once connected, the system is ready to use. No complex pairing or passwords are required.

Unique Features for Mild-Moderate Hearing Loss



	50% lighter than bulky headphones
	Adjustable voice clarifying dial
	Hearing amplifier button allows you to hear your surroundings
	Long lasting 8 hour battery life
	Adjust the Left/Right sound independently

Figure 3: Important TV compatibility information and connection types.

Your browser does not support the video tag.

WARNING: Consult your doctor or physician if you have a pacemaker before purchasing or using this device.

OPERATING INSTRUCTIONS

The AudioRange ITE-1000 is designed for ease of use. Here's how to operate your headset:

- **Wearing the Headset:** Gently place the headset around your neck with the earbuds positioned comfortably in your ears.
- **Volume Control:** Use the "VOL" dial on the headset to adjust the overall volume to your preferred listening level. The headset offers up to 130dB max volume for those with mild to moderate hearing loss.
- **Tone Adjustment:** Use the "TONE" dial to customize the voice clarity. This helps in making dialogue clearer and more understandable.
- **Balance Adjustment:** For individuals with different hearing levels in each ear, use the included small screwdriver to adjust the "BAL" (balance) control. This allows you to manually adjust the sound balance between the left and right earbuds.
- **Microphone Feature:** Press the "MIC" button to activate the built-in microphone. This allows you to hear conversations and sounds in your surrounding room without removing the headset, making it easy to interact with others while watching TV.
- **Simultaneous Listening:** The system allows you to listen to the TV through the headset at your desired volume, while others can listen to the TV speakers at their own volume.

- ✓ Easy Setup
- ✓ Plug & Play (No pairing, No Passwords)
- ✓ Compatible with most TVs and cable/satellite boxes
- ✓ Works with Streaming Services Netflix, Hulu, Amazon, and more
- ✓ Easy to Charge Headsets



Figure 4: Enjoying TV at different volumes with the AudioRange headset.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AudioRange ITE-1000 headset:

- **Charging:** The headset features a long-lasting 8-hour battery life per charge. Recharging is fast and simple by placing it on the sleek charging dock. The dock has slots for two headsets if you have a dual system or an additional headset.
- **Battery Replacement:** An extra battery is included in the package. Refer to the headset's battery compartment for replacement instructions if needed.
- **Cleaning:** Regularly clean the earbuds and the headset with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Eartip Care:** The included eartips can be removed and cleaned with mild soap and water. Ensure they are completely dry before reattaching them to the headset.

TROUBLESHOOTING

If you encounter any issues with your AudioRange ITE-1000, consider the following common solutions:

- **No Sound or Static Noise:**
 - Ensure the headset is fully charged.
 - Verify all cables are securely connected to both the charging dock and the TV.
 - If using the optical connection, check your TV's audio settings to ensure the output format is set to "PCM" or "Stereo".
 - Confirm that the TV's volume is not muted or set too low.
- **Audio Delays or Lip-Sync Issues:**
 - The AudioRange RF headphones are designed to have no audio lag. If you experience delays, ensure no other wireless devices are causing interference.
 - Check that the headset is within the optimal operating range from the charging dock/transmitter.
- **Uncomfortable Fit:**
 - Experiment with the three different sets of uniquely shaped earbuds included in the package to find the most comfortable fit for your ears.

SPECIFICATIONS

Feature	Detail
Model Name	ITE-1000

Brand	AudioRange
Color	Black
Material	Plastic
Item Weight	1 pound
Package Dimensions	9.13 x 7.32 x 2.13 inches
Batteries	2 Lithium Ion batteries required (included)
Max Volume	130dB
Battery Life	Up to 8 hours per charge

WARRANTY AND SUPPORT

AudioRange provides U.S.-based Lifetime Customer Support with your purchase. For any questions, technical assistance, or warranty claims, please contact AudioRange customer service.




Figure 5: AudioRange offers dedicated U.S.-based customer support.

