

QFX BT-65

QFX BT-65 Portable Bluetooth Speaker User Manual

Model: BT-65

1. INTRODUCTION

Thank you for purchasing the QFX BT-65 Portable Bluetooth Speaker. This manual provides important information regarding the setup, operation, and maintenance of your new speaker. Please read it thoroughly before using the device to ensure proper functionality and to maximize your listening experience.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the device or injury to yourself:

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- This product is not waterproof. Avoid contact with water or other liquids.
- Do not disassemble, repair, or modify the unit yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only the specified charging cable and power source.
- Ensure proper ventilation around the speaker during use.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- QFX BT-65 Portable Bluetooth Speaker
- USB Charging Cable
- User Manual (this document)

4. CONTROLS AND FEATURES



The image displays the QFX BT-65 portable speaker. At the top, the control panel features various buttons and ports, including USB, MIC.IN, AUX.IN, and a volume knob. Below the control panel, the large 6.5-inch woofer is visible, illuminated with green LED party lights, protected by a hexagonal grille.

Control Panel Overview:

- **POWER OFF/ON/VOLUME Knob:** Rotates to turn the unit ON/OFF and adjust the master volume.
- **DC IN 5V:** Power input port for charging the speaker using the provided USB cable.
- **USB Port:** Insert a USB flash drive for MP3 playback.
- **MODE/LED ON:** Press to switch between input modes (Bluetooth, FM, USB, AUX). Press and hold to turn the LED party lights ON/OFF.
- **PREV/K44:** Press to go to the previous track (in Bluetooth/USB mode) or previous FM station.
- **PLAY/PAUSE/TWS:** Press to play or pause audio. Press and hold to activate True Wireless Stereo (TWS) pairing mode.
- **NEXT/>>:** Press to go to the next track (in Bluetooth/USB mode) or next FM station.
- **MIC.IN:** 6.35mm input for connecting a microphone.
- **AUX.IN:** 3.5mm auxiliary input for connecting external audio devices.
- **CHARGE LED:** Indicator light for charging status.
- **Display:** Shows current mode (e.g., "BLUE" for Bluetooth) and other information.

Other Features:

- **6.5" Woofer:** Provides powerful bass and clear audio.
- **LED Party Lights:** Dynamic lights integrated into the woofer for visual effects.
- **Handles:** Integrated handles for easy portability.

5. SETUP

5.1 Charging the Speaker

1. Connect the small end of the included USB charging cable to the DC IN 5V port on the speaker.
2. Connect the large end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The CHARGE LED indicator will illuminate during charging. It will turn off or change color once fully charged (behavior may vary by unit).
4. Allow sufficient time for a full charge before first use.

5.2 Powering On/Off

- To turn the speaker ON, rotate the POWER OFF/ON/VOLUME knob clockwise until it clicks and the display illuminates.
- To turn the speaker OFF, rotate the POWER OFF/ON/VOLUME knob counter-clockwise until it clicks and the display turns off.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth mode, indicated by "BLUE" on the display and an audible prompt.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices and select "QFX BT-65" from the list.
4. Once paired, you will hear a confirmation sound. You can now play audio from your device through the speaker.

5. Use the PREV/K44, PLAY/PAUSE/TWS, and NEXT/>> buttons on the speaker or your device to control playback.

6.2 True Wireless Stereo (TWS) Pairing

TWS allows you to connect two BT-65 speakers together for a stereo sound experience.

1. Ensure both BT-65 speakers are turned ON and in Bluetooth mode.
2. On one of the speakers (this will be the primary unit), press and hold the PLAY/PAUSE/TWS button for a few seconds until you hear a pairing sound.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 6.1.
5. Audio will now play in stereo through both speakers.

6.3 FM Radio Mode

1. Turn on the speaker and press the MODE button repeatedly until you enter FM Radio mode. The display will show the FM frequency.
2. Press the PLAY/PAUSE/TWS button once to auto-scan and save available FM stations. The speaker will scan and store stations automatically.
3. Use the PREV/K44 and NEXT/>> buttons to navigate between saved stations.

6.4 USB Playback

1. Insert a USB flash drive containing MP3 audio files into the USB port.
2. The speaker will automatically switch to USB mode and begin playing the first compatible audio file. If not, press the MODE button to select USB mode.
3. Use the PREV/K44, PLAY/PAUSE/TWS, and NEXT/>> buttons to control playback.

6.5 Auxiliary Input (AUX) Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX.IN port on the speaker.
2. Connect the other end of the audio cable to the headphone jack or audio output of your external device (e.g., MP3 player, computer).
3. Press the MODE button repeatedly until you enter AUX mode.
4. Control audio playback directly from your external device.

6.6 Microphone Usage

1. Connect a wired microphone (not included) to the MIC.IN port on the speaker.
2. Adjust the master VOLUME knob on the speaker to control the microphone's output level.
3. The microphone input can be used simultaneously with other audio sources (Bluetooth, USB, AUX).

6.7 LED Party Lights

- To turn the LED party lights ON or OFF, press and hold the MODE/LED ON button for a few seconds.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not

in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided USB cable.
No sound.	Volume is too low.	Increase the master volume using the knob. Check volume on connected device.
Bluetooth pairing fails.	Speaker is not in pairing mode or too far from device.	Ensure speaker is in Bluetooth mode. Move device closer. Forget "QFX BT-65" on your device and try pairing again.
FM radio reception is poor.	Weak signal.	Relocate the speaker to an area with better reception.
USB playback not working.	USB drive not formatted correctly or unsupported file type.	Ensure USB drive is formatted to FAT32 and contains MP3 files. Try a different USB drive.

9. SPECIFICATIONS

Feature	Specification
Model	BT-65
Brand	QFX
Connectivity Technology	Bluetooth
Speaker Type	Woofers
Speaker Size / Subwoofer Diameter	6.5 Inches
Special Feature	FM Radio, LED Party Lights, True Wireless Stereo (TWS)
Inputs	USB, Microphone (MIC.IN), Auxiliary (AUX.IN)
Power Source	Rechargeable Battery (Corded Electric for charging)
Included Components	USB Cable
Waterproof	No
UPC	606540040218

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official QFX website. Keep your purchase receipt as proof of purchase.

