

- Manuals.plus /
- › BOOMJOY /
- › BOOMJOY Twist Mop User Manual

BOOMJOY Twist Mop

BOOMJOY Twist Mop Instruction Manual

PRODUCT OVERVIEW

The BOOMJOY Twist Mop is designed for efficient floor cleaning with its self-wringing mechanism and highly absorbent microfiber head. It includes a soft scrubbing pad for stubborn stains and is suitable for various floor types, including tile, hardwood, laminate, and vinyl.

FAREWELL TO THE PAIN OF BENDING OVER



Image: The BOOMJOY Twist Mop being used on a wooden floor, demonstrating its ergonomic design that reduces the need for bending.

SETUP INSTRUCTIONS

Follow these steps to assemble your BOOMJOY Twist Mop. The mop handle consists of several parts that connect to form a complete unit.

1. Take out PART 1 (the mop head connector) and pass it through the center of the mop head (PART 5).
2. Connect PART 1 to the bottom part of the mop handle.
3. Connect PART 2 (middle handle section) to PART 1.
4. Connect PART 3 (upper handle section) to PART 2.
5. Connect PART 4 (top handle with hanging loop) to PART 3. Ensure all connections are secure.

Your browser does not support the video tag.

Video: A detailed guide on how to properly install and assemble the BOOMJOY Twist Mop components.

OPERATING INSTRUCTIONS

Self-Wringing Mechanism

The BOOMJOY Twist Mop features an easy-to-use self-wringing design to keep your hands dry and clean. To wring out the mop head:

1. **Lift Up:** Hold the handle and lift the mop head upwards.
2. **Twist to Dry:** Twist the handle to engage the wringing mechanism, effectively squeezing water from the microfiber head.
3. **Press Unlock Button:** Press the unlock button on the handle to release the mop head back into its flat position for cleaning.



Image: A visual guide demonstrating the three steps for operating the self-wringing function of the mop.

Cleaning Floors

The plump microfiber mop head offers strong water absorption for effective wet cleaning and can also be used dry for dusting. The integrated soft scrubbing pad helps remove stubborn stains without scratching your floors.

SELF-WRINGING DESIGN KEEP YOUR HANDS DRY AND CLEAN



Image: The mop head effectively wringing out dirty water, showcasing its self-wringing capability.

SELF-WRINGING TWIST MOP




Image: A close-up of the microfiber mop head, highlighting its texture and the integrated scrubbing pad for thorough cleaning.

Your browser does not support the video tag.

Video: Demonstrates the BOOMJOY Twist Mop in action, showing its self-wringing feature, strong water absorption, and ability to clean various floor types and reach tight spaces.

MAINTENANCE

Mop Head Replacement

To ensure optimal cleaning performance, replace the mop head when it becomes worn or excessively dirty. Your BOOMJOY Twist Mop comes with 2 extra reusable heads.

1. To remove an old mop head, carefully take out PART 5 (the mop head connector) from the center of the old mop head.
2. Take a new mop head and pass PART 5 through its center.
3. Locate the tie ring on the new mop head and tighten it around PART 5 to secure the mop head in place.
4. Cut off any excess part of the tie ring for a neat finish.

Refer to the installation video in the Setup Instructions section for a visual guide on replacing the mop head.

Cleaning the Mop Head

The microfiber mop heads are reusable and can be machine washed. For best results, wash with similar colors and air dry. Avoid using bleach or fabric softeners, as these can degrade the microfiber material.

Storage

The mop features a convenient hanging design for easy storage, helping to keep your cleaning area tidy and the mop head dry.



Image: The mop hanging on a wall hook, illustrating its space-saving storage feature.

TROUBLESHOOTING

- **Handle Bending or Snapping:** Avoid applying excessive downward force or using the mop for heavy scrubbing tasks beyond its intended design. The handle is designed for standard mopping and wringing.
- **Mop Head Difficult to Change:** Ensure you follow the mop head replacement instructions carefully, particularly regarding the tie ring and passing PART 5 through the new head.
- **Mop Head Not Cleaning Effectively After Washing:** Ensure mop heads are thoroughly rinsed and air-dried

after washing. Avoid using fabric softeners, which can reduce microfiber effectiveness.

SPECIFICATIONS

Feature	Detail
Brand	BOOMJOY
Model	Twist Mop
Product Dimensions	15.7"L x 15.7"W x 51.6"H
Head Material	Microfiber
Surface Recommendation	Floor, Tile
Color	Gray



Image: Visual representation of the mop's dimensions.

WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not provided in the available product data. Please refer to the retailer or manufacturer's official website for the most current warranty policy and customer support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B096RP6DY6>

More documents and user manuals: **<https://manuals.plus/>**