

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KRUPS](#) /

› [Krups Nespresso Inissia Cup Support Grid Instruction Manual](#)

KRUPS XN100 series, MS-623609, MS-624404

Krups Nespresso Inissia Cup Support Grid Instruction Manual

INTRODUCTION

This document provides essential instructions for the proper installation, operation, and maintenance of your new Krups Nespresso Inissia Cup Support Grid. Please read this manual thoroughly before using the product to ensure correct usage and longevity.

PRODUCT OVERVIEW

The Krups Nespresso Inissia Cup Support Grid is an original replacement part designed for specific Krups Nespresso Inissia capsule coffee machines. It serves as the platform for placing your coffee cups during the brewing process, ensuring stability and proper coffee dispensing.




Image of the Krups Nespresso Inissia Cup Support Grid, showing its design and material. This grid is typically silver or grey plastic.

COMPATIBILITY

This cup support grid is compatible with the following Krups Nespresso Inissia coffee machine models:

- XN1001
- XN1002
- XN1003
- XN1004
- XN1005
- XN1007
- XN100F
- XN100110 / FB0, JX0, LL0
- XN100140 / FB0, JX0, LL0

- XN1001CH / JX0, LLO
- XN100210 / FB0
- XN100240 / FB0
- XN100310 / FB0
- XN100340 / FB0
- XN100410 / FB0, JX0
- XN100440 / FB0, JX0
- XN100510 / FB0, JX0, LLO
- XN100540 / FB0, JX0
- XN1005CH / JX0, LLO
- XN100710 / FB0, JX0
- XN100740 / FB0
- XN100F10 / FB0
- XN100F40 / FB0
- Also compatible with models MS-623609 and MS-624404.

To verify your machine's model number, check the rating plate, usually located on the underside of the appliance.

SETUP AND INSTALLATION

The cup support grid is designed for easy installation. No tools are required.

1. **Ensure the coffee machine is unplugged** from the power outlet before handling any parts.
2. Locate the designated slot for the cup support grid on the front of your Nespresso Inissia machine.
3. Align the new cup support grid with the slot.
4. Gently slide the grid into place until it sits securely. It should click or fit snugly without excessive force.
5. Once installed, ensure it is stable and does not wobble.

OPERATING INSTRUCTIONS

The cup support grid is an integral part of your coffee machine's operation, providing a stable base for your cups.

- **Cup Placement:** Place your desired coffee cup directly onto the installed cup support grid.
- **Versatility:** The grid is designed to accommodate various cup sizes, including standard espresso cups and larger mugs. For taller cups, the grid can often be removed or adjusted on some Inissia models to allow more clearance. Refer to your specific coffee machine's manual for details on cup height adjustments.
- **Stability:** Always ensure the cup is centered and stable on the grid before starting the brewing cycle to prevent spills.

MAINTENANCE AND CLEANING

Regular cleaning of the cup support grid is essential for hygiene and to maintain the appearance of your coffee machine.

1. **Removal:** Gently pull the cup support grid upwards or outwards from its slot to remove it from the machine.

2. **Cleaning:** Wash the grid by hand using warm water and a mild dish soap. Use a soft sponge or cloth to clean any coffee residue.
3. **Rinsing:** Rinse thoroughly under running water to remove all soap residue.
4. **Drying:** Dry the grid completely with a soft, clean cloth before re-installing it. Do not use abrasive cleaners or scouring pads, as these can scratch the plastic surface.
5. **Re-installation:** Once dry, slide the grid back into its designated slot on the coffee machine.

TROUBLESHOOTING

If you encounter issues with your cup support grid, consider the following:

- **Grid does not fit:**
 - Double-check the compatibility list in this manual to ensure your coffee machine model is supported.
 - Ensure the grid is oriented correctly before attempting to insert it.
 - Verify that there are no obstructions in the slot where the grid is meant to be placed.
- **Grid is unstable:**
 - Remove and re-install the grid, ensuring it is fully seated in its slot.
 - Inspect the grid and the machine's slot for any damage or deformities.

If problems persist, contact Krups customer support or your retailer for further assistance.

SPECIFICATIONS

Brand	KRUPS
Model Numbers	MS-623609, MS-624404 (and XN100 series variants)
Material	Plastic
Color	Silver or Grey
Item Weight	Approximately 40 g
Special Feature	Can accommodate cups of different sizes, including espresso cups.

WARRANTY AND SUPPORT

This product is an original replacement part. For specific warranty information regarding this component, please refer to the warranty documentation provided with your original Krups Nespresso Inissia coffee machine or contact Krups customer service directly.

For technical support or further inquiries, please visit the official Krups website or contact your local authorized Krups service center. Keep your purchase receipt as proof of purchase.

Krups Official Website: www.krups.com

