REVLON RVDR5298N1

REVLON One Step Volumizer PLUS Hair Dryer and Styler Instruction Manual

Product Overview

The REVLON One Step Volumizer PLUS Hair Dryer and Styler is an innovative tool designed to deliver salon-quality results efficiently. It combines the power of a dryer with the volume of a styler, providing 75% shinier blowouts in half the time. Its advanced features ensure less damage and more styling control for easy, fast, salon-style blowouts.

Key Features:

- **75% Shinier Blowouts:** Achieve healthy-looking results with enhanced shine.
- **Elevated Brush Design:** A more versatile 2.4” oval brush head allows styling closer to the root for added volume and diverse styles including flips and soft waves.
- **Quicker Drying & Styling:** Dry and style your hair in up to half the time.
- **Heat Damage Protection:** Ceramic Titanium Tourmaline technology helps reduce heat exposure by 50% for silky-smooth, healthy-looking results.
- **Multiple Heat Settings:** Four heat/speed settings (Low, Medium, High, and Cool) to tailor to your hair needs.
- **Refreshes Second Day Hair:** Charcoal-infused nylon pins and tufted boar bristles improve detangling and static control.
- **Travel Friendly:** Detachable design for greater control and easier storage.



The REVLON One Step Volumizer PLUS Hair Dryer and Styler in Black Red, showcasing its oval brush head and sleek design.



A visual comparison highlighting the differences between the original Volumizer and the new Volumizer PLUS, including barrel size and heat settings.

Safety Information

For your safety, the Revlon One Step Hair Dryer and Volumizer meets U.S. safety requirements and features ETL Certification. This unit is designed for 120 Volt United States outlets only and should NOT be used in other countries. DO NOT use a voltage converter or adapter as it will damage the unit and may pose a safety risk.

Setup

Before first use, ensure the appliance is clean and free from any packaging materials. Uncoil the power cord completely. Familiarize yourself with the heat/speed settings located at the base of the handle. This appliance is ready for immediate use upon plugging into a compatible 120V US outlet.

Operating Instructions

For best results, towel-dry hair to remove excess water, then detangle with a comb. For faster results, hair should be at least 50% dry before styling. Always apply a heat protectant spray to your hair before using any heat styling tool.

Usage Steps:

1. Plug the appliance into a 120V US electrical outlet.
2. Select the desired heat/speed setting by rotating the dial at the bottom of the handle:
    - **COOL:** For setting styles.
    - **LOW:** For fine or thin hair.

- **MEDIUM:** For normal hair.
- **HIGH:** For thick or coarse hair.

3. Divide hair into manageable sections.
4. Place the brush close to the roots and roll it down towards the ends. The unique oval brush design allows for styling closer to the roots for added volume.
5. Repeat for all sections until hair is completely dry and styled to your preference.

The combination of drying and styling in one step significantly reduces styling time while providing a smooth, voluminous finish.

Maintenance and Care

To ensure optimal performance and longevity of your Revlon One Step Volumizer PLUS, follow these maintenance guidelines:

- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe down the handle and barrel. Do not use abrasive cleaners or solvents.
- **Bristle Care:** Regularly remove any tangled hair from the bristles. The charcoal-infused nylon pins and tufted boar bristles are designed for durability, but gentle handling will prolong their life.
- **Air Inlet Filter:** Periodically check the air inlet filter at the bottom of the handle for dust and lint buildup. Clean it gently with a small brush or vacuum cleaner attachment to maintain proper airflow.
- **Storage:** Store the appliance in a cool, dry place. The detachable head allows for easier storage and travel. Do not wrap the cord around the appliance, as this can damage the cord.

Troubleshooting

If you encounter any issues with your Revlon One Step Volumizer PLUS, refer to the following common troubleshooting tips:

- **Appliance Not Turning On:**
  - Ensure the power cord is securely plugged into a functional 120V US outlet.
  - Check the power outlet by plugging in another appliance.
  - Verify the heat/speed dial is set to a position other than "OFF".
- **Reduced Airflow or Overheating:**
  - The air inlet filter may be blocked. Unplug the appliance and clean the filter as described in the Maintenance section.
  - Ensure there is no hair or debris obstructing the air vents on the brush head.
- **Hair Tangling in Bristles:**
  - Ensure hair is thoroughly detangled before use.
  - Work with smaller sections of hair to prevent tangling.
  - Avoid wrapping hair too tightly around the barrel.
- **Unsatisfactory Styling Results:**
  - Ensure hair is adequately towel-dried (at least 50% dry) before styling.
  - Experiment with different heat/speed settings to find what works best for your hair type.
  - For more volume, lift hair at the roots and hold the brush for a few seconds before gliding down.

If problems persist, refer to the official user manual or contact Revlon customer support.

Specifications

Product Dimensions	4 x 1.6 x 6 inches; 1.63 Pounds
Item Model Number	RVDR5298N1
Brand	REVLON
Color	Black Red
Material	Titanium, Ceramic
Wattage	1100 watts
Power Source	Corded Electric
Manufacturer	Helen of Troy

Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual provided with your product. A digital version of the user manual can be accessed via this link: REVLON One Step Volumizer PLUS User Manual (PDF).
For further assistance, you may contact the manufacturer, Helen of Troy, directly through their official support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question