

UrbanX uxakg3.5mmwht

UrbanX Corded Stereo Earbuds Headphones User Manual

Model: uxakg3.5mmwht

INTRODUCTION

This manual provides essential information for the proper use, setup, and maintenance of your UrbanX Corded Stereo Earbuds Headphones. Designed for devices with a 3.5mm audio jack, these earbuds offer a reliable audio experience with an integrated microphone and volume controls. Please read this manual thoroughly before using your headphones.

PRODUCT OVERVIEW

The UrbanX Corded Stereo Earbuds Headphones feature an in-ear design for comfortable fit and clear audio. Key components include the earbuds, a durable braided cable, an inline control unit with microphone and volume buttons, and a 3.5mm audio jack connector.



Image: Overview of the UrbanX Corded Stereo Earbuds Headphones, showing the earbuds, braided cable, 3.5mm jack, inline controls, and included silicone ear tips.



Image: Detailed view of the UrbanX earbuds and the 3.5mm audio jack connector, highlighting the design.

The inline control unit allows for easy management of audio playback and calls without needing to access your connected device directly.

SETUP

- 1. Unpack:** Carefully remove the headphones and any included accessories from the packaging.
- 2. Select Ear Tips:** Choose the ear tips that provide the most comfortable and secure fit for your ears. The correct size helps ensure optimal sound quality and noise isolation.
- 3. Connect:** Insert the 3.5mm audio jack firmly into the headphone port of your compatible device (e.g., smartphone, tablet, laptop). The headphones are plug-and-play and do not require batteries or complex setup procedures.

OPERATING INSTRUCTIONS

Once connected, your UrbanX Earbuds are ready for use. The inline control unit provides convenient access to common functions:

- **Audio Playback:**

- Press the center button once to play or pause audio.
- Press the center button twice quickly to skip to the next track.
- Press the center button three times quickly to go back to the previous track.

- **Volume Control:**

- Press the '+' button to increase volume.
- Press the '-' button to decrease volume.

- **Call Management:**

- Press the center button once to answer an incoming call.
- Press the center button once during a call to end it.
- Press and hold the center button to reject an incoming call.

- **Microphone:** The integrated microphone allows for hands-free communication during calls. Ensure the microphone is positioned clearly for optimal voice pickup.

MAINTENANCE

To ensure the longevity and optimal performance of your UrbanX Earbuds, follow these maintenance guidelines:

- **Cleaning:**

- Gently wipe the earbuds and cable with a soft, dry, lint-free cloth.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse thoroughly and allow to dry completely before reattaching.
- Do not use harsh chemicals, abrasive cleaners, or immerse the headphones in water.

- **Storage:** Store your headphones in a clean, dry place when not in use. Avoid extreme temperatures.

- **Cable Care:** The braided cable is designed for durability and to resist tangling. Avoid sharp bends or excessive pulling on the cable, especially near the connectors, to prevent damage.

TROUBLESHOOTING

If you encounter issues with your UrbanX Earbuds, try the following solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No sound or low volume	<ul style="list-style-type: none"> Headphone jack not fully inserted. Device volume too low or muted. Incorrect audio output selected on device. Damaged cable or connector. 	<ul style="list-style-type: none"> Ensure the 3.5mm jack is fully inserted into the device's port. Increase the volume on your device. Check your device's audio settings to ensure output is directed to the headphones. Try the headphones with another device to rule out a device issue. If still no sound, the headphones may be damaged.
Microphone not working	<ul style="list-style-type: none"> Microphone port blocked or dirty. Device microphone settings. Incompatible device. 	<ul style="list-style-type: none"> Ensure the microphone area is clear of obstructions. Check your device's microphone input settings. Verify your device supports external microphones via the 3.5mm jack.
Poor audio quality (static, distorted)	<ul style="list-style-type: none"> Loose connection. Damaged cable. Interference. 	<ul style="list-style-type: none"> Re-insert the 3.5mm jack firmly. Inspect the cable for visible damage. Move away from other electronic devices that might cause interference.

SPECIFICATIONS

- Product Dimensions:** 2 x 1 x 1 inches
- Item Weight:** 1 ounces
- Item Model Number:** uxakg3.5mmwht
- Manufacturer:** URBANX
- Brand:** UrbanX
- UPC:** 705914730998
- Connector Type:** 3.5mm Jack
- Cable Type:** Braided
- Features:** Inline Microphone, Volume Buttons, Plug and Play

WARRANTY AND SUPPORT

UrbanX products come with a **90-day warranty**. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.

If you experience any issues with your UrbanX Corded Stereo Earbuds Headphones within the warranty period, please contact UrbanX customer support. Provide your purchase details and a description of the issue for assistance. Do not attempt to repair the product yourself, as this may void the warranty.

For further assistance or inquiries, please refer to the contact information provided with your purchase or visit the official UrbanX website.

Related Documents



[Digital Indoor TV Antenna User Guide](#)

This guide provides instructions for setting up and optimizing a digital indoor TV antenna for the best reception. It covers antenna placement, connection, and channel scanning, along with tips for improving signal quality.