

[Manuals.plus](#) /

› [SIMBASHOPPING](#) /

› SIMBASHOPPING Verona Whirlpool Bathtub Instruction Manual

SIMBASHOPPING Verona

SIMBASHOPPING Verona Whirlpool Bathtub Instruction Manual

This manual provides essential information for the safe installation, operation, and maintenance of your SIMBASHOPPING Verona 2-person whirlpool bathtub. Please read thoroughly before use.

1. PRODUCT OVERVIEW

The SIMBASHOPPING Verona is a 2-person whirlpool bathtub designed for comfort and relaxation. It features a hydromassage system, integrated heater, chromotherapy lighting, and a radio. The tub is constructed from glossy white acrylic with chrome finishes and supported by an aluminum structure with adjustable feet.



2. INSTALLATION AND SETUP

2.1 Pre-Installation Checklist

- Verify all components are present and undamaged upon delivery.
- Ensure the installation area meets the required dimensions (70.8"L x 47.2"W x 25.6"H) and can support the combined weight of the tub (220 lbs empty) and water (approximately 40 gallons).
- Confirm that a dedicated 110V – 15A electrical supply and appropriate plumbing connections (hot/cold water, drain) are available and comply with local building codes.

2.2 Plumbing Connections

- Connect the flexible hoses to the hot and cold water supply lines.
- Connect the drain pipe to the existing drainage system.
- The bathtub is designed to be adaptable to pre-existing plumbing systems.

2.3 Electrical Connection

- Connect the 110V plug to a dedicated, grounded 15A electrical outlet.
- Ensure the breather pipe is left free and not connected to any other hose or pipe.

2.4 Leveling

The bathtub features an aluminum structure with adjustable feet. Adjust these feet as necessary to ensure the tub is perfectly level on the floor surface, preventing instability and drainage issues.




Image 2: This diagram shows the location of key components such as the heater, water pump, air pump, breather, drainpipe, 110V plug, flexible pipes for water connection, steel frame, and loudspeaker. Below the component layout, the overall dimensions of the bathtub are provided: Length 70.8 inches, Width 47.2 inches, Height 25.6 inches.

3. OPERATION

3.1 Control Panel

The control panel, located on the rim of the bathtub, allows you to manage all functions. Familiarize yourself with its buttons and indicators before use.



Image 3: A close-up view of the control panel, various hydromassage jets, and the two black headrests, demonstrating the user interface and comfort features.

3.2 Hydromassage System

- Activate the 1.5 HP water pump to engage the 6 large and 6 small water jets.
- Activate the 0.25 HP air pump to engage the 16 small air jets.
- Use the hydromassage adjustment valve to control the intensity of the water jets.

3.3 Heater Function

The integrated heater maintains the water at your desired temperature. Set the temperature using the control panel. Ensure the water level is sufficient for the heater to operate safely.

3.4 Chromotherapy

Activate the 7-color LED chromotherapy feature via the control panel for an enhanced bathing experience.

3.5 Radio

Tune into your preferred radio stations using the control panel. The bathtub includes two integrated speakers.

3.6 Faucets and Hand Shower

Operate the integrated chrome finish faucets to fill the tub. Utilize the hand shower for targeted rinsing.



Image 4: This image displays the elegant chrome finish faucets, the American-style waterfall spout, and the detachable hand shower, all integrated into the bathtub's design.

4. MAINTENANCE

4.1 Cleaning the Bathtub

- Regularly clean the acrylic surface with a soft cloth and a non-abrasive, mild bathroom cleaner.
- Avoid harsh chemicals, abrasive pads, or solvents that can damage the finish.

- For stubborn stains, consult the cleaner's instructions for acrylic surfaces.

4.2 Jet and Pipe Cleaning

- Periodically run the hydromassage system with a specialized whirlpool cleaner or a solution of white vinegar and water to prevent mineral buildup and bacterial growth in the jets and internal piping.
- Follow the cleaner's instructions for proper dilution and cycle time.

4.3 Drain Maintenance

- Ensure the drain is clear of hair and debris to maintain proper drainage. Regularly remove and clean the drain cover.

4.4 Component Inspection

- Periodically inspect all visible components, including hoses, pipes, and electrical connections, for any signs of wear, damage, or leaks.
- If any issues are found, discontinue use and contact customer support.

5. TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, please contact customer support.

5.1 No Power

- Check the electrical connection and ensure the 110V plug is securely inserted into a functional 15A outlet.
- Verify that the circuit breaker for the outlet has not tripped.

5.2 Hydromassage Jets Not Working

- Ensure the water level in the tub is above the jets.
- Check if both the water pump and air pump are activated via the control panel.
- Verify that the hydromassage adjustment valve is open.

5.3 Heater Not Maintaining Temperature

- Confirm the heater function is activated and the desired temperature is set on the control panel.
- Ensure the water level is adequate for the heater to operate.

5.4 Leaks

- Immediately turn off the power and drain the tub.
- Inspect all plumbing connections for tightness. If a leak persists, contact customer support.

5.5 Unusual Noises

- If the pumps or jets produce unusual noises, ensure there are no obstructions.
- If the noise continues after checking for obstructions, contact customer support.

6. TECHNICAL SPECIFICATIONS

Attribute	Specification
Brand	SIMBASHOPPING
Model	Verona
Material	Acrylic
Color	White
Product Dimensions (L x W x H)	70.8" x 47.2" x 25.6"
Weight (Empty)	220 lbs
Capacity	40 Gallons
Power Requirement	110V – 15A
Water Pump	1.5 HP (6 large + 6 small jets)
Air Pump	0.25 HP (16 small air jets)
Heater	Integrated
Key Features	Control panel, Faucets, American-style waterfall, Hand shower, 2 Headrests, Hydromassage adjustment valve, 2 Speakers, 1 LED Chromotherapy
Installation Type	Alcove
Shape	Semi-Circular
UPC	762179103325
ASIN	B096WCCF57

7. WARRANTY INFORMATION

For detailed warranty information regarding your SIMBASHOPPING Verona whirlpool bathtub, please refer to the documentation provided with your purchase. Warranty terms typically cover manufacturing defects for a specified period. Keep your proof of purchase for any warranty claims.

8. CUSTOMER SUPPORT

If you require assistance with installation, operation, maintenance, or troubleshooting, please contact SIMBASHOPPING USA customer support.

Manufacturer: SIMBASHOPPING USA

For the most current contact information, including phone numbers or email addresses, please visit the official SIMBASHOPPING website or refer to your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B096WCCF57>

More documents and user manuals: <https://manuals.plus/>