

Edifier M201BT

Edifier M201BT Multimedia Computer Speaker System User Manual

Model: M201BT | Brand: Edifier

INTRODUCTION

Thank you for purchasing the Edifier M201BT Multimedia Computer Speaker System. This manual provides essential information for the proper setup, operation, and maintenance of your new speaker system. Please read it thoroughly before use and retain it for future reference.

The Edifier M201BT system delivers powerful audio with a dedicated subwoofer, offering versatile connectivity options including Bluetooth 5.0 and Aux input, suitable for various audio sources.

PACKAGE CONTENTS

- 1 x Subwoofer
- 2 x Satellite Speakers
- 1 x Wired Remote Control
- 1 x 3.5mm Audio Cable
- 1 x Power Cable
- 1 x User Manual (this document)

PRODUCT OVERVIEW



Figure 1: Edifier M201BT Multimedia Computer Speaker System. This image displays the complete 2.1 speaker system, including the central subwoofer unit and two compact satellite speakers, all in a black finish.



Figure 2: Subwoofer Rear Panel. This close-up view of the subwoofer's rear panel highlights the various input ports, including AUX, and control knobs for volume and bass adjustment, along with the power switch.



Figure 3: Satellite Speakers. A pair of compact satellite speakers are shown, designed to complement the subwoofer and provide clear mid-range and high-frequency audio.

Key Components:

- **Subwoofer:** Houses the 5-inch woofer for strong bass output and the main control panel.
- **Satellite Speakers:** Two compact speakers for stereo sound.
- **Wired Remote Control:** Allows convenient adjustment of volume and bass.

SETUP INSTRUCTIONS

1. Placement

- Place the subwoofer on the floor or a sturdy surface, ensuring adequate ventilation.
- Position the satellite speakers on either side of your listening area, facing towards you for optimal stereo imaging.

2. Connections

1. **Connect Satellite Speakers:** Plug the cables from the satellite speakers into the 'Satellite Speaker Out' ports on the rear of the subwoofer. Ensure correct polarity (red to red, black to black).

- 2. **Connect Wired Remote Control:** Plug the wired remote control into its dedicated port on the subwoofer.
- 3. **Power Connection:** Connect the power cable to the subwoofer and then to a power outlet.
- 4. **Audio Source Connection:** Choose one of the following methods:
 - **Auxiliary Input:** Use the provided 3.5mm audio cable to connect your audio source (PC, tablet, smartphone, TV) to the 'AUX' input on the subwoofer's rear panel.
 - **Bluetooth Connection:**
 - a. Turn on the speaker system.
 - b. Press the input selection button on the wired remote control until the Bluetooth indicator (blue LED) is lit.
 - c. On your audio device, search for Bluetooth devices and select 'EDIFIER M201BT' to pair.
 - d. Once paired, the Bluetooth indicator will remain solid blue.

OPERATING INSTRUCTIONS

1. Power On/Off

- Flip the power switch on the rear of the subwoofer to the 'ON' position to power on the system.
- Flip the power switch to 'OFF' to power off the system.

2. Volume and Bass Control

- **Volume:** Use the main knob on the wired remote control or the 'Volume/Input' knob on the subwoofer's rear panel to adjust the overall volume.
- **Bass:** Use the 'Bass' knob on the subwoofer's rear panel to adjust the bass level to your preference.

3. Input Selection

- Press the input selection button on the wired remote control to cycle between Aux input (green LED) and Bluetooth input (blue LED).

MAINTENANCE

- Regularly clean the speaker surfaces with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Keep the speakers away from direct sunlight, heat sources, and moisture.
- Ensure proper ventilation around the subwoofer to prevent overheating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	Power not connected/on; Incorrect input selected; Volume too low; Cables loose.	Ensure power is on; Select correct input (green for Aux, blue for Bluetooth); Increase volume; Check all cable connections.

Problem	Possible Cause	Solution
Bluetooth not connecting	Speakers not in Bluetooth mode; Device not discoverable; Interference.	Switch speakers to Bluetooth mode (blue LED); Ensure device's Bluetooth is on and discoverable; Move closer to speakers; Disconnect other Bluetooth devices.
Distorted audio	Volume too high; Audio source issue; Loose connections.	Lower volume on speakers and/or audio source; Test with a different audio source; Check all cable connections.

SPECIFICATIONS

Feature	Detail
Model Number	M201BT
Brand	Edifier
Speaker Type	2.1 Channel Speaker System (Bookshelf)
Total Peak Power	68 Watts
Subwoofer Driver	5-inch Woofer
Connectivity	Bluetooth 5.0, Auxiliary (3.5mm)
Control Method	Wired Remote Control, Knobs on Subwoofer
Enclosure Material	Wood
Product Dimensions	13.27 x 9.72 x 11.61 inches
Item Weight	7.7 pounds

SAFETY INFORMATION








- Do not expose the product to rain or moisture.
- Do not open the speaker enclosure. Refer servicing to qualified personnel.
- Avoid placing the product near heat sources or in direct sunlight.
- Ensure proper ventilation to prevent overheating.

WARRANTY AND SUPPORT

The Edifier M201BT Multimedia Computer Speaker System comes with a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or visit the official Edifier website.

For technical support, troubleshooting assistance, or any inquiries regarding your product, please contact Edifier customer service through their official channels. Contact information can typically be found on the Edifier website or in the product packaging.

Related Documents - M201BT

	<p>Edifier R19BT Multimedia Speaker User Manual</p> <p>User manual for the Edifier R19BT multimedia speaker. Learn how to connect via USB, AUX, and Bluetooth, understand functional operations, and find troubleshooting tips for your Edifier R19BT speakers.</p>
	<p>EDIFIER R1700BT Multimedia Speakers User Manual</p> <p>User manual for the EDIFIER R1700BT multimedia speakers, covering setup, operation, safety instructions, specifications, and troubleshooting. Includes details on connectivity, Bluetooth pairing, and product features.</p>
    	

Note:
To switch the speaker to standby mode or work mode, tap and hold the "Q" button on the speaker.

5. Source selection

USB IN :

AUX IN :

6. Bluetooth connection

Note:
- The mode for connection is "BTSPK" if needed.
- To enjoy all Bluetooth functions of this product, make sure that your audio device supports A2DP and AVRCP profiles.
- If the device is not connected to the speaker, the speaker will enter the Bluetooth standby mode. The "Q" button highlight will turn a breathing pattern in this mode. If you always connect the speaker to a device that exists in the pairing record of this speaker, you can select "BTSPK" from the Bluetooth menu to connect. To add new Bluetooth devices, use the "Q" button on the speaker.
- To disconnect from the current Bluetooth device, tap and hold the "Q" and "Q" buttons on the speaker for 10 seconds.

7. USB connection

Note:
The following operating systems support USB audio streaming: Windows 11, Windows 10, Windows 8, and Windows 7.

8. Play control

Note:
In both USB modes, volume keys is not supported. To adjust the volume, adjust on the speaker and your device separately.

9. Specifications

Total output power (RMS): L/R Channels: 15W+15W
L/R Peak range and burst: 10W+10W
Frequency response: 80Hz-16kHz
Impedance (at 1kHz): 4Ω
Impedance (at 1kHz): 4Ω
Power Output: < 10 dBm (SPL)
There is no restriction of use.

10. Troubleshooting

Cannot connect to your Bluetooth device

Make sure that the distance between this product and your Bluetooth device is less than 10 meters and there are no obstacles between them.

Make sure that the device is connected to the product for the first time.

Make sure that the product is in Bluetooth pairing mode. If not, manually switch it to this mode.

Restart this product, enable Bluetooth function on your Bluetooth device, and then try again.

No power

Make sure that the power cable is properly connected.

Make sure that the power supply is not disconnected.

No signal

Make sure that this product is powered on.

Make sure that the product and your device is properly connected.

Make sure that the playback is not paused.

Make sure that the product and your device are not muted.

Increase the volume of this product and your device.

Noise coming from speakers

EDIFIER speakers generate little noise, while the background noise of some audio devices are too high. Please unplug audio cables and turn the volume up. The sound can be heard at 1 meter away from the speaker. There is no problem with this product.

To learn more about EDIFIER, please visit www.edifier.com.
For EDIFIER warranty queries, please visit the relevant country page on www.edifier.com and review the website (Edifier Warranty Terms, USA and Canada: www.edifierusa.com, South America: www.edifier.com (English) or www.edifier.com (Spanish/Portuguese) for local contact information.

[EDIFIER M60 Multimedia Speaker User Manual](#)

Comprehensive user manual for the EDIFIER M60 multimedia speaker, covering setup, connections, features, troubleshooting, and specifications. Learn how to use the EDIFIER ConneX app for enhanced control.



[Edifier M601DB Multimedia Speaker User Manual](#)

User manual for the Edifier M601DB multimedia speaker system, providing safety instructions, box contents, illustrations, connection guides, audio input details, specifications, and troubleshooting tips.

EDIFIER®

M601DB
1.6ch 20W Speaker

Get more information about EDIFIER products, visit www.edifier.com.
For EDIFIER warranty queries, please visit the relevant country page on www.edifier.com and review the website (Edifier Warranty Terms, USA and Canada: www.edifierusa.com, South America: www.edifier.com (English) or www.edifier.com (Spanish/Portuguese) for local contact information.

 The image shows the front cover of the Edifier e25 Luna Eclipse Multimedia Speaker User Manual. The cover is dark, possibly black or dark grey, with the Edifier logo at the top. Below the logo, the text 'Luna Eclipse' is visible, followed by 'e25' and 'Multimedia Speaker'.	<p>Edifier e25 Luna Eclipse Multimedia Speaker User Manual</p> <p>User manual for the Edifier e25 Luna Eclipse multimedia speaker, covering setup, connectivity, operation, troubleshooting, and specifications. Learn how to connect, use Bluetooth, and resolve common issues.</p>
 The image shows the front cover of the Edifier R980T Multimedia Speaker User Manual. The cover is white with a grid of small images showing different views and features of the speaker system.	<p>Edifier R980T Multimedia Speaker User Manual</p> <p>Comprehensive user manual for the Edifier R980T multimedia speaker system, covering setup, specifications, safety instructions, and troubleshooting. Includes details on connections, audio settings, and product care.</p>