

[Manuals.plus](#) /

› [RELAX4LIFE](#) /

› RELAX4LIFE 3-Seater Garden Swing Instruction Manual

RELAX4LIFE 3-Seater Garden Swing

RELAX4LIFE 3-Seater Garden Swing Instruction Manual

Model: 3-Seater Garden Swing

1. INTRODUCTION

Thank you for choosing the RELAX4LIFE 3-Seater Garden Swing. This manual provides essential information for the safe assembly, operation, and maintenance of your new garden swing. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: The RELAX4LIFE 3-Seater Garden Swing, featuring a black frame and canopy, designed for outdoor relaxation.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- **Assembly:** Ensure all components are correctly assembled and tightened according to the instructions. Do not use the swing if any parts are missing or damaged.
- **Placement:** Place the swing on a flat, stable, and level surface. Ensure there is adequate clear space around the swing to prevent collisions.
- **Weight Capacity:** The maximum weight capacity for this 3-seater swing is 250 kg. Do not exceed this limit.
- **Children:** Children should be supervised by an adult when using the swing. Do not allow children to play unsupervised around the swing.
- **Weather Conditions:** In strong winds or severe weather, remove the canopy and secure the swing to prevent damage or tipping.
- **Inspection:** Regularly inspect the swing for loose bolts, worn parts, or structural damage. Tighten all fasteners periodically.
- **Usage:** Do not stand on the swing or use it for purposes other than its intended use as a garden

swing.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- 1 x 3-Seater Garden Swing Frame (Steel)
- 1 x Canopy (Waterproof Polyester)
- 1 x Seat (Textilene Fabric)
- Assembly Hardware (bolts, nuts, washers)
- Small Assembly Tools
- 1 x Instruction Manual



Image 3.1: Visual representation of the garden swing components and technical specifications.

4. SETUP AND ASSEMBLY

Assembly of the RELAX4LIFE Garden Swing is designed to be straightforward. Follow the detailed instructions provided in the separate assembly guide included in your package. Ensure you have sufficient space and a second person to assist with assembly for safety and ease.

1. Unpack all components and verify against the package contents list.
2. Assemble the main frame structure using the provided hardware. Ensure all bolts are securely tightened.
3. Attach the seat to the frame using the suspension hooks.
4. Install the canopy frame and then attach the waterproof polyester canopy.
5. Perform a final check to ensure all connections are secure and the swing is stable before use.



Image 4.1: Close-up of structural elements, highlighting the robust steel frame, spring hooks, and anti-slip foot caps for stability.

5. OPERATING INSTRUCTIONS

The RELAX4LIFE Garden Swing is designed for comfortable outdoor seating and gentle swinging motion.

- **Seating:** The swing is designed to comfortably seat up to three individuals. Ensure weight is distributed evenly.
- **Swinging Motion:** Initiate a gentle swinging motion by pushing off the ground with your feet. Avoid excessive force or aggressive swinging.
- **Canopy Adjustment:** The canopy can be adjusted to provide optimal shade. Loosen the adjustment knobs on the side, position the canopy, and then tighten the knobs to secure it.

Idéal pour diverses occasions



Image 5.1: Visual representation of the swing's features, including the adjustable canopy for sun protection and breathable seat material.

6. MAINTENANCE

Regular maintenance will extend the life and appearance of your garden swing.

- **Cleaning Frame:** Wipe the steel frame with a damp cloth and mild soap. Rinse thoroughly and dry to prevent rust.
- **Cleaning Fabric:** The Textilene seat and polyester canopy can be cleaned with a soft brush, mild soap, and water. Allow to air dry completely. Do not use harsh chemicals or abrasive cleaners.
- **Seasonal Storage:** During winter months or prolonged periods of non-use, it is recommended to store the swing indoors or cover it with a protective outdoor furniture cover to prevent weather damage.
- **Fasteners:** Periodically check all bolts, nuts, and screws to ensure they are tight. Re-tighten as necessary.

Tissu polyester hydrofuge



**Siège de conception ergonomique et respirant.
Le tissu offre un confort d'assise.**

Image 6.1: Detail of the waterproof polyester canopy fabric, illustrating its resistance to moisture.

7. TROUBLESHOOTING

If you encounter any issues with your garden swing, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Swing feels unstable or wobbly.	Uneven ground; loose fasteners.	Move the swing to a level surface. Check and tighten all assembly bolts.
Canopy does not stay in position.	Adjustment knobs are not tightened sufficiently.	Ensure the canopy adjustment knobs on both sides are securely tightened after positioning.
Squeaking noise during swinging.	Friction in suspension points or joints.	Apply a small amount of silicone-based lubricant to the spring hooks and pivot points.

8. SPECIFICATIONS

Key technical specifications for the RELAX4LIFE 3-Seater Garden Swing:

- **Dimensions (L x W x H):** 170 x 120 x 153 cm (approximate, based on product images and specifications)
- **Product Dimensions (P x L x H):** 120P x 153l x 170H centimeters
- **Weight:** 22 Kilograms
- **Material:** Powder-coated Steel Frame, Textilene Seat, Waterproof Polyester Canopy
- **Color:** Black
- **Seating Capacity:** 3 persons
- **Maximum Weight Capacity:** 250 KG
- **Assembly Required:** Yes
- **Country of Origin:** China



Image 8.1: Dimensional overview of the garden swing, including its overall size and seating area, along with the stated weight capacity.

9. WARRANTY AND SUPPORT

RELAX4LIFE is committed to providing quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any questions, concerns, or assistance with your product, please contact RELAX4LIFE customer support through the retailer where the product was purchased or visit the official RELAX4LIFE website for contact information.

Please refer to the contact information provided with your purchase documentation for the most direct support.