

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Men's Quartz Watch User Manual

OLEVS SC-S-G9931GJ-JH

OLEVS Men's Quartz Watch Instruction Manual

Brand: OLEVS | Model: SC-S-G9931GJ-JH

1. INTRODUCTION

Thank you for choosing the OLEVS Men's Quartz Watch. This timepiece combines classic design with modern functionality, featuring a precise quartz movement, durable stainless steel construction, and practical features for daily wear. Please read this manual carefully to understand the proper use and care of your watch.



Figure 1: OLEVS Men's Quartz Watch (Model 9931-Gold black)

Key features of your OLEVS watch include:

- **Fashion Classic Design:** Rhombus three-dimensional dial with subdials, simple analog display, and elegant design suitable for various occasions.
- **Precision Quartz Movement:** Ensures accurate timekeeping.
- **30M Water Resistance:** Withstands daily splashes or short immersion in water. Not suitable for bathing, swimming, diving, or hot water contact.
- **Luminous Function:** Hands and markers glow in the dark after exposure to strong light, providing visibility at night.
- **Durable Construction:** Features a high hardness coated glass mirror and a stainless steel strap.

2. SETUP

2.1 Adjusting the Watch Band

Your OLEVS watch comes with a stainless steel band that can be adjusted to fit your wrist. A band adjustment tool is typically included. Follow these steps to remove or add links:

1. Locate the small circular holes on the side of the watch band links. These indicate the removable pins.
2. Place the band in the active slot of the strap removal tool.
3. Gently push the slot into the appropriate position, aligning the tool's pin with the watch band pin.
4. Rotate the top pin of the handle on the removal tool to align with the rivet on the steel strip.
5. Simply rotate the handle manually to push out the rivet. Remove the desired number of links from each side of the clasp for a balanced fit.
6. To reassemble, insert the pins back into the links in the opposite direction, ensuring they are fully seated.




Figure 2: Watch Band Adjustment Steps

3. OPERATING INSTRUCTIONS

3.1 Setting Time and Date

To set the time and date on your OLEVS watch:

1. Pull the crown (the knob on the side of the watch) out to the first click position to adjust the date. Turn the crown clockwise or counter-clockwise until the correct date is displayed.
2. Pull the crown out to the second click position to adjust the time. Turn the crown to move the hour and minute hands until the correct time is set.
3. Once the time and date are set, push the crown back in to its original position to start the watch movement.

3.2 Luminous Function

The hands and markers of your OLEVS watch are coated with a luminous material. To activate the glow-in-the-dark feature, expose the watch to a strong light source (e.g., sunlight, bright lamp) for 30-40 seconds. The watch will then emit a glow in low-light conditions, providing easy readability.




Figure 3: Luminous Function in Low Light

Video: Demonstration of the OLEVS watch features, including its design and wearability.

4. MAINTENANCE

4.1 Water Resistance

Your OLEVS watch is rated for 30 meters (3 ATM) of water resistance. This means it is suitable for daily splashes, rain, or short immersion in water. However, it is **not** designed for:

- Bathing or showering (especially with hot water, as steam can penetrate seals).
- Swimming or diving.
- Operating the crown or pushers while the watch is wet or submerged.

Always ensure the crown is fully pushed in before any contact with water. If water condensation appears inside the watch, have it inspected by a professional immediately to prevent damage.



Figure 4: Water Resistance and Other Features

4.2 Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

5. TROUBLESHOOTING

If you encounter any issues with your OLEVS watch, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Watch not running	Battery depleted; Crown not pushed in.	Replace battery (professional service recommended); Push crown fully into position.
Time/Date not changing	Crown not pulled out to correct position.	Ensure crown is pulled out to the first (date) or second (time) click position.
Luminous function not working	Insufficient light exposure.	Expose the watch to strong light for 30-40 seconds to charge the luminous material.
Water condensation inside watch	Water ingress due to seal compromise or improper use.	Seek professional repair immediately to prevent further damage. Avoid further water exposure.

6. SPECIFICATIONS

Detailed specifications for your OLEVS Men's Quartz Watch:

Feature	Detail
Brand Model Number	SC-S-G9931GJ-JH
Mirror Material	High hardness coated glass mirror
Movement Type	Original Quartz Movement
Water Resistance	30 Meters (3 ATM)
Clasp Type	Push Button Hidden Clasp
Case Diameter	41 mm
Case Thickness	11 mm
Chain Width	20 mm
Chain Length	19 cm
Watch Weight	114g
Department	Mens
Item Type Name	Dress Watch

Note: All sizes are manually measured; there may be a reasonable error. Please refer to the actual product.





Product Size

41

Case diameter
(MM)

11

Case thickness
(MM)

20

Chain width
(MM)

19

chain length
(CM)

Brand model number :	OLEVS/9931
Mirror :	High hardness coated glass mirror
Movement :	Original Quartz Movement
Waterproof :	30 Meters
Watch weight :	114g

Tips: All sizes are manually measured, there is a reasonable error, please prevail in kind

Figure 5: Product Parameters

7. WARRANTY AND SUPPORT

For any questions or support regarding your OLEVS watch, please contact the seller or refer to the product listing for warranty information. OLEVS is committed to providing quality products and customer satisfaction. You can visit the official OLEVS store for more information and product offerings:[OLEVS Store on Amazon](#)