Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Majorette 212059987

Majorette Motor Lift Center Garage Playset Instruction Manual

Model: 212059987

Introduction

Thank you for choosing the Majorette Motor Lift Center Garage Playset. This multi-level car park is designed for interactive play with die-cast cars, featuring a motorized lift, a 360° crane, a car wash, and repair stations. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your playset.

Safety Information

- **Recommended Age:** Suitable for children aged 5 years and older.
- **Adult Supervision:** Adult supervision is recommended during assembly and play.
- **Battery Safety:** Use only the specified battery type (3 x AAA). Ensure correct polarity. Do not mix old and new batteries or different types of batteries. Remove batteries if the toy is not used for an extended period.
- **Small Parts:** This playset contains small parts which may pose a choking hazard for young children. Keep away from children under 3 years.

Package Contents

Please ensure all components are present before beginning assembly:

- 1 x Motor Lift Center Garage Playset (main structure, ramps, accessories)
- 5 x Die-Cast Cars (1:64 scale, 7.5 cm length each)
- Assembly Instructions (included in packaging)



Image: The five included die-cast cars, each approximately 7.5 cm long.

Setup and Assembly

Assembly time is approximately 15 minutes. Follow the detailed instructions provided in the product packaging. A Phillips head screwdriver (not included) will be required for battery installation.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify all components listed in the "Package Contents" section are present.
2. **Assemble Base:** Connect the base sections of the garage as per the diagrams in the included manual.
3. **Construct Levels:** Attach the vertical support pillars and connect the five parking levels in sequence. Ensure each level is securely fastened.
4. **Install Ramps:** Attach the curving ramps to connect the different levels of the garage.
5. **Attach Features:** Secure the 360° crane, car wash, repair stations, and gas stations to their designated positions on the playset.
6. **Battery Installation (Motorized Lift):** Locate the battery compartment for the motorized lift. Using a Phillips head screwdriver, open the compartment. Insert 3 x AAA batteries, ensuring correct polarity (+/-). Close the compartment securely.
7. **Apply Stickers:** Apply any decorative stickers as indicated in the assembly guide for enhanced detail.



Image: The assembled Majorette Motor Lift Center Garage as depicted on the product packaging.

Operating Instructions

Once assembled, the Majorette Motor Lift Center Garage offers various interactive play features:

- **Motorized Lift:** Place a die-cast car onto the lift platform. Press the activation button to transport the car between different levels of the garage. The lift moves cars up and down automatically.
- **360° Crane:** Manually rotate the crane arm 360 degrees. Use the attached wrecking ball for imaginative demolition scenarios or to lift small items.
- **Car Wash:** Drive a car into the car wash station. The rotating brushes (manual operation) simulate cleaning the vehicle.
- **Repair Stations:** Position cars on the repair platforms for pretend maintenance and tune-ups.
- **Gas Stations:** Pull up to the gas pumps to refuel your die-cast vehicles for their next adventure.
- **Ramps:** Utilize the curving ramps to race cars between the five levels of the garage.



Image: Detailed views of the crane, motorized lift, repair station, and car wash features.



Image: A child demonstrating interaction with the playset's features.

Maintenance

- **Cleaning:** Wipe the playset with a soft, damp cloth. Do not immerse in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight when not in use.
- **Battery Replacement:** Replace batteries in the motorized lift when its operation becomes weak or inconsistent. Refer to the "Battery Installation" step in the Setup section.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Motorized lift is not working or is weak.	Batteries are depleted. Batteries are inserted incorrectly. Lift mechanism is obstructed. Lift components are not assembled correctly.	Replace with new AAA batteries. Check battery polarity and reinsert correctly. Ensure no foreign objects are blocking the lift path. Review assembly instructions for the motorized lift section to ensure all parts are correctly connected and aligned.
Cars do not move smoothly on ramps.	Ramps are not securely connected. Debris on ramps.	Check all ramp connections and ensure they are firmly in place. Clean ramps to remove any dust or small particles.
Playset feels unstable.	Components are not fully clicked into place.	Review all assembly steps, ensuring all connections are secure and tight.

Specifications

- **Model Number:** 212059987
- **Brand:** Majorette
- **Dimensions (Assembled):** 53 cm (Width) x 56 cm (Depth) x 75 cm (Height)
- **Weight:** Approximately 2.44 kg
- **Material:** Plastic
- **Power Source:** 3 x AAA batteries (not included) for motorized lift
- **Recommended Age:** 5 - 9 years
- **Car Scale:** 1:64
- **Assembly Time:** Approximately 15 minutes




Image: The assembled playset with indicated dimensions.

Warranty Information

This product is sold without a manufacturer's warranty. Please refer to the retailer's return policy for any issues or defects upon purchase.

Support

For further assistance or inquiries regarding your Majorette Motor Lift Center Garage Playset, please contact the retailer where the product was purchased. You may also visit the official Majorette website for general product information.

© 2023 Majorette. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B096ZKSRTL

More documents and user manuals: **https://manuals.plus/**