

## APPASO APS2181MB

# APPASO APS2181MB 3-Hole Kitchen Faucet User Manual

Model: APS2181MB

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your new APPASO APS2181MB 3-Hole Kitchen Faucet with Pull-Down Sprayer and Soap Dispenser. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product. Keep this manual for future reference.

## 2. PRODUCT OVERVIEW

The APPASO APS2181MB kitchen faucet is designed for convenience and durability. It features a pull-down sprayer with dual functions (stream and spray), a separate handle for precise temperature and flow control, and an integrated soap dispenser. The matte black finish is engineered to resist fingerprints and spots, maintaining its appearance over time. The faucet is compatible with both 2-hole and 3-hole sink configurations.



Image 2.1: The APPASO APS2181MB 3-Hole Kitchen Faucet with its pull-down sprayer, single handle, and soap dispenser.

### 3. SAFETY INFORMATION

---

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks. Do not overtighten.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep small parts out of reach of children.

### 4. INCLUDED COMPONENTS

---

Verify that all parts are present before beginning installation:

- APPASO 3-Hole Kitchen Faucet (Main body with pull-down sprayer)
- Single Handle
- Soap Dispenser
- Mounting Accessories (nuts, washers, gaskets)
- Weight (for pull-down hose retraction)
- Deck Plate (for 3-hole installation)
- Hot and Cold Water Supply Hoses
- User Manual (this document)



Image 4.1: All parts included with the APPASO APS2181MB faucet, laid out for inspection.

## 5. SPECIFICATIONS

Brand	APPASO
-------	--------

Model Name	APS2181MB
Finish Type	Matte Black
Material	304 Stainless Steel, PEX Hose, ABS Plastic
Mounting Type	Deck Mount
Hole Count	3 (also compatible with 2-hole sinks)
Number of Handles	1
Maximum Flow Rate	1.8 Gallons Per Minute (6.8 L/min)
Spout Height	7.4 Inches
Spout Reach	9.2 Inches
Hose Length (Pull-Down)	20 Inches
Product Dimensions	12 x 3 x 18 inches

## OPTIMUM SIZE

Fit for most undercounter cabinets



## 6. SETUP (INSTALLATION)

### 6.1 Pre-Installation

1. Turn off the water supply at the main valve.
2. Clear the area under the sink for easy access.
3. Remove your old faucet, if applicable.
4. Ensure your sink has the correct number of holes (2 or 3) and that the mounting hole size is between 1.4 and 1.5 inches. The maximum counter-top thickness should be 2 inches.



Image 6.1: The faucet is adaptable for both two-hole and three-hole sink installations.

### 6.2 Installation Steps

The APPASO faucet features a quick-in system designed for straightforward DIY installation, typically completed in approximately 20 minutes without specialized tools.

1. **Install Faucet Body:** Insert the main faucet body into the center hole of your sink. If using a 3-hole sink, place the deck plate over the holes first. Secure it from underneath with the provided washer and mounting nut.
2. **Install Handle and Soap Dispenser:** Insert the handle and soap dispenser into their respective holes. Secure them from underneath with their mounting hardware.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding connections on the faucet body and to your hot and cold water stops. Ensure a tight seal.
4. **Connect Sprayer Hose:** Connect the pull-down sprayer hose to the quick-connect fitting under the faucet.
5. **Attach Weight:** Install the counterweight onto the pull-down sprayer hose at the indicated position. This ensures smooth retraction of the spray head.

6. **Test for Leaks:** Slowly turn on the main water supply and check all connections for leaks.
7. **Flush System:** Before first use, remove the spray head and flush the faucet for a few minutes to clear any debris from the water lines. Reattach the spray head.

## 7. OPERATING INSTRUCTIONS

---

### 7.1 Water Flow and Temperature Control

The single handle controls both water flow and temperature:

- **Turn On/Off:** Lift the handle to turn on the water. Push it down to turn off.
- **Adjust Flow:** The further you lift the handle, the greater the water flow.
- **Adjust Temperature:** Move the handle to the left for hot water and to the right for cold water.



Image 7.1: The single handle allows for precise control of both water temperature and flow.

### 7.2 Pull-Down Sprayer Functions

The pull-down sprayer offers two distinct spray modes:

- **Stream Mode:** Ideal for filling pots and pitchers. Press the button on the spray head to activate this mode.
- **Spray Mode:** Provides a powerful spray for rinsing dishes and cleaning the sink. Press the button again to switch to this mode.

The 20-inch pull-out hose provides extended reach for various kitchen tasks.



# TWO -FUNCTION SPRAYHEAD



Easy-clean nozzles



Stream mode



Spray mode

Image 7.2: The sprayhead features easy-clean nozzles and switches between stream and spray modes.



Image 7.3: The 20-inch pull-down hose allows for extensive reach within the sink area.

### 7.3 Soap Dispenser Operation

To use the soap dispenser, simply press down on the pump head. To refill, lift the pump head and pour liquid soap directly into the reservoir from above the counter.

## 8. MAINTENANCE

### 8.1 Cleaning the Faucet

- Clean the matte black finish with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- The easy-clean nozzles on the spray head can be wiped with a finger or soft brush to remove mineral buildup.





Image 8.1: The flexible rubber nozzles allow for easy removal of mineral deposits.

## 8.2 Ceramic Cartridge

The faucet is equipped with a durable ceramic cartridge, designed for long-lasting, drip-free performance. No regular maintenance is typically required for the cartridge itself.



Image 8.2: An illustration of the durable ceramic cartridge, key to the faucet's reliable operation.

## 9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Pressure	Clogged aerator or debris in water lines.	Remove the spray head and flush the faucet to clear debris. Clean the aerator if necessary. Ensure water supply valves are fully open.
Leaks from connections	Loose connections or damaged washers.	Ensure all connections are tightened properly. Check and replace any damaged washers or O-rings. Do not overtighten.
Sprayer does not retract fully	Weight improperly positioned or obstruction.	Verify the counterweight is correctly installed on the pull-down hose and is not obstructed under the sink.
Water temperature not adjusting	Hot/cold water supply valves closed or cartridge issue.	Ensure both hot and cold water supply valves are fully open. If the problem persists, the ceramic cartridge may need inspection or replacement (contact support).

## 10. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 10.1: An official APPASO product video demonstrating the features and functionality of the kitchen faucet, including the pull-down sprayer and dual spray modes. (Note: Actual video URL would be provided if available in the product data.)

## 11. WARRANTY AND SUPPORT

### 11.1 Warranty Information

The APPASO APS2181MB Kitchen Faucet comes with a **lifetime warranty**, covering defects in material and workmanship under normal use. Please retain your proof of purchase for warranty claims.




### 11.2 Customer Support

For technical assistance, warranty claims, or replacement parts, please contact APPASO customer support:

- **Website:** [Visit the APPASO Store on Amazon](#)
- **Email:** [support@appaso.com](mailto:support@appaso.com) (placeholder)
- **Phone:** 1-800-XXX-XXXX (placeholder)

When contacting support, please have your model number (APS2181MB) and purchase date available.

### Related Documents - APS2181MB

	<p><a href="#">APPASO Pull-Down Spring Kitchen Faucet: Installation and Care Guide</a></p> <p>Comprehensive installation and care guide for the APPASO Pull-Down Spring Kitchen Faucet. Includes pre-installation steps, detailed installation instructions, maintenance tips, troubleshooting solutions, warranty information, and contact details for APPASO.</p>
	<p><a href="#">APPASO Kitchen Faucet Installation Guide</a></p> <p>Detailed instructions for installing your APPASO kitchen faucet, covering product components, dimensions, installation steps, and maintenance. Includes tips for a successful setup.</p>
	<p><a href="#">APPASO Kitchen Faucet: Installation, Specs &amp; Maintenance Guide</a></p> <p>Detailed installation, usage, and maintenance guide for the APPASO Commercial Pre-Rinse Kitchen Faucet. Covers specifications, parts, step-by-step installation, and cleaning instructions for optimal performance and longevity.</p>



[APPASO Pull-Down Kitchen Faucet: Installation and Care Guide](#)

A comprehensive guide for installing, maintaining, and troubleshooting the APPASO Pull-Down Kitchen Faucet. Includes a detailed parts list, warranty information, and step-by-step instructions.



[APPASO Pull Out Kitchen Faucet - Installation and Maintenance Guide](#)

Detailed guide for the APPASO Pull Out Kitchen Faucet, covering specifications, installation guidance, maintenance procedures, and cleaning tips for optimal performance and longevity.



[APPASO Pull-Down Kitchen Faucet Installation and Care Guide](#)

Comprehensive installation and care guide for the APPASO pull-down kitchen faucet. Includes pre-installation checks, step-by-step installation instructions, maintenance tips, troubleshooting advice, and warranty information.