

Brigii Y120PRO

Brigii Mini Vacuum Cleaner Y120PRO User Manual

Model: Y120PRO

INTRODUCTION

The Brigii Mini Vacuum Cleaner Y120PRO is a compact and powerful 3-in-1 device designed for versatile cleaning. It functions as a mini vacuum cleaner for dust and debris, an air duster for blowing away particles from hard-to-reach areas, and a hand pump for vacuum storage bags. This manual provides detailed instructions to help you effectively use and maintain your device.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filter in place.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Charge the device using the provided USB cable and a compatible power source.
- Store the device in a dry place when not in use.

PACKAGE CONTENTS

- Brigii Mini Vacuum Cleaner Y120PRO Main Unit
- Mini brush/flat nozzle
- Hose
- Blow nozzle
- USB Charging Cable
- 2 x Washable HEPA Filters (1 pre-installed, 1 extra)



Image: Brigii Mini Vacuum Cleaner Y120PRO with its various attachments and extra filters.

PRODUCT COMPONENTS

- **Main Unit:** Contains the motor, battery, and control button.
- **Dust Cup:** Collects dust and debris during vacuuming.
- **HEPA Filter:** Filters fine particles from the air. Located inside the dust cup.
- **Vacuum Inlet:** Located at one end for vacuuming.
- **Air Outlet:** Located at the opposite end for blowing/dusting.
- **Nozzles:** Various attachments for specific cleaning tasks (brush, flat, hose, blow).
- **USB Charging Port:** For recharging the internal battery.



Image: Side view of the Brigii Mini Vacuum Cleaner Y120PRO, showing its compact design.

SETUP

- Initial Charge:** Before first use, fully charge the vacuum cleaner. Connect the USB charging cable to the device's charging port and a suitable USB power adapter (not included). The indicator light will show charging status and turn off when fully charged (approximately 3-4 hours).
- Install Filter:** Ensure the HEPA filter is correctly seated inside the dust cup.
- Attach Dust Cup:** Securely attach the dust cup to the main unit.
- Select Nozzle:** Choose the appropriate nozzle for your task and attach it to either the vacuum inlet or the air outlet, depending on the desired function.

OPERATING INSTRUCTIONS

Vacuuming Mode

- Attach the desired nozzle (e.g., flat nozzle, brush nozzle) to the vacuum inlet.
- Press the power button to turn on the vacuum.
- Direct the nozzle towards the area to be cleaned.
- After use, press the power button again to turn off the device.

Air Duster Mode

- Attach the blow nozzle or hose to the air outlet.
- Press the power button to activate the blowing function.
- Use the directed airflow to clear dust from keyboards, electronics, or other delicate surfaces.
- Press the power button to turn off.

Hand Pump Mode

- Connect the vacuum slot (vacuum inlet) to the valve of your vacuum storage bag.
- Press the power button to start the suction.
- Allow the device to remove air from the storage bag until it is compressed.

- Press the power button to turn off and remove the device from the bag.

MAINTENANCE

Cleaning the Dust Cup

1. Ensure the device is turned off.
2. Twist or unlatch the dust cup from the main unit.
3. Empty the collected dust and debris into a waste bin.
4. Wipe the inside of the dust cup with a dry cloth if necessary.

Cleaning/Replacing HEPA Filters



Image: Two Brigi HEPA filters, showing their design for effective filtration.

1. Remove the dust cup and then carefully pull out the HEPA filter.
2. Tap the filter gently over a trash can to dislodge loose dust.

3. For a more thorough cleaning, rinse the filter under running water. Ensure it is completely dry before reinserting it into the vacuum.
4. Replace the filter if it is visibly damaged or if suction power significantly decreases even after cleaning. The product includes extra filters for convenience.

General Care

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure all parts are dry before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Doesn't turn on	Battery is low or depleted.	Charge the device fully.
Weak suction power	Dust cup is full. Filter is clogged. Nozzle is blocked.	Empty dust cup. Clean or replace filter. Check and clear any blockages in the nozzle or inlet.
Device stops unexpectedly	Battery is depleted. Overheating.	Recharge the battery. Allow the device to cool down before resuming use.
Charging indicator not working	Faulty cable or power adapter.	Try a different USB cable or power adapter.

SPECIFICATIONS

Feature	Detail
Model Name	Y120PRO
Brand	Brigii
Special Feature	HEPA Filtration
Filter Type	Cartridge
Is Cordless?	Yes
Maximum Suction	4Kpa (as per feature bullets) / 5.8 Inches (as per specifications)
Battery Capacity	2500 mAh Lithium Battery
Charging Time	3-4 hours
Item Weight	1 pound


Feature	Detail
Dimensions	Length: 8.5in, Diameter: 2.6in
Connectivity Technology	USB

WARRANTY AND SUPPORT

Brigii products are manufactured to high-quality standards. For warranty information, technical support, or any inquiries regarding your Brigii Mini Vacuum Cleaner Y120PRO, please refer to the official Brigii website or contact the seller directly through the platform where the purchase was made. Please retain your proof of purchase for warranty claims.

You can visit the Brigii Store for more information:[Brigii Official Store](#)

Documents - Brigii – Y120PRO



[pdf]

Brigii Y120pro Brigii Y120 Pro @ DC 5V 2500mAhX2
1500mA B1g3tR4IJ1S m media amazon images | |||
...
lang: score:11 filesize: 2.07 M page_count: 5 document date: 2021-08-24