

## Audio Pro P5

# Audio Pro P5 Bluetooth Speaker

## Instruction Manual

### 1. INTRODUCTION

Thank you for choosing the Audio Pro P5 portable Bluetooth speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read these instructions carefully before use.



Image 1.1: The Audio Pro P5 Bluetooth Speaker, showcasing its sleek design and grille.

### 2. PRODUCT OVERVIEW

#### Key Features:

- **Portable Design:** Compact and lightweight for easy transport.
- **Battery Powered:** Up to 14 hours of playback at mid-volume, 4 hours at max volume.

- **Water Resistant (IPX4):** Protected against splashing water from any direction.
- **Bluetooth 5.0:** For stable wireless audio streaming.
- **True 2-Way Speaker:** Features a 1-inch dome tweeter and a 3.2-inch mid-woofer for balanced sound.
- **True Wireless Connection:** Allows pairing two P5 speakers for stereo sound.
- **3.5mm Audio Cable Input:** For wired connections to non-Bluetooth devices.

### What's in the Box:

- Audio Pro P5 Bluetooth Speaker
- 3.5mm Audio Cable
- USB Charging Cable (Type-C)
- User Manual



Image 2.1: The P5 speaker highlighting its portable nature and speaker components.

## 3. SETUP

### Initial Charging:

Before first use, fully charge the Audio Pro P5 speaker. Connect the provided USB charging cable to the speaker's USB-C port and a suitable USB power adapter (not included). The LED indicator will show charging status and turn off when fully charged.


### Powering On/Off:

- **To Power On:** Press and hold the power button ( ) for approximately 2 seconds until the LED indicator illuminates.
- **To Power Off:** Press and hold the power button ( ) for approximately 2 seconds until the LED indicator turns off.

## 4. OPERATING INSTRUCTIONS

### Controls:

The Audio Pro P5 features intuitive touch controls located on the top panel of the speaker.



## Simple and Easy to Use Preset Buttons

Image 4.1: Close-up of the speaker's top panel, showing the power, volume, and Bluetooth buttons.

- **Power Button ( ):** Press and hold to power on/off.
- **Volume Down (-):** Press to decrease volume.
- **Volume Up (+):** Press to increase volume.
- **Bluetooth Button ( ):** Press and hold to enter Bluetooth pairing mode.

### Bluetooth Pairing:

1. Ensure the speaker is powered on.
2. Press and hold the Bluetooth button ( ) for 3 seconds. The LED indicator will flash blue, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
4. Select "Audio Pro P5" from the list of available devices.
5. Once connected, the LED indicator will turn solid blue.

### True Wireless Stereo Pairing (TWS):

To achieve a stereo sound experience, you can pair two Audio Pro P5 speakers together.

1. Ensure both P5 speakers are powered on and not connected to any other Bluetooth device.

2. On one speaker (this will be the primary speaker), press and hold the Bluetooth button () until the LED flashes blue.
3. On the second speaker, quickly double-press the Bluetooth button (). Its LED will flash white.
4. The speakers will attempt to connect to each other. Once connected, the primary speaker's LED will remain solid blue, and the secondary speaker's LED will turn solid white.
5. Now, connect your device to the primary "Audio Pro P5" speaker via Bluetooth as described above. Audio will play in stereo across both speakers.

### **Auxiliary Input:**

For devices without Bluetooth, use the 3.5mm auxiliary input.





Image 4.2: Side view of the P5 speaker, showing the USB-C charging port and the 3.5mm AUX IN port.

1. Connect one end of the supplied 3.5mm audio cable to the AUX IN port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output of your device.
3. The speaker will automatically switch to AUX input mode.

## 5. CHARGING

The Audio Pro P5 is equipped with a rechargeable Lithium Polymer battery. To charge, connect the USB-C cable to the speaker's charging port and a USB power source. A full charge provides approximately 14 hours of playback at mid-volume or 4 hours at maximum volume. The LED indicator will show charging status.

## 6. MAINTENANCE

### Cleaning:

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the surface.

### Water Resistance (IPX4):

The P5 speaker is rated IPX4, meaning it is resistant to splashing water. This makes it suitable for outdoor use where it might encounter light rain or splashes. However, it is not designed to be submerged in water. Ensure all port covers are securely closed before exposing the speaker to moisture.



Image 6.1: The P5 speaker in an outdoor setting, demonstrating its splash-resistant design.

## 7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker fully.
No sound	Volume too low; Device not connected; Incorrect input mode	Increase speaker and device volume; Re-pair Bluetooth; Ensure AUX cable is fully inserted.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker LED is flashing blue; Move device closer; Turn off other Bluetooth devices.
TWS pairing fails	Incorrect pairing sequence; Speakers too far apart	Follow TWS pairing steps carefully; Ensure speakers are within close proximity.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Audio Pro P5
Speaker Type	2-Way (1" dome tweeter, 3.2" mid-woofer)
Connectivity	Bluetooth 5.0, 3.5mm AUX Input
Power Output	25 Watts
Battery Life	Up to 14 hours (mid-volume), 4 hours (max volume)
Water Resistance	IPX4 (Splash Resistant)
Dimensions (DxWxH)	11.2" x 6.42" x 4.92"

Feature	Detail
Item Weight	2.42 pounds (1.1 kg)
Control Method	Touch
Power Source	Battery Powered

## 9. WARRANTY AND SUPPORT


The Audio Pro P5 speaker comes with a limited warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Audio Pro website. For technical support or service inquiries, please contact Audio Pro customer service.

For further assistance, please visit the [Audio Pro Store on Amazon](#).

© 2023 Audio Pro. All rights reserved.

## Related Documents - P5

	<p><a href="#">Audio Pro P5 Portable Bluetooth Speaker User Manual</a></p> <p>User manual for the Audio Pro P5 portable Bluetooth speaker, covering setup, controls, TWS pairing, specifications, and safety information.</p>
	<p><a href="#">Intezze CUBE True Wireless Earbuds: Simple Operating Instructions</a></p> <p>Concise guide to operating Intezze CUBE True Wireless Earbuds, covering power, functions, warranty, and specifications. Features Bluetooth 5.1 and IPX4 rating.</p>
	<p><a href="#">Mobilla MBuds 104 Wireless Earbuds User Manual</a></p> <p>User manual for Mobilla MBuds 104 Wireless Earbuds, covering appearance, charging, pairing, smart touch controls, and specifications. Learn how to connect and use your earbuds.</p>
	<p><a href="#">Solamagic ECO+PRO 1400 Lämmittimen Tekniset Tiedot ja Asennusohjeet</a></p> <p>Energiatehokas Solamagic ECO+PRO 1400 -lämpösäteilijä ulkokäyttöön. Tarkat tekniset tiedot, mitat, asennusohjeet ja 5 vuoden takuutiedot.</p>
	<p><a href="#">Skullcandy Spoke True Wireless Earbuds: Features, Setup, and Controls</a></p> <p>Comprehensive guide to Skullcandy Spoke True Wireless Earbuds, covering features, contents, step-by-step setup, and detailed control functions for music, calls, and voice assistants.</p>



### [LAMAX Clips1 Plus True Wireless Earbuds User Manual and Specifications](#)

Comprehensive guide to the LAMAX Clips1 Plus true wireless earbuds, detailing technical specifications, features, usage instructions, and important safety warnings. Discover the capabilities of your LAMAX audio device.