

[Manuals.plus](#) /

› [Franke](#) /

› Franke Icon Pull-Out Spray Kitchen Faucet User Manual

Franke 115.0625.188

Franke Icon Pull-Out Spray Kitchen Faucet

Model: 115.0625.188

INTRODUCTION

Thank you for choosing the Franke Icon Pull-Out Spray Kitchen Faucet. This modern faucet features an innovative laminar jet for splash-free water flow and a durable ceramic cartridge for long-lasting reliability. This manual provides essential information for the proper installation, operation, and maintenance of your new faucet.



Image: Franke Icon Pull-Out Spray Kitchen Faucet in Chrome finish. This image shows the full faucet from a slight angle, highlighting its sleek design and the pull-out spray head.

SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage or personal injury.

- Ensure water supply is turned off before beginning installation.
- Use appropriate tools and safety equipment.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the faucet finish.

PACKAGE CONTENTS

Verify that all components are present before starting installation:

- Franke Icon Kitchen Faucet (Main Body)
- Mounting Nut
- Connection Hoses (2x, 450mm length)
- Installation Hardware
- User Manual (This document)

SETUP AND INSTALLATION

This faucet is designed for single-hole, deck-mounted installation. A mounting hole diameter of 35 mm is required.

1. **Prepare the Mounting Surface:** Ensure the mounting surface is clean and dry. The maximum thickness for mounting is 55mm.
2. **Insert Faucet:** Place the faucet body into the pre-drilled 35mm mounting hole on your sink or countertop.
3. **Secure Faucet:** From underneath the sink, thread the mounting nut onto the faucet shank and tighten it securely to hold the faucet in place.
4. **Connect Water Supply:** Attach the 3/8" connection hoses (450mm length) to the corresponding hot and cold water supply lines. Ensure all connections are tight to prevent leaks.
5. **Test for Leaks:** Slowly turn on the main water supply and check all connections for any signs of leaks.




Image: Technical drawing illustrating the dimensions and installation requirements for the Franke Icon faucet. Key dimensions include a total height of 355mm, spout height of 260mm, and a required mounting hole diameter of 35mm.

OPERATING INSTRUCTIONS

Your Franke Icon faucet is designed for ease of use with a single lever handle and a pull-out spray function.

- **Water Flow and Temperature:** The single lever handle controls both water flow and temperature. Move the handle up to increase flow and down to decrease. Move it left for hot water and right for cold water.
- **Pull-Out Spray:** Gently pull the spray head from the spout to extend the hose. This allows for greater reach and flexibility for various kitchen tasks.
- **Spray Function:** The pull-out spray head features a shower function in addition to the standard laminar flow. Switch between functions as needed.
- **Spout Rotation:** The faucet spout can rotate 360°, providing maximum flexibility for single or double sinks.



Image: The Franke Icon faucet installed in a modern kitchen, demonstrating its elegant appearance and how the pull-out spray head can be used over a sink.



Image: A close-up view of the single lever handle of the Franke Icon faucet, showing the hot and cold indicators (red and blue dots) and the smooth chrome finish.



Image: A detailed view of the pull-out spray head of the Franke Icon faucet, highlighting the aerator and the sleek design of the nozzle.

MAINTENANCE

Proper care will ensure the longevity and appearance of your Franke Icon faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia-based cleaners, or bleach, as these can damage the finish.
- **Aerator Maintenance:** Periodically unscrew and clean the aerator to remove any mineral deposits that may affect water flow.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve.	Clean or replace aerator; ensure shut-off valves are fully open.
Leaking from Spout	Worn ceramic cartridge; loose connections.	Contact Franke customer support for cartridge replacement; check and tighten connections.
Difficulty Pulling Out Spray Head	Hose obstruction or tangling.	Check under the sink for any obstructions or kinks in the hose.

SPECIFICATIONS

Feature	Detail
Model Number	115.0625.188
Brand	Franke
Material	Brass (Faucet Body), Ceramic (Cartridge), Nylon (Hose)
Finish	Chrome
Installation Method	Single-hole, Deck Mount
Mounting Hole Diameter	35 mm
Spout Height	260 mm
Total Height	355 mm
Number of Handles	1
Special Features	Pull-out spray, 360° swivel spout, Laminar jet
Connection Size	3/8"
Connection Hose Length	450 mm

WARRANTY AND SUPPORT

Franke products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the official Franke website or contact their customer service department. Keep your purchase receipt as proof of purchase.

For further assistance, please visit: www.franke.com

© 2024 Franke. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question