

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Skytech Gaming](#) /
- › [SkyTech Chronos Gaming Computer PC Desktop User Manual](#)

### Skytech Gaming ST-CHRONOSW-0266-AM

# SkyTech Chronos Gaming Computer PC Desktop User Manual

Model: ST-CHRONOSW-0266-AM | Brand: Skytech Gaming

## 1. PRODUCT OVERVIEW

The Skytech Chronos Gaming Computer PC Desktop is a high-performance system designed for an immersive gaming experience. It features an AMD Ryzen 7 3700X 8-Core processor and an Nvidia GeForce RTX 3070 8GB GDDR6 graphics card, ensuring smooth gameplay and efficient multitasking. This system is equipped with a 1TB M.2 Gen4 NVMe SSD for rapid boot times and fast data access, alongside 16GB of DDR4 3200MHz gaming memory for responsive performance. The Chronos series is built with a focus on value and performance, capable of running demanding titles at high to ultra settings with crisp 1440p Quad HD resolution and over 60 frames per second.



Figure 1: Front view of the SkyTech Chronos Gaming PC, showcasing its white chassis and vibrant RGB lighting from the internal fans and components.

## 2. INITIAL SETUP

---

Follow these steps to set up your Skytech Chronos PC for the first time:

1. **Unboxing:** Carefully remove the PC from its packaging. Ensure all accessories, including the power cord, gaming keyboard, and mouse, are present.
2. **Placement:** Place the PC on a stable, flat surface with adequate ventilation. Avoid placing it in enclosed spaces or near heat sources.
3. **Connect Peripherals:**
  - Connect your monitor(s) to the graphics card's display outputs (HDMI or DisplayPort). Ensure the connection is to the dedicated graphics card (Nvidia GeForce RTX 3070), not the motherboard's integrated graphics ports.
  - Connect the included gaming keyboard and mouse to available USB ports.
  - Connect any other peripherals such as speakers, headphones, or external drives.
4. **Power Connection:** Connect the provided power cord to the PC's power supply unit (PSU) and then to a grounded electrical outlet.
5. **Network Connection:** For internet access, connect an Ethernet cable to the LAN port on the back of the PC, or prepare to connect via Wi-Fi (802.11AC) after initial boot-up.
6. **First Boot:** Press the power button on the front of the PC. The system will boot into Windows 10 Home 64-bit. Follow the on-screen instructions to complete the initial Windows setup.



Figure 2: Close-up of the top front panel of the SkyTech Chronos PC, highlighting the power button, LED control, audio jacks, and USB ports (including USB 3.0).

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Power On/Off

- **To Power On:** Press the power button located on the top front panel of the PC.
- **To Shut Down:** Click the Start button in Windows, then select Power > Shut down. Avoid forced shutdowns by holding the power button unless absolutely necessary.

- **To Restart:** Click the Start button in Windows, then select Power > Restart.

## 3.2 Connecting to Wi-Fi

Your PC supports 802.11AC Wi-Fi. To connect:

1. Click the Wi-Fi icon in the system tray (bottom right corner of the screen).
2. Select your desired Wi-Fi network from the list.
3. Click "Connect" and enter the network security key (password) if prompted.

## 3.3 RGB Lighting Control

The Skytech Chronos features 4 RGB dual ring fans. The RGB lighting can typically be controlled via a dedicated button on the top panel (labeled "LED" or similar) or through pre-installed software. Refer to the specific motherboard or fan controller manual for advanced customization options.



Figure 3: Internal view of the SkyTech Chronos PC, showcasing the motherboard, CPU cooler, graphics card, and the illuminated RGB fans designed for maximum cooling performance.

## 4. MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your PC:

- **Dust Cleaning:** Periodically clean dust from the PC's interior, especially fans and heatsinks, using compressed air. Ensure the PC is powered off and unplugged before cleaning.
- **Software Updates:** Keep your Windows operating system, graphics drivers (Nvidia), and other software up to date to ensure stability and performance.

- **Ventilation:** Ensure the PC's vents are not obstructed to allow for proper airflow and prevent overheating.
- **Cable Management:** Maintain tidy internal and external cable management to improve airflow and ease of access.

## 5. TROUBLESHOOTING

This section addresses common issues you might encounter:

Problem	Possible Cause	Solution
PC does not power on.	Loose power cable, PSU switch off, faulty power outlet.	Check power cable connections. Ensure the PSU switch on the back of the PC is in the 'ON' position. Try a different power outlet.
No display on monitor.	Monitor not connected to graphics card, incorrect input source, faulty cable.	Ensure monitor cable is connected to the dedicated graphics card (RTX 3070) ports, not the motherboard ports. Check monitor input source. Try a different display cable.
System is slow or freezing.	Overheating, outdated drivers, too many background applications.	Check for proper ventilation and dust buildup. Update graphics drivers and Windows. Close unnecessary background programs.
RGB fans not lighting up.	Loose connection, software issue, LED button not pressed.	Ensure fan RGB cables are securely connected. Try pressing the LED control button on the top panel. Check for RGB control software.

For more detailed troubleshooting, refer to the [Troubleshooting Guide \(PDF\)](#).

## 6. TECHNICAL SPECIFICATIONS

Component	Specification
Processor	AMD Ryzen 7 3700X 8-Core 3.6GHz (4.4GHz Max Boost) CPU
Motherboard	B550M Motherboard
Graphics Card	Nvidia GeForce RTX 3070 8GB GDDR6
Memory (RAM)	16GB DDR4 3200MHz Gaming Memory
Storage	1TB M.2 Gen4 NVMe SSD
Power Supply	650W 80 PLUS Gold Certified
Operating System	Microsoft Windows 10 Home 64-bit
Case	Skytech Chronos White Edition Gaming Case with front mesh
Cooling	240mm AIO Liquid Cooler, 4 x RGB dual ring fans
Wireless Connectivity	802.11AC Wi-Fi

Component	Specification
Dimensions (LxWxH)	18.1 x 8.4 x 16 inches
Weight	30.8 pounds

## 7. WARRANTY AND SUPPORT

---

Your Skytech Chronos PC comes with comprehensive support:

- **Warranty:** 1 Year Warranty on Parts and Labor.
- **Technical Support:** Lifetime Free Technical Support.
- **Additional Resources:** For further assistance, you can refer to the official [User Manual \(PDF\)](#) or visit the [Skytech Gaming Store on Amazon](#).

