

[Manuals.plus](#) /

› [ArtToFrames](#) /

› ArtToFrames 250 Circle Picture Frame 12x12 Inch, Matte Black - Instruction Manual

ArtToFrames 250 Circle Frame 12x12

ArtToFrames 250 Circle Picture Frame 12x12 Inch, Matte Black - Instruction Manual

1. INTRODUCTION

This manual provides instructions for the proper setup, installation, and maintenance of your ArtToFrames 250 Circle Picture Frame. Please read these instructions carefully before proceeding to ensure correct usage and to preserve the quality of your frame.

2. PRODUCT OVERVIEW

The ArtToFrames 250 Circle Picture Frame is designed to display 12x12 inch circular photos or artwork. It features a matte black finish and is constructed from wood, providing a classic aesthetic. The frame includes flat glass and a sturdy back for protection, along with hardware for wall mounting.

Components:

- 12x12 Inch Circle Frame (Matte Black Wood)
- Circle Flat Glass
- Circle Frame Backing
- Wall Hanging Hardware (sawtooth hanger)



Image 1: Front view of the ArtToFrames 12x12 Inch 250 Circle Frame in Matte Black. This image shows the complete circular frame with its smooth matte black finish, ready to display a picture.



Image 2: A cross-section view of the frame's profile, illustrating the curved design and the rabbet where the glass, artwork, and backing are secured. The matte black finish is visible on the exterior.




Image 3: Technical diagram showing the profile dimensions of the frame, including the 1-inch width and 3/8-inch rabbet depth, labeled with "250" indicating the frame style.

3. SETUP AND INSTALLATION

Follow these steps to prepare your frame and mount it on a wall.

1. **Unpack the Frame:** Carefully remove the frame from its packaging. Inspect all components for any damage.
2. **Prepare Your Artwork:** Ensure your circular photo or artwork is 12x12 inches in size. If necessary, trim your artwork to fit the circular opening precisely.
3. **Remove the Backing:** Gently unfasten the clips or tabs securing the frame backing. Remove the backing and the flat glass.
4. **Clean the Glass:** Use a soft, lint-free cloth and a glass cleaner to clean both sides of the flat glass. Ensure no dust or smudges remain.
5. **Insert Artwork:** Place your prepared artwork into the frame, followed by the clean flat glass, and then the frame backing. Ensure all layers are aligned correctly.
6. **Secure the Backing:** Fasten the clips or tabs to securely hold the backing, glass, and artwork in place.
7. **Attach Wall Hanging Hardware:** The frame comes with a sawtooth hanger for wall mounting. The holes for the hanger must be drilled. Position the sawtooth hanger centrally on the top edge of the frame backing. Mark the screw holes with a pencil. Carefully drill pilot holes (smaller than the screw diameter) and then attach the hanger using the provided screws. Ensure it is securely fastened.
8. **Mount on Wall:** Choose a suitable location on your wall. Use a level to mark the desired hanging point. Install a wall hook or nail appropriate for the frame's weight (approximately 6.8 pounds). Carefully hang the frame, ensuring it is stable and level.

4. OPERATING INSTRUCTIONS

Once installed, the frame requires no further operation. To change the displayed artwork, follow the steps in the "Setup and Installation" section in reverse to remove the backing, replace the artwork, and reassemble.

5. MAINTENANCE

- **Cleaning the Frame:** Wipe the wood frame with a soft, dry cloth to remove dust. Avoid abrasive cleaners or harsh chemicals, as these can damage the matte finish.
- **Cleaning the Glass:** For fingerprints or smudges on the glass, use a glass cleaner and a lint-free cloth. Spray cleaner onto the cloth, not directly onto the glass, to prevent liquid from seeping into the frame edges.
- **Environmental Conditions:** Avoid exposing the frame to direct sunlight, extreme temperatures, or high humidity, which can cause warping, fading, or damage to the wood and artwork.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Frame hangs crooked	Improperly installed wall hook or uneven hanging hardware.	Ensure the wall hook is level. Re-adjust the sawtooth hanger on the frame backing if necessary, ensuring it is centered and straight. Use a level when hanging.
Dust or debris visible under glass	Glass or artwork not cleaned thoroughly before assembly.	Carefully disassemble the frame, clean the glass and artwork with a lint-free cloth, and reassemble.
Artwork appears loose	Backing not fully secured or artwork not sized correctly.	Ensure all clips or tabs are firmly fastened. Verify artwork size is 12x12 inches. If artwork is slightly smaller, use acid-free mounting tape to secure it to the backing.

7. SPECIFICATIONS

Feature	Detail
Brand	ArtToFrames
Model	250 Circle Frame
Size	12x12 inches (for artwork)
Actual Frame Size	13.38 x 13.38 inches (finished size)
Frame Width	1.00 inch
Color	Matte Black
Shape	Round
Mounting Type	Wall Mount
Frame Material	Wood
Finish Type	Matte
Cover Material	Glass
Back Material Type	Wood
Item Weight	6.8 pounds
Product Dimensions	12 x 12 x 1.5 inches

Feature	Detail
Origin	Made in USA



Image 4: A circular logo indicating "Made in the USA, Brooklyn New York," highlighting the product's origin.

8. WARRANTY AND SUPPORT

For warranty information or support inquiries, please refer to the manufacturer's official website or contact ArtToFrames customer service directly. Contact details are typically provided with your purchase documentation or on the product packaging.

You can also visit the [ArtToFrames Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question