

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [HOGART](#) /

› HOGART Electric Instant Water Heater Faucet User Manual

HOGART 10002

HOGART Electric Instant Water Heater Faucet User Manual

Brand: HOGART

Model: 10002

PRODUCT OVERVIEW

The HOGART Electric Instant Water Heater Faucet provides immediate hot water for various applications. Designed for quick and easy installation, it eliminates the need for a separate water heater or central heating system. This faucet is suitable for kitchens, bathrooms, caravans, and other locations where instant hot water is desired.



Image: The HOGART Electric Instant Water Heater Faucet, showcasing its sleek design with a digital temperature display and a chrome-finished spout.

PACKAGE CONTENTS

Before beginning installation, please ensure all components are present in the package:

- 1 x Electric Instant Water Heater Faucet (radiator with solid classic spout)
- 1 x Hose for water supply connection (40 cm, 1/2" F to 1/2" F)
- 1 x Pair of protective gloves
- 1 x User Manual (this document)
- Necessary installation hardware (washers, nuts, etc.)





Image: All components of the HOGART Electric Instant Water Heater Faucet laid out, including the main unit, flexible hose, power cable, and installation accessories.

SETUP AND INSTALLATION

The HOGART Electric Instant Water Heater Faucet is designed for a straightforward DIY installation. Follow these steps carefully:

1. **Preparation:** Ensure the water supply is turned off at the main valve. Clear the installation area.
2. **Mounting:** Insert the faucet into the designated hole on your countertop or sink. The extended thread supports countertops up to 30 mm thickness.
3. **Secure the Faucet:** From underneath the countertop, secure the faucet using the provided washers and nuts. Ensure it is firmly in place and does not wobble.
4. **Water Connection:** Connect the supplied 40 cm hose to the cold water supply line. Connect the other end of the hose to the faucet's water inlet. Ensure all connections are tight to prevent leaks.
5. **Electrical Connection:** The faucet requires a 220V electrical connection. For the power cable to pass through, a minimum 36 mm wide opening is required under the countertop for the electrical plug. Connect the plug to a suitable power outlet.
6. **Final Check:** Once installed, slowly turn on the main water supply and check for any leaks. Before plugging in the unit, ensure water flows freely from the faucet.



Image: A diagram illustrating the installation process, showing the faucet mounted on a countertop with connections for water and electricity. Note the requirement for a 36mm opening for the electrical plug.

ANSCHLIESSEN DES ELEKTRISCHEN KABELS ÜBER ODER UNTER DER OBERFLÄCHE



Image: Depiction of two installation methods for the electrical cable: above or below the surface, highlighting flexibility in setup.

OPERATING INSTRUCTIONS

The HOGART Electric Instant Water Heater Faucet is simple to operate:

- **Cold Water:** Turn the handle to the right for cold water. The further right you turn, the higher the flow.
- **Hot Water:** Turn the handle to the left for hot water. The faucet heats water within 5 seconds of activation.
- **Temperature Variation:** The water temperature ranges between 25 and 50 degrees Celsius. The temperature is inversely proportional to the water flow; a stronger flow results in a lower temperature.
- **Winter Performance:** During cold winter periods, the maximum hot water temperature may be lower than usual, typically not exceeding 30-40 degrees Celsius. For situations requiring a large volume of very hot water, a conventional boiler is recommended.
- **LED Display:** The integrated LED screen displays the current water temperature.



Image: The faucet dispensing hot water, with arrows indicating the flow direction and the heating process. Steam is visible, demonstrating the instant heating capability.




Image: A detailed diagram highlighting key features such as the 360° rotatable spout, hot/cold water control, LED temperature display, ECO Flow for energy saving, safety features, IPX4 splash protection, and nominal power of 3000-3300W.

MAINTENANCE

To ensure the longevity and optimal performance of your HOGART Electric Instant Water Heater Faucet, follow these simple maintenance guidelines:

- **Regular Cleaning:** Clean the exterior of the faucet regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the chrome finish and plastic components.
- **Spout Cleaning:** Periodically check the spout for any mineral buildup or debris that might affect water flow. You can gently unscrew the aerator at the tip of the spout and clean it.
- **Winter Care:** If the faucet is installed in an area prone to freezing temperatures and will not be used for an extended period, it is advisable to drain the water from the unit to prevent damage from freezing.
- **Professional Inspection:** For any internal issues or complex repairs, it is recommended to contact a qualified professional. Do not attempt to disassemble the heating element or internal electrical components yourself.

TROUBLESHOOTING

If you encounter issues with your HOGART Electric Instant Water Heater Faucet, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
No hot water or insufficient heating.	• Power supply issue. • Water flow too high. • Ambient water temperature too low (winter).	• Check if the faucet is properly plugged in and the power outlet is functional. • Reduce water flow to allow more time for heating. • During very cold periods, the maximum temperature may be limited. Consider a conventional boiler for higher temperature needs.
Water leakage from connections.	• Loose connections. • Damaged washers.	• Ensure all water connections are tightened securely. • Check and replace any worn or damaged washers.
Faucet not stable after installation.	• Mounting nut not tightened. • Countertop thickness exceeds limit.	• Re-tighten the mounting nut from underneath the countertop. • Ensure your countertop thickness is within the 30mm limit for proper securing.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	HOGART
Model Number	10002
Product Dimensions	19.48 x 19.48 x 21 cm (7.67 x 7.67 x 8.26 inches)
Weight	1.22 Kilograms
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Electric Corded
Voltage	220 Volt
Wattage	3 kW (3000-3300W)
Flow Rate	4 Liters Per Minute (LPM)
Maximum Pressure	6 Bar
Special Features	LED Display
Installation Method	Surface Mount




Image: A detailed technical drawing showing the dimensions of the HOGART faucet in both millimeters and inches, along with key electrical and water specifications like cable length, working pressure, connection size, voltage, frequency, and nominal power.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your HOGART Electric Instant Water Heater Faucet, please contact the seller directly through the platform where you purchased the product. Keep your purchase receipt or order details handy as proof of purchase.

The product is sold by "Hogart EU store" and fulfilled by Amazon. For specific return policies, please refer to the platform's guidelines, which typically allow returns within 30 days.

© 2025 HOGART. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09751ZVRQ>

More documents and user manuals: <https://manuals.plus/>