**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Summit Appliance CAB18TALLBLK

# Summit Appliance CAB18TALLBLK 18-inch Wide Wall Cabinet Instruction Manual

### Introduction

This manual provides essential instructions for the safe and proper installation, operation, and maintenance of your Summit Appliance CAB18TALLBLK 18-inch Wide Wall Cabinet. Please read all instructions carefully before installation and use. Retain this manual for future reference.

### Important Safety Information

**WARNING:** Always ensure the cabinet is securely mounted to the wall using the provided hardware. Do not overload the cabinet as it may cause it to become unstable and potentially fall off the wall, leading to injury or damage. Follow all local building codes and regulations during installation.



Figure 1: Front view of the Summit Appliance CAB18TALLBLK Wall Cabinet.

This wall cabinet features a durable powder-coated metal construction, two hinged French doors, and two adjustable shelves, designed for efficient storage in various settings.

## Included Components

Verify that all components are present before beginning installation:

- 1 x Wall Cabinet Unit
- 2 x Adjustable Shelves
- Mounting Hardware (screws, anchors, etc.)
- Instruction Manual

## Setup and Installation

Proper installation is crucial for the stability and safety of your wall cabinet. It is recommended that two people perform the installation.

### Tools Required (Not Included):

- Drill
- Level
- Measuring Tape
- Pencil
- Screwdriver (Phillips head recommended)
- Stud Finder (recommended for secure mounting)

### Installation Steps:

1. **Select Location:** Choose a suitable wall location that can support the weight of the cabinet and its contents. Ensure there are no electrical wires or plumbing in the wall where you plan to drill.
2. **Mark Mounting Points:** Hold the cabinet against the wall at the desired height. Use a level to ensure it is straight. Mark the locations for the mounting screws through the pre-drilled holes on the cabinet's back panel.
3. **Prepare Wall:** If mounting into wood studs, drill pilot holes. If mounting into drywall without studs, use appropriate wall anchors (included) and drill holes according to anchor manufacturer instructions.
4. **Mount Cabinet:** Align the cabinet with the drilled holes. Insert and tighten the mounting screws securely. Ensure the cabinet is firmly attached to the wall and does not wobble.
5. **Install Shelves:** Place the adjustable shelves inside the cabinet at your desired height. The cabinet is designed with multiple shelf support positions for flexibility.




Figure 2: Example of wall cabinet installation in a compact kitchen setup.

## Operating Instructions

### Opening and Closing Doors:

The cabinet features two hinged French doors. To open, gently pull the angled steel handles. To close, push the doors until they are flush with the cabinet frame.

### Adjusting Shelves:

The two shelves inside the cabinet are adjustable to accommodate items of various heights. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove it from its current support pegs.
3. Relocate the support pegs to the desired height within the cabinet's pre-drilled holes. Ensure all four pegs are at the same level.
4. Place the shelf back onto the support pegs, ensuring it is stable and level before placing items on it.



Figure 3: Cabinet interior with adjustable shelves.



Figure 4: Detail of adjustable shelf supports.

## Care and Maintenance

To maintain the appearance and longevity of your Summit Appliance wall cabinet, follow these simple care instructions:

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive pads, which can damage the powder-coated finish.
- **Drying:** Dry all surfaces thoroughly with a clean, dry cloth to prevent water spots or streaks.

- **Handles:** Clean the angled steel handles with a soft cloth. If necessary, use a stainless steel cleaner for stubborn marks, following the product instructions.
- **Inspection:** Periodically check the mounting hardware to ensure it remains tight and secure. Retighten screws if any looseness is detected.

## Troubleshooting

If you encounter any issues with your wall cabinet, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Cabinet feels unstable or wobbly. | Loose mounting screws or improper installation. | Ensure all mounting screws are securely tightened. Verify the cabinet is mounted into appropriate wall studs or using adequate anchors. Do not overload the cabinet. |
| Doors do not close properly or are misaligned. | Hinge adjustment needed or cabinet not level. | Check if the cabinet is level. Adjust hinges if necessary (refer to hinge manufacturer instructions if specific adjustments are available). |
| Shelves are not level. | Shelf support pegs are not inserted evenly. | Remove the shelf and ensure all four support pegs are inserted into corresponding holes at the same height. |

## Specifications

Technical details for the Summit Appliance CAB18TALLBLK Wall Cabinet:

| Feature | Detail |
|---|---|
| Model Number | CAB18TALLBLK |
| Brand | Summit Appliance |
| Product Dimensions (D x W x H) | 12"D x 18"W x 18"H |
| Color | Black |
| Material | Metal (Powder Coated) |
| Item Weight | 17 Pounds |
| Number of Shelves | 2 (Adjustable) |
| Door Style | Slab (French Doors) |
| Mounting Type | Wall Mount |
| Assembly Required | No (for cabinet unit, installation required) |

| Feature | Detail |
| --- | --- |
| UPC | 761101066912 |

## Warranty and Customer Support

For specific warranty information regarding your Summit Appliance CAB18TALLBLK wall cabinet, please refer to the warranty card included with your purchase or visit the official Summit Appliance website. For technical assistance, replacement parts, or any other inquiries, please contact Summit Appliance customer support directly.
You can find contact information and additional resources by visiting theSummit Appliance Store on Amazon or their official website.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0975X2145**

More documents and user manuals: **https://manuals.plus/**