

Manuals.plus /

› Moxom /

› Moxom MX-WL15 Hi-Fi Wireless Over-Ear Bluetooth Headset with 7-Color LED Lighting - Black User Manual

Moxom MX-WL15

Moxom MX-WL15 Wireless Over-Ear Bluetooth Headset

Model: MX-WL15 - User Manual

1. INTRODUCTION

Thank you for choosing the Moxom MX-WL15 Wireless Over-Ear Bluetooth Headset. This manual provides essential information for setting up, operating, and maintaining your new headset. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

- Moxom MX-WL15 Wireless Over-Ear Bluetooth Headset
- USB Charging Cable
- User Manual

Note: Specific contents may vary slightly based on region or package version.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and features of your MX-WL15 headset.



Figure 3.1: Moxom MX-WL15 Wireless Over-Ear Bluetooth Headset, front view. This image shows the headset in its full form, highlighting the over-ear design and the general aesthetic.



Figure 3.2: Moxom MX-WL15 Wireless Over-Ear Bluetooth Headset, angled view. This perspective provides a better look at the earcups and headband structure.



Sonido stereo superior

MOXOM MX-WL15

Todos los auriculares son sometido a un meticuloso proceso de producción, proceso de control de calidad de sonido en alta estabilidad.

Figure 3.3: Close-up of the Moxom MX-WL15 ear cup showing control buttons and LED lighting. This image details the button layout for volume, track control, and the distinctive 7-color LED light ring.



Figure 3.4: Moxom MX-WL15 retail packaging. This image displays the product box, indicating key features like Hi-Fi audio and 9 hours of playback time.

4. SETUP

4.1 Charging the Headset

Before first use, fully charge your MX-WL15 headset. The headset is equipped with a 500 mAh Lithium battery.

1. Connect the small end of the USB charging cable to the charging port on the headset.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red light for charging, off or blue for fully charged).
4. Charging time is approximately **2.5 hours** for a full charge.

4.2 Bluetooth Pairing

Pair your headset with your Bluetooth-enabled device (smartphone, tablet, computer).

1. Ensure the headset is turned off.
2. Press and hold the Power/Multi-function button on the headset until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "MX-WL15" from the list of found devices.
5. Once connected, the LED indicator on the headset will typically show a solid blue light or flash slowly.
6. The headset will automatically reconnect to the last paired device when turned on, if the device's Bluetooth is active and within range.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for 3 seconds.
- **Power Off:** Press and hold the Power/Multi-function button for 3-5 seconds.

5.2 Music Playback

- **Play/Pause:** Short press the Power/Multi-function button.
- **Volume Up:** Short press the "V+" button.
- **Volume Down:** Short press the "V-" button.
- **Next Track:** Long press the "V+" button.
- **Previous Track:** Long press the "V-" button.

5.3 Call Management

The MX-WL15 includes a built-in microphone for hands-free calls.

- **Answer/End Call:** Short press the Power/Multi-function button.
- **Reject Call:** Long press the Power/Multi-function button.
- **Redial Last Number:** Double-press the Power/Multi-function button.

5.4 LED Lighting

The headset features 7-color LED lighting. Refer to the specific button on your headset (if available, often a dedicated light button or a long press on a volume button) to cycle through lighting modes or turn them off.

6. MAINTENANCE

6.1 Cleaning

- Wipe the headset with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging port free of dust and debris.

6.2 Storage

- Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in humid environments.
- If storing for an extended period, charge the battery every few months to maintain its lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset for 2.5 hours.
Cannot pair with device.	Headset not in pairing mode; device Bluetooth off; too far from device.	Ensure headset is in pairing mode (flashing red/blue); turn on device Bluetooth; move headset closer to device (within 10 meters).
No sound.	Volume too low; headset not connected; incorrect audio output selected on device.	Increase headset and device volume; ensure headset is paired and connected; select MX-WL15 as audio output on your device.
Poor sound quality.	Interference; low battery.	Move away from other wireless devices; charge the headset.

8. SPECIFICATIONS

Feature	Detail
Brand Name	Moxom
Model Number	MX-WL15
Headphones Form Factor	Over Ear
Connectivity Technology	Bluetooth
Wireless Communication Technology	Wireless
Bluetooth Version	5.0
Frequency	2.402 - 2.480 GHz
Speaker Size	40mm * 1
Impedance	32Ω
Lithium Battery	500 mAh
Play Time	9 hours
Talk Time	9 hours
Charging Time	2.5 hours
Microphone Included	Yes
Color	Black
Noise Control	Active Noise Cancellation
Headphone Jack	3.5 mm Jack
Included Components	Ear Cushions, Headband
Age Range Description	Adult
Package Dimensions	20.8 x 19.6 x 8.6 cm
Item Weight	496 grams
Manufacturer	Moxom
First Available Date	June 13, 2021

9. WARRANTY AND SUPPORT

Moxom products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Moxom website. Keep your purchase receipt as proof of purchase for warranty claims. No official seller videos were found for this product.

