

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VJIANGER](#) /

› [VJIANGER 4K Vlogging Camera Instruction Manual](#)

VJIANGER 4K-2

VJIANGER 4K Vlogging Camera Instruction Manual

Model: 4K-2 | Brand: VJIANGER

PRODUCT OVERVIEW

The VJIANGER 4K Vlogging Camera (Model 4K-2) is a versatile digital camera designed for both photography and video recording, particularly suited for vlogging and content creation. It features 4K Ultra HD resolution, a 180° flip screen, 16X digital zoom, and comes with wide-angle and macro lenses for enhanced versatility. Its compact and portable design makes it ideal for various uses, from casual photography to travel vlogging.



Figure 1: VJIANGER 4K Vlogging Camera and included accessories.

WHAT'S IN THE BOX

Upon unboxing your VJIANGER 4K Vlogging Camera, please ensure all the following items are present:

- 4K Camera x1
- 32GB Micro SD Card x1
- Type-C Cable x1
- Battery x2
- Instruction Manual x1
- Lenses x1 (includes 52mm wide angle & macro lenses)



Ideal Gift-Accessories



Digital Camera*1



Batteries*2
Dual Charger*1



Type-C Cable*1



32G TF Card*1



Macro Lens*1



Wide Angle Lens*1



Charger*1

Figure 2: All components included in the VJIANGER 4K Vlogging Camera package.

SETUP GUIDE

1. Charging the Batteries

Before first use, fully charge both included Lithium Ion batteries. Insert a battery into the dual charger and connect

the Type-C cable to a USB power source. The indicator light on the charger will show charging status.

2. Inserting the Battery and Micro SD Card

1. Open the battery compartment cover on the bottom of the camera.
2. Insert a charged battery, ensuring correct orientation.
3. Insert the 32GB Micro SD card into the designated slot until it clicks into place.
4. Close the battery compartment cover securely.

3. Attaching Lenses

The camera comes with a 52mm wide-angle lens and a macro lens. To attach, align the lens with the camera's main lens and gently twist clockwise until it locks. The macro lens can be used independently or attached to the wide-angle lens for extreme close-ups.



Figure 3: Demonstrating the attachment of the macro lens to the camera.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the power button located on the top of the camera to turn it on or off. The LCD screen will illuminate.

2. Using the 180° Flip Screen

The LCD screen can be flipped out and rotated 180° for self-recording (vlogging) or viewing from different angles. This feature is particularly useful for framing yourself in videos or photos.



4K Video Camera

Higher image quality and clearer videos



Figure 4: The 180° flip screen allows for easy self-recording and versatile viewing.

3. Taking Photos

1. Turn on the camera and select Photo Mode using the mode dial.
2. Frame your shot using the LCD screen.

3. Half-press the shutter button to autofocus. The focus frame will turn from red to green when focus is achieved.
4. Fully press the shutter button to capture the photo.

4. Recording Videos

1. Turn on the camera and select Video Mode.
2. Press the record button to start recording. Press again to stop.
3. The camera supports 4K video at 30fps and 1080p Full HD at 60fps.

Your browser does not support the video tag.

Video 1: A demonstration of the VJIANGER 4K camera's video recording capabilities and features like Wi-Fi upload.

5. Digital Zoom and Flash

Use the zoom controls to adjust the 16X digital zoom. The built-in fill light (flash) can be activated for low-light conditions to capture detailed photos.

Built-in Fill Light

Capture detailed photos even in low-light conditions



Figure 5: The camera's built-in flash helps illuminate subjects in dark environments.

6. Webcam Functionality

Connect the camera to your PC using the USB cable to use it as a webcam. This is ideal for live streaming or video calls, especially for vloggers and content creators.

7. Playback and Transfer

View your photos and videos directly on the camera's LCD screen. You can transfer files to a computer via USB or use an HDMI cable (not included) to connect to a TV for larger viewing.

MAINTENANCE

- Keep the camera clean by wiping it with a soft, dry cloth.
- Avoid exposing the camera to extreme temperatures, dust, or moisture.
- When not in use, store the camera in a dry, cool place, preferably in its original packaging or a protective case.
- Regularly check the battery contacts for any dirt or corrosion.
- Ensure the lens is free from smudges or dust for optimal image quality. Use a lens cleaning cloth if necessary.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Camera does not power on.	Battery is not charged or incorrectly inserted. Ensure battery is fully charged and inserted correctly.
Blurred photos.	Lens is dirty or not properly focused. Clean the lens. Ensure autofocus is engaged or manually adjust focus.
Cannot record video/take photos.	Micro SD card is full or not inserted. Check card storage or insert a new card. Ensure correct mode is selected.
Poor image quality in low light.	Flash is off or insufficient lighting. Activate the built-in flash or use external lighting.
Camera not recognized by PC.	USB cable issue or driver problem. Try a different USB port/cable. Ensure camera is in PC mode.

TECHNICAL SPECIFICATIONS

Brand: VJIANGER

Model Name: W02

Model Number: 4K-2

Effective Still Resolution: 56 MP

Video Resolution: 1080p, 2160p (4K)

Digital Zoom: 16 x

Screen Size: 3 Inches LCD

Flash Memory Type: Micro SD (32 GB included)

Connectivity Technology: Wi-Fi, USB

Battery Type: Lithium Ion (2 included)

Item Weight: 0.65 Kilograms

Item Dimensions (D x W x H): 2"D x 5"W x 3"H

Material: Metal, Plastic


Special Feature: Compact, 180° Flip Screen, Autofocus, Built-in Fill Light

WARRANTY AND SUPPORT

VJIANGER products are designed for reliability and performance. For any questions, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official VJIANGER website. We are committed to providing excellent customer service.



Figure 6: VJIANGER is dedicated to providing comprehensive customer support.

	<p><u>AGFAPHOTO Realishot VLG-4K Vlogging Camera Bundle: Features and Specifications</u></p> <p>Explore the AGFAPHOTO Realishot VLG-4K vlogging camera bundle, featuring a 24MP sensor, 4K video recording, 16x digital zoom, and included accessories like a wide-angle lens, powerbank tripod, and microphone.</p>
	<p><u>LAOWA FF 15mm F4.5 Wide Angle Macro Lens User Manual</u></p> <p>User manual for the LAOWA FF 15mm F4.5 Wide Angle Macro 1:2 full frame lens, covering features, precautions, instructions, focusing methods, and specifications.</p>
	<p><u>AUKEY Ora 2-in-1 Lens Set (PL-WD06) User Manual</u></p> <p>User manual for the AUKEY Ora 2-in-1 Lens Set (PL-WD06), featuring a 120° Wide Angle lens and a 15X Macro lens for smartphones. Includes instructions on attachment and usage.</p>
	<p><u>AUKEY Ora 2-in-1 Lens Set User Manual</u></p> <p>User manual for the AUKEY Ora 2-in-1 Lens Set, featuring a 140° Wide Angle lens and a 10X Macro lens for smartphones. Includes instructions on attachment, usage, and specifications.</p>
	<p><u>Apexel HD Clear 2-in-1 Kit 120° Wide Angle P 15X Macro // Apexel HD 110° Wide Angle Lens User Manual</u></p> <p>User manual for Apexel smartphone lenses, including the HD Clear 2-in-1 Kit (120° Wide Angle, 15X Macro) and HD 110° Wide Angle Lens. Covers installation, lens effects, usage, FAQs, and warranty information.</p>
	<p><u>Video Camera Camcorder 4K 48MP 30FPS with IR Night Vision, 18X Digital Zoom Camera Recorder 3.0" LCD Touch Screen Vlogging Camera for YouTube with Remote Controller, 2 Batteries, 32GB SD Card</u></p> <p>User manual for the 4K Video Camera Camcorder featuring 48MP, 30FPS, IR Night Vision, 18X Digital Zoom, 3.0" LCD Touch Screen, Vlogging capabilities, remote controller, and support for 2 batteries and 32GB SD card. Provides detailed instructions on setup, operation, shooting modes, settings, connectivity, and troubleshooting.</p>