

## VJIANGER 4K-2

# VJIANGER 4K 48MP Vlogging Camera User Manual

Model: 4K-2

## INTRODUCTION

This manual provides essential instructions for the safe and effective operation of your VJIANGER 4K 48MP Vlogging Camera, Model 4K-2. Please read this manual thoroughly before using the camera and retain it for future reference.

## WHAT'S INCLUDED

The VJIANGER 4K 48MP Vlogging Camera package includes the following items:

- VJIANGER 4K 48MP Vlogging Camera (Model: 4K-2)
- 52mm Wide Angle Lens
- Macro Lens
- 32GB Micro SD Card
- USB Cable
- Dual Charger
- 2 x Lithium Ion Batteries
- Power Adapter
- User Manual



Figure 1: VJIANGER 4K 48MP Vlogging Camera and its primary accessories.



Figure 2: Breakdown of included accessories for the VJANGER 4K 48MP Vlogging Camera.

## CAMERA COMPONENTS

Familiarize yourself with the main components of your camera:

- **Lens:** The primary lens for capturing images and videos. The camera supports 16X Digital Zoom.
- **Flash:** Integrated flash for low-light conditions.
- **Hot Shoe:** Allows attachment of external accessories like microphones or additional lights.
- **180° Flip Screen:** Rotatable LCD screen for easy self-recording and viewing.
- **Control Buttons:** Various buttons for navigation, menu access, zoom, and playback.
- **Power Button:** Turns the camera on/off.
- **Shutter Button:** Captures photos and starts/stops video recording.
- **USB-C Port:** For charging and data transfer.
- **HDMI Port:** For connecting to external displays.
- **Microphone Input:** 3.5mm jack for external microphone.
- **Tripod Mount:** 1/4 standard size thread for tripod attachment.



Figure 3: Front view of the VJIANGER 4K 48MP Vlogging Camera.



# Pause Function




Figure 4: Rear view of the VJIANGER 4K 48MP Vlogging Camera with flip screen open.

## SETUP

### 1. Battery Installation and Charging

1. Open the battery compartment cover located at the bottom of the camera.
2. Insert a fully charged Lithium Ion battery into the compartment, ensuring correct polarity.
3. Close the battery compartment cover securely.
4. To charge batteries, use the provided dual charger and USB cable. Connect the charger to a power source using the power adapter.
5. A fully charged battery provides approximately 1-1.5 hours of use. The camera supports recording while charging.

### 2. Memory Card Installation

1. Locate the Micro SD card slot, typically near the battery compartment.
2. Insert the provided 32GB Micro SD card into the slot until it clicks into place.
3. Ensure the card is inserted correctly to avoid damage.



### 3. Lens Attachment

1. The camera comes with a pre-attached macro lens and a separate wide-angle lens.
2. To attach the wide-angle lens, gently twist it onto the front of the macro lens until secure.
3. Ensure lenses are clean and free of dust before attachment.




Figure 5: VJANGER 4K 48MP Vlogging Camera with wide-angle lens attached.

## OPERATING MODES

### 1. Power On/Off

Press and hold the **Power Button** (usually on top) to turn the camera on or off. The LCD screen will display a welcome message upon startup.

### 2. Photo Mode

- Select Photo Mode using the mode dial or menu.
- Frame your shot using the 180° flip screen.
- Press the **Shutter Button** halfway to focus, then fully press to capture the photo.
- The camera captures images at 48MP resolution.

### 3. Video Mode

- Select Video Mode using the mode dial or menu.
- Press the **Shutter Button** to start recording. A red indicator will typically appear on the screen.
- Press the **Shutter Button** again to stop recording.
- The camera records 4K video at 30FPS, 1080p, or 720p for slow-motion effects.
- **Pause Function:** During video recording, you can pause and resume without creating a new file.




Figure 6: Video resolution options and flip screen functionality.

## ADVANCED FEATURES

### 1. Manual Focus (MF)

This camera supports Manual Focus. In both video and photo modes, gently press the shutter button halfway. A focusing logo frame will appear on the display, allowing you to achieve precise focus before fully pressing the button to capture the moment.



# Manual Focus

MF

Pre-press the camera button,  
press the first segment to focus,  
press the second segment to pause or take photo.



Figure 7: Manual Focus feature in action.

## 2. Webcam Functionality

The camera can be used as a PC camera for live streaming. Connect the camera to your PC using the USB cable and select "Camera Mode" on the device. No additional hardware or software is required.

## 3. External Accessories

The camera features a 3.5mm jack for an external microphone and a hot shoe for connecting external fill lights. It also supports a standard 1/4 inch tripod mount.

## 4. Wi-Fi Connectivity

The camera supports Wi-Fi connectivity for transferring photos and videos to a mobile device. Refer to the camera's on-screen menu for Wi-Fi setup instructions and app download details.

## MAINTENANCE

- Keep the camera and lenses clean using the provided cleaning cloth.
- Store the camera in a dry, cool place away from direct sunlight and moisture.
- Ensure battery contacts are clean.



- Use the lens cap when the camera is not in use to protect the lens.

## TROUBLESHOOTING

If you encounter issues, try the following:

- **Camera not turning on:** Ensure batteries are fully charged and correctly inserted.
- **Blurry photos:** Ensure proper focus (manual or autofocus) and hold the camera steady during capture.
- **Memory card error:** Reinsert the Micro SD card or try a different compatible card.
- **Short battery life:** Ensure batteries are fully charged. Consider carrying spare charged batteries.


## SPECIFICATIONS



Product Dimensions	4.33 x 2.95 x 1.18 inches
Item Weight	1.34 pounds
Item Model Number	4K-2
Batteries	2 Lithium Ion batteries required (included)
Manufacturer	VJIANGER
Photo Sensor Technology	CMOS
Supported File Format	JPEG, RAW
Image Stabilization	Digital
Optical Zoom	16 x
Maximum Aperture	2 f

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the documentation included with your product or visit the official VJIANGER website. Contact information for customer service is typically provided in the product packaging.

### Related Documents - 4K-2

	<p><a href="#">Oiadek DC101L-AF 4K Digital Camera User Manual: Setup, Operation, and Features</a></p> <p>Comprehensive user manual for the Oiadek DC101L-AF 4K digital camera, covering battery installation, charging, SD card usage, formatting, autofocus, playback, downloading files, and webcam functionality.</p>
---	--

	<p><a href="#">Oiadek 4K Digital Camera User Manual</a></p> <p>User manual for the Oiadek 4K Digital Camera, covering battery insertion and removal, charging, TF card usage, formatting, autofocus, playback, deletion, and using the camera as a webcam.</p>
	<p><a href="#">Digital Camera DC202-4K Instruction Manual - User Guide</a></p> <p>User manual for the FamBrow DC202-4K Digital Camera. This guide covers setup, operation, shooting photos and videos, camera settings, technical specifications, and troubleshooting for this 48MP, 16X zoom camera.</p>
	<p><a href="#">Bifevrsr 4K Digital Camera Quick Start Guide</a></p> <p>Comprehensive quick start guide for the Bifevrsr DC202AF-4K digital camera. Learn how to install the battery and SD card, charge the device, format the SD card, take photos and videos, and use the viewfinder. Includes essential operational steps for this 48MP, 16X zoom vlogging camera.</p>
	<p><a href="#">AUKEY Ora 2-in-1 Lens Set (PL-WD06) User Manual</a></p> <p>User manual for the AUKEY Ora 2-in-1 Lens Set (PL-WD06), featuring a 120° Wide Angle lens and a 15X Macro lens for smartphones. Includes instructions on attachment and usage.</p>
	<p><a href="#">AGFAPHOTO Realishot VLG-4K Vlogging Camera Bundle: Features and Specifications</a></p> <p>Explore the AGFAPHOTO Realishot VLG-4K vlogging camera bundle, featuring a 24MP sensor, 4K video recording, 16x digital zoom, and included accessories like a wide-angle lens, powerbank tripod, and microphone.</p>