

[Manuals.plus](#) /

> [Reebok](#) /

> Reebok Classic Leather Nylon Cb User Manual

Reebok AR1701

Reebok Classic Leather Nylon Cb User Manual

Model: AR1701 | Brand: Reebok

PRODUCT OVERVIEW

The Reebok Classic Leather Nylon Cb is a versatile athletic lifestyle shoe designed for both men and women. It combines a classic leather aesthetic with modern comfort and durability, suitable for walking, jogging, and casual daily wear. This model emphasizes human movement and comfort, reflecting Reebok's heritage in sport and style.



Image: A pair of Reebok Classic Leather Nylon Cb shoes, showcasing their overall design.

Key Features

- **Signature Style:** Comfortable and supportive synthetic upper with a classic leather look.
- **Durable and Efficient:** Lightweight yet supportive die-cut EVA midsole designed for longevity.
- **Comfort and Mobility:** Low-top design for enhanced ankle mobility and a padded foam sockliner for extra

cushioning.

- **Reliable Traction:** Highly abrasion-resistant rubber outsoles for durable responsiveness and confident movement.
- **High Performance:** Ideal for walking, jogging, and general casual use.

SETUP AND FIRST USE

Unboxing

Upon receiving your Reebok Classic Leather Nylon Cb shoes, carefully remove them from their packaging. Inspect the shoes for any visible defects or damage. Ensure both shoes are present and match the expected size and color.

Sizing and Fit

These shoes are designed to fit true to size. For optimal comfort and performance, try on the shoes with the type of socks you typically wear. Ensure there is about a thumb's width of space between your longest toe and the end of the shoe. The fit should be snug but not tight, allowing for natural foot movement.



Image: Side view of the Reebok Classic Leather Nylon Cb shoe, showcasing its classic design and material composition.

Refer to the size guide below for detailed measurements:

US ON TERRY SNEAKERS Size Chart

Brand Size	Heel to toe (in)
3.5	8
4	8.2
4.5	8.3
5	8.5
5.5	8.7
6	8.8
6.5	9
7	9.2
7.5	9.3
8	9.5
8.5	9.7
9	9.8
9.5	10
10	10.2
10.5	10.3
11	10.5
11.5	10.7
12	10.8
12.5	11
13	11.2
13.5	11.3
14	11.5
14.5	11.7
15	11.8

WEARING AND USE

General Use

The Reebok Classic Leather Nylon Cb shoes are designed for everyday casual wear, light walking, and jogging. Their durable construction and comfortable fit make them suitable for various daily activities. Avoid using them for specialized

sports that require specific footwear, such as intense running, basketball, or hiking, as this may lead to premature wear or inadequate support.

Lacing

Proper lacing ensures a secure and comfortable fit. Start by loosening the laces completely before putting on the shoes. Once your foot is comfortably inside, begin tightening the laces from the bottom eyelets upwards, ensuring even tension across the foot. Tie a secure knot or bow that does not come undone easily during activity.



Image: Front view of the Reebok Classic Leather Nylon Cb shoe, highlighting the toe box and lacing system.

Cleaning Instructions

- **Surface Cleaning:** For light dirt, wipe the shoes with a soft, damp cloth.
- **Deep Cleaning:** For more stubborn stains, use a mild soap or shoe cleaner mixed with water. Apply with a soft brush or cloth, gently scrubbing the affected areas.
- **Sole Cleaning:** Use a brush to remove dirt and debris from the rubber outsole.
- **Drying:** After cleaning, allow the shoes to air dry naturally at room temperature. Avoid direct sunlight or heat sources, as these can damage the materials. You can stuff the shoes with newspaper or paper towels to help absorb moisture and maintain their shape.
- **Do NOT Machine Wash:** Machine washing can damage the shoe's structure, materials, and adhesives.





Image: Back view of the Reebok Classic Leather Nylon Cb shoe, showing the heel counter and Reebok branding.

Storage

Store your shoes in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, consider using shoe trees to help maintain their shape and prevent creasing.

TROUBLESHOOTING

Common Concerns

- **Shoes feel too tight/loose:** Ensure you have selected the correct size based on the size guide. Adjust lacing for a more secure or relaxed fit. Consider wearing different thickness socks.
- **Squeaking noise:** This can sometimes occur if the insole is rubbing against the inside of the shoe. Try removing the insole, cleaning the area, and reinserting it. If the issue persists, a light dusting of baby powder under the insole may help.
- **Odor:** To prevent odor, allow shoes to air out after each use. You can use shoe deodorizers or baking soda sprinkled inside the shoes overnight. Ensure shoes are completely dry before storage.
- **Excessive sole wear:** While the outsole is abrasion-resistant, excessive wear on specific areas might indicate an irregular gait or overuse. Consider rotating your footwear to extend the lifespan of your shoes.



Image: Bottom view of the Reebok Classic Leather Nylon Cb shoe, showing the rubber outsole pattern designed for traction.

PRODUCT SPECIFICATIONS

Specification	Detail
Item Model Number	AR1701
Brand	Reebok
Department	Mens (Unisex sizing available)
Sole Material	Rubber
Outer Material	Rubber
Closure Type	Lace-Up
Water Resistance Level	Not Water Resistant
First Available Date	November 21, 2014

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or specific support inquiries, please refer to the official Reebok website or contact Reebok customer service directly. Warranty terms and conditions may vary based on region and purchase location.

You can typically find support contact details, FAQs, and warranty information on the manufacturer's official website:

[Visit Reebok Official Website](#)