

Livoo TES242

Livoo TES242 LED Speaker with Wireless Charger

Model: TES242 | Brand: Livoo

1. INTRODUCTION

The Livoo TES242 is a versatile device that integrates a Bluetooth speaker, a 15W fast wireless charger, and an LED ambient light. This manual provides essential information for the safe and efficient use of your device. Please read it thoroughly before operation and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Do not expose the device to water, moisture, or extreme temperatures.
- Keep the device away from heat sources, direct sunlight, and flammable materials.
- Use only the provided USB cable for power. Ensure the power adapter (not included) meets the required specifications (e.g., 5V/2A or higher for optimal charging).
- Do not attempt to disassemble, repair, or modify the device. This will void the warranty and may cause damage or injury.
- Keep out of reach of children.
- Avoid placing metal objects or cards with magnetic strips (e.g., credit cards) on the wireless charging pad, as this may damage the device or the objects.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Livoo TES242 LED Speaker with Wireless Charger
- USB Power Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Livoo TES242 device.



Figure 4.1: Top View of the Device. This image shows the top surface of the Livoo TES242, highlighting the central cross symbol for wireless charging alignment and the control buttons located below it.



Figure 4.2: Device with Phone on Charging Pad. An angled view illustrating a smartphone positioned on the wireless charging pad, with the LED light arch illuminated, demonstrating the device in use.

Controls and Indicators:

- **Wireless Charging Pad:** Central area on the top surface for Qi-compatible device charging.
- **LED Light Arch:** Provides ambient lighting, pivots for direction adjustment.
- **Touch Button (Light Control):** Located on the base, cycles through LED light modes.
- **Bluetooth Speaker:** Integrated speaker for audio output.
- **USB-C Input Port:** For connecting the power cable.

5. SETUP

5.1 Power Connection

1. Connect the small end of the provided USB power cable to the USB-C input port on the Livoo TES242.
2. Connect the larger end of the USB cable to a compatible USB power adapter (e.g., a smartphone charger, minimum 5V/2A recommended for optimal performance, not included).
3. Plug the power adapter into a wall outlet. The device will power on automatically or can be turned on by pressing a power button if available (refer to product overview for specific button locations).

5.2 Initial Charge

For optimal battery performance, it is recommended to fully charge the Livoo TES242 before its first use. The device has a built-in 1500 mAh Li-ion battery, providing up to 4 hours of audio playback on a full charge.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

To connect your smartphone or other Bluetooth-enabled device:

1. Ensure the Livoo TES242 is powered on. It will automatically enter Bluetooth pairing mode, indicated by an audible prompt or flashing light (if applicable).
2. On your smartphone or audio device, enable Bluetooth and search for available devices.
3. Select "TES242" or "Livoo Speaker" from the list of found devices.
4. Once connected, a confirmation sound will be heard from the speaker. You can now play audio through the speaker.
5. The effective Bluetooth range is up to 10 meters (33 feet).

6.2 Wireless Charging Function

The Livoo TES242 features a 15W fast wireless charging pad:

1. Ensure the Livoo TES242 is connected to a power source.
2. Place your Qi-compatible smartphone or device directly onto the center of the charging pad. Align your device with the cross symbol for optimal charging.
3. Charging will begin automatically. Your device's screen or charging indicator will confirm that it is charging.
4. For fast charging, ensure your power adapter supports the required output (e.g., 9V/1.67A).

6.3 LED Light Modes

The integrated LED light arch offers three ambient lighting modes:

1. Locate the "Touch" button on the base of the device.
2. Tap the "Touch" button to cycle through the available light modes: **Natural Light**, **White Light**, and **Yellow Light**.
3. The LED arch can be manually pivoted to adjust the direction of the light as desired.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the device. Do not use liquid cleaners, aerosols, or abrasive chemicals, as these may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, even if not in constant use.

8. TROUBLESHOOTING

If you encounter issues with your Livoo TES242, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	No power connection or depleted battery.	Ensure the USB cable is securely connected to both the device and a working power adapter. Charge the device for at least 30 minutes.
Cannot pair via Bluetooth.	Speaker not in pairing mode, Bluetooth off on source device, or out of range.	Ensure the speaker is powered on and in pairing mode. Turn Bluetooth off and on again on your source device. Move the source device closer to the speaker (within 10m). Forget "TES242" from your device's Bluetooth list and try pairing again.
Wireless charging is not working.	Phone not Qi-compatible, misaligned, or thick phone case.	Verify your phone supports Qi wireless charging. Re-position the phone centrally on the charging pad, aligning it with the cross symbol. Remove any thick phone cases that might interfere with charging. Ensure the speaker is connected to a sufficient power source.
Poor sound quality or disconnections.	Weak Bluetooth signal or interference.	Move your paired device closer to the speaker. Ensure there are no large obstructions between the speaker and your device. Avoid placing the speaker near other electronic devices that may cause interference.

9. SPECIFICATIONS

Technical details for the Livoo TES242 LED Speaker with Wireless Charger:

Feature	Specification
Brand	Livoo
Model Number	TES242
Connectivity Technology	Bluetooth
Speaker Output Power	5 W

Feature	Specification
Bluetooth Range	Up to 10 meters
Wireless Charging Standard	Qi
Wireless Charging Power	15 W Fast Charge
Max Output (Wireless Charging)	9 V / 1.67 A
Compatible Devices	Smartphones, Bluetooth-enabled audio devices
LED Light Modes	3 (Natural, White, Yellow)
Battery Type	Li-ion
Battery Capacity	1500 mAh
Audio Playback Time	Up to 4 hours
Power Source	USB Cable (included)
Output Voltage	5 Volts (DC)
Amperage	1.67 A
Total USB Ports	1
Internal Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Wood
Portable	Yes
Country of Origin	France

10. WARRANTY AND SUPPORT

The Livoo TES242 LED Speaker with Wireless Charger comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical support, warranty claims, or further assistance, please contact your retailer or visit the official Livoo website for customer service information.