

[Manuals.plus](#) /

› [LUXPRO](#) /

› LUXPRO LP600V3 LED Handheld Flashlight User Manual

LUXPRO LP600V3

LUXPRO LP600V3 LED Handheld Flashlight

USER MANUAL

Model: LP600V3

Product Overview

The LUXPRO LP600V3 is a durable and versatile LED handheld flashlight designed for various lighting needs, from everyday use to outdoor activities. It features a robust aircraft-grade aluminum construction and multiple lighting modes, providing reliable illumination.



Figure 1: The LUXPRO LP600V3 LED Handheld Flashlight. This image displays the overall design of the flashlight, highlighting its black, textured body and wrist lanyard.

Safety Information

- **Eye Safety:** Do not look directly into the LED light. The high intensity light can cause temporary vision impairment or permanent eye damage.
- **Battery Safety:**
 - Use only the specified battery type (4 AAA Alkaline batteries).
 - Do not mix old and new batteries, or different types of batteries.
 - Insert batteries with correct polarity (+/-). Incorrect insertion can cause damage.

- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.
- **Heat:** The flashlight head may become warm during prolonged use on high settings. This is normal.
- **Children:** Keep out of reach of children. This is not a toy.

Package Contents

Verify that all items are present in your package:

- LUXPRO LP600V3 LED Handheld Flashlight
- 4 x AAA Alkaline Batteries (pre-installed or included separately)
- Wrist Lanyard

Setup: Battery Installation

The LUXPRO LP600V3 flashlight operates on 4 AAA alkaline batteries. These batteries may be pre-installed with a protective disc, or included separately.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Remove the battery cartridge from the flashlight body.
3. Insert 4 AAA batteries into the cartridge, ensuring the positive (+) and negative (-) ends align with the markings on the cartridge. If batteries are pre-installed, remove any protective disc.
4. Insert the battery cartridge back into the flashlight body with the arrow on the cartridge pointing towards the head of the flashlight.
5. Screw the tail cap back on clockwise until it is securely tightened.

Note: Ensure the tail cap is fully tightened for proper electrical contact and water resistance.

Operating Instructions

The LP600V3 flashlight features a tactical tail cap button for easy operation and mode cycling.

- **Turning On/Off:** Press the tail cap button completely until it clicks to turn the flashlight ON or OFF.
- **Cycling Modes:** With the flashlight ON, lightly press the tail cap button (without clicking) to cycle through the lighting modes:
 - **High:** Provides maximum brightness (550 lumens).
 - **Medium:** A balanced brightness level.
 - **Low:** For extended runtime or close-up tasks (40 lumens).
 - **Hidden Strobe:** A flashing mode for signaling or self-defense.
- **Memory Mode:** The flashlight features a memory mode, meaning it will turn on in the last used lighting mode if left off for more than 5 seconds.

4 Lighting Modes

High, Medium, Low & Hidden Strobe



Figure 2: Illustration of the four lighting modes: High, Medium, Low, and Hidden Strobe, available on the LP600V3 flashlight.




Figure 3: The LP600V3 flashlight provides an ultra-bright output of 550 lumens on its high setting, illuminating a wide area.

Your browser does not support the video tag.

Video 1: Demonstrates the LUXPRO LP600 V3 550 Lumen Flashlight in use, showcasing its brightness and functionality in various scenarios, including indoor and outdoor settings.

Maintenance

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **O-Rings:** Periodically inspect the O-rings for wear and tear. Lubricate them with silicone grease to maintain water resistance.
- **Battery Replacement:** Replace all 4 AAA batteries simultaneously when the light dims significantly. Do not mix old and new batteries.
- **Storage:** Store the flashlight in a cool, dry place. Remove batteries if storing for extended periods (more than a month) to prevent battery leakage and potential damage to the flashlight.

IPX4 Water Resistant Rating

Protected from splashing water
from all directions



Figure 4: The LP600V3 flashlight features an IPX4 water-resistant rating, protecting it from splashing water from all directions. This image shows the flashlight with water droplets, emphasizing its water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Flashlight does not turn on.	Batteries inserted incorrectly. Batteries are dead. Tail cap is loose. Corroded contacts.	Check battery polarity and reinsert. Replace with new AAA batteries. Tighten the tail cap securely. Clean battery contacts with a pencil eraser or cotton swab.
Light is dim or flickers.	Low battery power. Loose tail cap or head.	Replace batteries. Ensure tail cap and head are fully tightened.

Problem	Possible Cause	Solution
Cannot cycle through modes.	Button not fully pressed or released.	Ensure light presses are distinct.
	Tail cap mechanism issue.	Check for debris around the button; clean if necessary.

Specifications

Feature	Detail
Model Number	LP600V3
Brightness	High: 550 Lumens, Low: 40 Lumens
Runtime	Up to 20 hours (Low mode)
Beam Distance	Up to 335 meters (High mode)
Water Resistance	IPX4 (Water Resistant)
Material	Aircraft-Grade Aluminum
Power Source	4 x AAA Alkaline Batteries (Included)
Dimensions	1.48 x 1.48 x 5.7 inches
Weight	6.1 ounces
Special Features	Durable, Ergonomic Handle, Tackgrip Design



Figure 5: A visual summary of the LP600V3's key specifications, including brightness, runtime, beam distance, shockproof rating, and weather resistance.

Tackgrip Design

Molded directly to the aluminum body for longer-lasting durability.



Figure 6: Close-up of the LP600V3's Tackgrip Design, which is molded directly into the aluminum body for enhanced grip and durability.

Warranty & Support

LUXPRO stands behind the quality of its products. The LP600V3 LED Handheld Flashlight comes with a **Lifetime Warranty**.

For warranty claims, technical support, or any questions regarding your product, please visit the official LUXPRO website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Please refer to the official LUXPRO website for the most up-to-date warranty information and contact details.

© 2024 LUXPRO. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question