## Samsung EF-GF711TNEGUS

# Samsung Galaxy Z Flip 3 Silicone Cover with Strap Instruction Manual

**Model: EF-GF711TNEGUS**

## 1. Introduction

This manual provides comprehensive instructions for the proper installation, use, and maintenance of your Samsung Galaxy Z Flip 3 Silicone Cover with Strap. This protective cover is designed to safeguard your device from daily wear and tear while offering enhanced grip and a distinct style.

## 2. Product Features

- **Silicone Material:** Provides protection against bumps, scratches, and minor impacts.
- **Integrated Strap:** Features a built-in strap on the back for a secure and comfortable grip, reducing the risk of accidental drops.
- **Matte Finish:** Enhances the tactile feel and provides a non-slip surface for improved handling.
- **Wireless Charging Compatible:** Designed to allow wireless charging without needing to remove the case.
- **Precise Fit:** Custom-designed for the Samsung Galaxy Z Flip 3, ensuring full access to ports, buttons, and cameras.

## 3. Package Contents

- 1 x Samsung Galaxy Z Flip 3 Silicone Cover (Navy)
- 1 x Integrated Strap

## 4. Setup and Installation

Follow these steps to correctly install the silicone cover on your Samsung Galaxy Z Flip 3:

1. **Prepare Your Device:** Ensure your Samsung Galaxy Z Flip 3 is clean and free of dust or debris.
2. **Identify Case Sections:** The silicone cover consists of two separate pieces, one for the top half of your phone and one for the bottom half.
3. **Remove Protective Film (if present):** Inside each case section, there may be small adhesive strips. Carefully peel off any protective film from these strips. These adhesives help secure the case to your phone.
4. **Install Top Section:** Gently align the top section of the case with the top half of your phone. Press firmly around the edges to ensure a snug fit.
5. **Install Bottom Section:** Similarly, align the bottom section of the case with the bottom half of your phone. Press firmly to secure it.
6. **Verify Installation:** Check that both parts of the case are securely attached and that all ports, buttons, and cameras are unobstructed.






*Image: Inside view of the silicone cover, highlighting the adhesive strips for secure phone attachment.*



*Image: The Samsung Galaxy Z Flip 3 enclosed in the navy silicone cover, displaying the device in its folded state with the strap visible.*

## 5. Operating Instructions

- **Using the Strap:** The integrated strap is designed to provide a more secure grip on your phone. Slide your fingers through the strap to hold your device comfortably and reduce the chance of dropping it. The strap can be adjusted for length to suit your preference.
- **Wireless Charging:** The case is compatible with wireless charging. Place your phone with the case on a compatible wireless charger. Note that the strap material may become slightly warm during wireless charging, which is normal and does not affect phone performance.

- **Accessing Controls:** The case is designed with precise cutouts and button covers to ensure full functionality of your phone's volume buttons, power button, charging port, and speakers.






*Image: The Samsung Galaxy Z Flip 3 in its open position, fitted with the navy silicone cover and its integrated strap.*






*Image: A detailed view of the navy silicone cover, highlighting the orange strap with "FLIP" text, demonstrating its design.*

## 6. Maintenance

- **Cleaning the Silicone Cover:** To clean the silicone cover, gently wipe it with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid harsh chemicals or abrasive cleaners, as these may damage the material.
- **Cleaning the Strap:** The fabric strap can be detached from the case for cleaning. Hand wash the strap with water and a small amount of mild soap. Rinse thoroughly and allow it to air dry completely before reattaching.
- **Regular Inspection:** Periodically inspect the case for any signs of wear or damage. If the case is significantly damaged, consider replacing it to ensure continued protection for your device.

## 7. Troubleshooting

- **Case Feels Loose:** Ensure the adhesive strips inside the case are properly engaged with your phone. If they have lost their stickiness, gently clean the phone's surface and the adhesive strips.
- **Strap Appears Dirty:** Refer to the "Cleaning the Strap" section under Maintenance for instructions on how to clean the fabric strap.
- **Wireless Charging Issues:** Ensure your phone is correctly positioned on the wireless charger. If issues persist, try removing the case to confirm it is not interfering with the charging process.

## 8. Specifications

| | |
|---|---|
| **Brand** | Samsung |
| **Model Number** | EF-GF711TNEGUS |

| | |
|---|---|
| **Compatible Phone Models** | Samsung Galaxy Z Flip3, Samsung Galaxy Z Flip3 5G |
| **Material** | Silicone |
| **Color** | Navy |
| **Item Weight** | 2.12 ounces |
| **Item Dimensions** | 9.5 x 3.5 x 1 inches |
| **Additional Features** | Wireless Charging Compatible |

## 9. Warranty and Support

This Samsung Galaxy Z Flip 3 Silicone Cover with Strap is covered by a**1-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or further support, please contact Samsung Customer Service through their official website or the contact information provided with your product packaging. Please have your model number (EF-GF711TNEGUS) and proof of purchase available when contacting support.
For more information, visit the officialSamsung website.