Manuals+

Q & A | Deep Search | Upload

Timex TW2V30800VQ

Timex Waterbury Classic Chrono 40mm Quartz Watch Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the Timex Waterbury Classic Chrono 40mm Stainless Steel Quartz Dress Watch with Leather Strap (Model: TW2V30800VQ). Please read this manual thoroughly to understand the features and proper operation of your watch.

The watch features a 40mm stainless steel case, a quartz movement, and a genuine leather strap. Key functions include a 30-minute chronograph, a date window, and the Indiglo night-light for visibility in low light conditions. It is designed to be water resistant to 30 meters (100 feet).



Image: Front view of the Timex Waterbury Classic Chrono watch, showcasing the blue dial, chronograph subdials, and brown leather strap.

SETUP

Strap Adjustment

The watch comes with an adjustable 20mm genuine leather strap designed to fit wrist circumferences up to 8 inches. The strap features quick-release spring bars for easy removal and attachment. To adjust the fit, use the buckle to select the appropriate hole on the strap.





Image: Rear view of the watch, showing the brown leather strap with stitching and the stainless steel buckle mechanism.

Time and Date Setting

To set the time and date:

- 1. Pull the crown (center knob) out to position 2 (first click) to set the date. Turn the crown clockwise or counter-clockwise until the correct date appears in the date window.
- 2. Pull the crown out to position 3 (second click) to set the time. Turn the crown to move the hour and minute hands. Ensure the time is set for AM/PM correctly, especially when setting past midnight for the date change.
- 3. Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch.



Image: Side profile of the watch case, highlighting the crown and chronograph pushers.

OPERATION

Chronograph Function

Your watch is equipped with a 30-minute chronograph that measures time to 1/20th of a second.

- Start/Stop: Press the top pusher (button) to start the chronograph. Press it again to stop.
- **Reset:** While the chronograph is stopped, press the bottom pusher to reset all chronograph hands to zero.

Indiglo Night-Light

The Indiglo night-light illuminates the watch dial for easy reading in low-light conditions. To activate, simply press and hold the crown (center knob) briefly.

MAINTENANCE

Water Resistance

This watch is water resistant to 30 meters (100 feet). This rating means the watch can withstand splashes or brief immersion in water. It is **not** suitable for swimming, bathing, or diving. To maintain water

resistance, ensure the crown is fully pushed in at all times when the watch is in contact with water. Do not operate the pushers or crown while the watch is wet or submerged.




Image: A chart illustrating the degree of water resistance for Timex watches, indicating that 30 meters is suitable for rain and splashes but not swimming or diving.

General Care

- Clean your watch regularly with a soft, dry cloth. For the leather strap, avoid prolonged exposure to water and direct sunlight to prevent damage and discoloration.
- Avoid exposing the watch to extreme temperatures, strong magnetic fields, or harsh chemicals.
- Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

TROUBLESHOOTING

- Watch not running: Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Time inaccuracy:** Ensure the crown is fully pushed in. If the watch is consistently fast or slow, it may require servicing.
- Chronograph hands not resetting to zero: Some chronographs allow for micro-adjustment of the hands. Refer to the full Timex manual online or contact customer support for specific adjustment procedures if needed.

SPECIFICATIONS

Feature	Detail
Model Number	TW2V30800VQ
Case Material	Stainless Steel
Case Diameter	40 mm
Case Thickness	10.5 mm
Band Material	Genuine Leather
Band Width	20 mm
Band Circumference/Length	9 inches
Movement	Quartz
Water Resistance	30 meters (100 feet)
Dial Features	Indiglo night-light, Date window, Chronograph subdials
Battery	1 Lithium Metal battery (included)
Weight	1.6 oz (45.36 grams)
Department	Men's



Image: Detailed view of the watch's stainless steel case back, engraved with 'TIMEX', 'WATERBURY COLLECTION', 'WR 50M', and 'STAINLESS STEEL'.

WARRANTY AND SUPPORT

Timex watches are manufactured to high standards and come with a limited warranty. For specific warranty details, registration, or to obtain service, please refer to the warranty card included with your purchase or visit the official Timex website. You can also contact Timex customer support for assistance with any product-related inquiries.

For further information or to find authorized service centers, please visit the Timex Store on Amazon or the official Timex corporate website.

Related Documents

