

[Manuals.plus](#) /

› [AGARO](#) /

› AGARO CR3001 Callus Remover Instruction Manual

AGARO CR3001

AGARO CR3001 Callus Remover Instruction Manual

Model: CR3001

1. PRODUCT OVERVIEW

The AGARO CR3001 Callus Remover is a rechargeable, waterproof device designed for effective removal of hard skin and dead skin from your feet. It features three interchangeable roller heads to suit various skin types and an ergonomic design for comfortable use.



Image 1.1: The AGARO CR3001 Callus Remover, showcasing its main unit and three interchangeable roller heads.

2. WHAT'S IN THE BOX

- AGARO CR3001 Callus Remover Main Unit
- Fine Grinding Head (for daily caring)
- Medium Grinding Head (for dead skin)
- Coarse Grinding Head (for hard skin & stubborn calluses)
- USB Charging Cable
- Cleaning Brush
- Carry Bag

AGARO

CR3001 Callus Remover

- 3 Interchangeable heads
- Rechargeable battery



Image 2.1: The three interchangeable roller heads included with the device, each designed for specific levels of exfoliation.

3. SETUP AND CHARGING

3.1 Initial Charge

Before first use, fully charge the device. Connect the USB charging cable to the charging port on the callus remover and a suitable USB power source. The charging indicator light will show red during charging and turn green when fully charged. A full charge provides approximately 45 minutes of cordless use.

Keep your feet more beautiful



Image 3.1: The callus remover being charged via its USB cable, highlighting its rechargeable battery.

3.2 Attaching/Changing Roller Heads

To attach or change a roller head, ensure the device is turned off. Gently press the release button on the side of the device and pull the current roller head off. Align the new roller head with the slots and push it firmly until it clicks into place.



Image 3.2: A user demonstrating the easy replacement of roller heads on the device.

4. OPERATING INSTRUCTIONS

4.1 Preparation

For best results, soak your feet in warm water for approximately 10 minutes to soften the skin. After soaking, dry your feet thoroughly.

4.2 Using the Callus Remover

1. Select the appropriate grinding head for your needs (fine, medium, or coarse).
2. Press the power button to turn on the device. The device offers two variable speeds: Low for gentle exfoliation and High for powerful scrubbing. Adjust as needed.
3. Gently glide the roller head over the callused or dry skin areas. Apply light to medium pressure. Do not press too hard, as this may cause the device to stop or damage your skin.
4. Continue until the desired smoothness is achieved. Avoid overuse on sensitive areas.
5. After use, turn off the device.



Image 4.1: Visual guide for the three main steps of using the callus remover for optimal results.

4.3 Wet & Dry Use

The AGARO CR3001 is IPX7 waterproof, making it suitable for use in both wet and dry conditions. You can use it in the shower or bath for added convenience.



Image 4.2: The device in use on wet feet, highlighting its waterproof design and ergonomic grip.

4.4 Post-Treatment

After removing calluses, clean your feet and apply a moisturizing cream to keep them soft and smooth.

5. MAINTENANCE

5.1 Cleaning the Device

The roller heads are washable. After each use, remove the roller head and rinse it under running water. Use the included cleaning brush to remove any remaining skin particles from the device and roller head. Ensure the device is completely dry before storing.

5.2 Storage

Store the callus remover and its accessories in the provided carry bag in a cool, dry place, away from direct sunlight and out of reach of children.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, the charging indicator will be red.
- **Roller head stops during use:** This may occur if too much pressure is applied. Reduce pressure and continue. Ensure the roller head is correctly attached.
- **Ineffective callus removal:** Ensure the correct grinding head is selected for the skin type. For very hard calluses, use the coarse grinding head. Ensure the roller head is clean and not worn out.
- **Skin irritation:** Avoid applying excessive pressure or using the device for too long on one area. If irritation occurs, discontinue use.

7. SPECIFICATIONS

Brand	AGARO
Model Number	CR3001 (Item model number: 33528)
Product Dimensions	16.5 x 4.5 x 16 cm
Item Weight	140 g
Material	Stainless Steel (for roller components)
Color	White
Waterproof Rating	IPX7
Battery Type	Rechargeable Lithium-ion
Cordless Use Time	Up to 45 minutes on full charge

Number of Roller Heads	3 (Interchangeable)
------------------------	---------------------

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This product comes with a 1-year warranty. Please refer to the warranty card included in the packaging for detailed terms and conditions. To register your product for warranty, scan the QR code on the product packaging or visit the manufacturer's website. Registration must be completed within 10 days from the date of purchase.

8.2 Customer Support

For any product-related queries, technical assistance, or warranty claims, please contact AGARO customer support. Contact details can typically be found on the product packaging or the official AGARO website.

9. PRODUCT DEMONSTRATION VIDEO

Video 9.1: A short demonstration video showcasing the AGARO CR3001 Callus Remover's features, usage, and accessories.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0979JMR2N>

More documents and user manuals: <https://manuals.plus/>