

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Dyson](#) /
- › [Dyson V15 Detect Cordless Vacuum Cleaner, Multicolor User Manual](#)

Dyson V15

Dyson V15 Detect Cordless Vacuum Cleaner User Manual

Model: V15 Detect

Brand: Dyson

INTRODUCTION

The Dyson V15 Detect is a powerful and intelligent cordless vacuum cleaner designed to reveal microscopic dust and provide thorough cleaning across various surfaces. Its advanced technology ensures efficient debris removal and a cleaner home environment.

INCLUDED COMPONENTS

Your Dyson V15 Detect vacuum cleaner comes with the following components:

- Dyson V15 Detect vacuum cleaner (main unit)
- Anti-tangle hair screw tool
- De-tangling digital Motorbar™ cleaner head
- Dusting Brush
- Combination tool
- Stubborn dirt brush
- Docking station
- Wand clip
- Charger
- Laser Slim Fluffy™ cleaner head
- Crevice Tool





Figure 1: Dyson V15 Detect main unit with Laser Slim Fluffy™ cleaner head attached.



Figure 2: All included tools and cleaner heads for the Dyson V15 Detect.

SETUP

Initial Charging

Before first use, fully charge your Dyson V15 Detect vacuum. Connect the charger to the docking station and plug it into a power outlet. Mount the vacuum onto the docking station. The LCD screen will display the charging status. A full charge takes approximately 270 minutes (4.5 hours).



Figure 3: Dyson V15 Detect charging on its wall-mounted docking station.

Assembly

Attach the desired cleaner head or tool to the end of the wand. Ensure it clicks securely into place. The main unit can also be used as a handheld vacuum by directly attaching tools.

OPERATING INSTRUCTIONS

Power Modes

The Dyson V15 Detect offers multiple power modes to suit different cleaning needs:

- **Eco Mode:** Provides the longest runtime (up to 60 minutes) for lighter cleaning tasks.
- **Auto Mode:** Intelligently adapts suction power based on floor type and debris level, optimizing battery life and cleaning performance.
- **Boost Mode:** Delivers maximum suction for intensive spot cleaning or heavily soiled areas.

Switch between modes using the button on the rear of the main unit's display.

Laser Illumination & Particle Detection

The Laser Slim Fluffy™ cleaner head features a precisely angled laser that illuminates microscopic dust on hard floors, making it visible for thorough cleaning. The LCD screen on the main unit displays real-time particle count and size, providing scientific proof of a deep clean.





Figure 4: Laser Slim Fluffy™ cleaner head illuminating dust on hard floors.

MAINTENANCE

Emptying the Dustbin

To empty the dustbin, hold the vacuum over a trash can. Push the red lever on the side of the dustbin downwards. The bin will open, and the contents will be propelled out. Close the bin securely after emptying.

Washing the Filter

The HEPA filter is washable. To maintain optimal suction, wash the filter at least once a month. Twist the filter counter-clockwise to remove it from the main unit. Rinse the filter under cold running water until the water runs clear. Do not use detergent. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Ensure it is completely dry to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Vacuum not turning on	Battery is depleted	Charge the vacuum fully.
Reduced suction power	Dustbin is full	Empty the dustbin.
Reduced suction power	Filter is dirty or clogged	Wash and thoroughly dry the HEPA filter.
Reduced suction power	Blockage in the cleaner head or wand	Check and clear any blockages from the cleaner head, wand, or main unit.
Cleaner head not spinning	Obstruction in the brush bar	Remove the brush bar and clear any tangled hair or debris.

SPECIFICATIONS

Feature	Detail
Brand	Dyson
Model Name	V15 Detect

Feature	Detail
Item Model Number	V15
Special Features	Dyson DLS Technology, Laser illumination, Cordless, Engineered for homes with pets, 2 advanced cleaner heads, LCD screen display, Washable Filter
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	0.77 Liters
Wattage	120 watts
Runtime	1 hour (60 minutes)
Charging Time	270 minutes
Recommended Uses	Carpet, Hard Floor
Form Factor	Stick
Color	Yellow/Nickel
Product Dimensions	10.5"L x 9.8"W x 49.6"H
Battery Description	Lithium-Ion
Noise Level	78 dB
Amperage	15 Amps
Number of Items	1
Controller Type	Push Button
Control Method	Touch
Number of Speeds	3
Cleaning Path Width	10.1 Inches
Portable	Yes

Feature	Detail
Number of Handles	1
Number of Wheels	2
Series Number	15
Indoor/Outdoor Usage	Indoor
UPC	885609023106
Item Weight	6.03 pounds
Batteries Required	No (built-in)
Battery Type	Lithium-Ion
Import	Made in the USA

WARRANTY AND SUPPORT

Your Dyson V15 Detect Cordless Vacuum Cleaner comes with a manufacturer's warranty. Please refer to the warranty documentation included with your product for specific terms and conditions.

For further support, troubleshooting, or to register your product, please visit the official Dyson website or contact Dyson customer service.

Official Dyson Website: www.dyson.com