

[Manuals.plus](#) /

› [TCL](#) /

› TCL 32S62 32-inch Smart HD LED TV User Manual

TCL 32S62

TCL 32S62 32-inch Smart HD LED TV User Manual

Model: 32S62

1. INTRODUCTION

Thank you for choosing the TCL 32S62 32-inch Smart HD LED TV. This manual is designed to guide you through the installation, operation, and maintenance of your new television. Please read these instructions carefully before operating the TV and retain them for future reference.



Image 1.1: Front view of the TCL 32S62 32-inch Smart HD LED TV.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following safety precautions:

- **Power Source:** Connect the TV only to an AC power outlet with the correct voltage as indicated on the TV's label.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Heat Sources:** Keep the TV away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- TCL 32S62 32-inch Smart HD LED TV
- Remote Control

- Power Cable
- User Manual (this document)
- TV Stand (if applicable)
- Screws for TV Stand (if applicable)

4. SETUP

4.1 Attaching the Stand (Optional)

If you are not wall-mounting the TV, attach the included stand:

1. Place the TV face down on a soft, flat surface to prevent screen damage.
2. Align the stand with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws. Ensure the stand is firmly attached.

4.2 Connecting External Devices

Connect your devices to the TV using the appropriate ports:

- **HDMI (x3):** For high-definition audio and video from Blu-ray players, game consoles, or set-top boxes.
- **USB (x2):** For connecting USB storage devices to play media files (video, photos, music).
- **Video Input (Composite/Component x1):** For older devices using composite or component video cables.
- **RF (x1):** For connecting an antenna or cable TV signal.
- **LAN (x1):** For a wired internet connection.

4.3 Power On and Initial Setup

After connecting all necessary cables:

1. Plug the power cable into the TV and then into a wall outlet.
2. Press the power button on the TV or the remote control.
3. Follow the on-screen instructions for the initial setup, including language selection, network connection (Wi-Fi or LAN), and channel scanning.

5. OPERATING THE TV

5.1 Remote Control Functions

The remote control allows you to access all TV functions. Refer to the remote control diagram (not included in this text) for specific button layouts.

5.2 Smart TV Features

Your TCL 32S62 TV runs on a Linux operating system and offers various smart features:

- **Wi-Fi Connectivity:** Connect to your home wireless network for internet access.
- **Internet Browser:** Browse websites directly on your TV.
- **Pre-installed Apps:** Access popular streaming services like YouTube, Netflix, Dailymotion, and Filmbox Live.
- **App Store:** Download additional applications and games from the integrated app store.
- **T-Cast App:** Use your mobile phone as a remote control for the TV by downloading the T-Cast application.

- **Parental Control:** Utilize features like the 'Toon Googles' app for child protection.

5.3 Digital Terrestrial Reception

The TV supports DVB-C/T/T2 digital terrestrial reception, allowing you to receive digital broadcast channels with a compatible antenna.

6. MAINTENANCE

Proper care ensures the longevity of your TV:

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (apply to cloth, not directly to screen).
- **Cabinet Cleaning:** Wipe the TV cabinet with a soft, dry cloth.
- **Dusting:** Regularly dust the ventilation openings to prevent overheating.
- **Unplug When Not in Use:** If the TV will not be used for an extended period, unplug it from the power outlet.

7. TROUBLESHOOTING

Before contacting service, try these solutions for common issues:

Problem	Possible Cause	Solution
No power	Power cable disconnected; power outlet issue	Check power cable connection; try another outlet.
No picture, but sound is present	Incorrect input source; external device issue	Press the 'Source' button on the remote to select the correct input. Check external device connections.
No sound, but picture is present	Volume too low or muted; audio cable issue	Increase volume; check mute status. Ensure audio cables are connected correctly.
Cannot connect to Wi-Fi	Incorrect password; router issue; TV too far from router	Re-enter Wi-Fi password. Restart router. Move TV closer to router or use a wired LAN connection.
Remote control not working	Batteries depleted; obstruction	Replace batteries. Remove any obstructions between remote and TV.

8. SPECIFICATIONS

Feature	Specification
Brand	TCL
Model Number	32S62
Screen Size	32 inches
Display Technology	LED (LCD with LED Backlight)
Resolution	1366 x 768 (HD)

Feature	Specification
Aspect Ratio	16:9
Refresh Rate	60 Hz
Contrast Ratio	1:3000
Brightness	240 cd/m ²
Viewing Angle	178°
Response Time	6.5 ms
Operating System	Linux
Connectivity Technology	Wi-Fi, LAN
Supported Internet Services	Amazon Instant Video, Netflix, YouTube, Dailymotion, Filmbox Live
HDMI Ports	3
USB Ports	2
Video Input (Composite/Component)	1
RF Input	1
LAN Port	1
Audio Power Output	2 x 5 Watt
Dimensions (W x H x D) without Stand	734 x 435 x 81.6 mm
Dimensions (W x H x D) with Stand	734 x 482 x 184 mm
Net Weight	4.5 kg
Gross Weight (Packaged)	6 kg

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official TCL website for your region. If you encounter any issues that cannot be resolved using the troubleshooting guide, please contact TCL customer support for assistance.

Please have your TV model number (32S62) and serial number ready when contacting support.