

[Manuals.plus](#) /

› [JISULIFE](#) /

› JISULIFE Handheld Mini Fan, 3 IN 1 USB Rechargeable Portable Fan Instruction Manual

JISULIFE F8

JISULIFE F8 Handheld Mini Fan User Manual

Model: F8

1. INTRODUCTION

Thank you for choosing the JISULIFE F8 Handheld Mini Fan. This innovative device combines three essential functions into one compact unit: a powerful portable fan, a convenient backup power bank, and a practical flashlight. Designed for maximum portability and versatility, the F8 is your ideal companion for staying cool and connected on the go, whether you're traveling, attending concerts, or simply enjoying the outdoors.

2. PRODUCT OVERVIEW

The JISULIFE F8 features a unique folding design, allowing it to transform from a compact, pocket-sized device into a handheld fan or a stable desktop fan. Its durable construction and long-lasting battery ensure reliable performance.



Figure 2.1: JISULIFE F8 Handheld Mini Fan (Closed and Open)

Key Features:

- **3-in-1 Functionality:** Handheld Fan, Power Bank, and Flashlight.

- **Long Battery Life:** Up to 19 hours of cooling on a single charge.
- **Folding Design:** Transforms from 180° handheld to 270° desktop mode.
- **Pocket-sized Portability:** Compact and easy to carry.
- **USB Rechargeable:** Convenient charging via various USB sources.


3 IN 1 Pocket Fan



Fan



Flashlight



Backup Power Bank

Figure 2.2: The JISULIFE F8's 3-in-1 capabilities: Fan, Flashlight, and Backup Power Bank.

Use it Anywhere with Large Battery Capacity

Speed 1

19 Hours

Speed 2

12 Hours



Figure 2.3: Extended battery life for prolonged use.

Unique Folding Design

90° -- Desk Style

180° -- Handheld Style



Figure 2.4: The F8's versatile folding design for handheld or desktop use.

3. SETUP

Initial Charging:

1. Before first use, fully charge the fan.
2. Connect the included USB charging cable to the fan's Micro USB or USB Type A port.
3. Plug the other end into a USB power source (e.g., wall adapter, laptop, power bank, car charger).
4. The charging indicator light will show charging status (refer to LED indicators section for details).

USB-C Rechargeable Fan



Socket



Laptop



Power Bank



Car Charger

Figure 3.1: Charging the JISULIFE F8 via various USB sources.

Unfolding the Fan:

- To use as a handheld fan, gently unfold the fan head to a 180° angle.
- For desktop use, unfold the fan head to a 270° angle, allowing it to stand stably on a flat surface.



Figure 3.2: Opening Method 1: Press the base where the USB connectors are and pull out the main body.



Figure 3.3: Opening Method 2: Use the small gap on top between the cover and the main body.

4. OPERATING INSTRUCTIONS

Fan Operation:

- Press the power button once to turn on the fan at Speed 1 (low).
- Press the power button a second time for Speed 2 (high).
- Press the power button a third time to turn off the fan.

Flashlight Operation:

- Press and hold the power button for approximately 2 seconds to turn on the flashlight.
- Press and hold the power button again for approximately 2 seconds to turn off the flashlight.



Figure 4.1: The integrated flashlight provides illumination when needed.

Power Bank Function:

- To use the fan as a power bank, connect your device's charging cable to the USB-A output port on the fan.
- The fan will automatically begin charging your device.



Figure 4.2: The F8 fan can serve as a backup power bank for your devices.

Usage Scenarios:

Outdoor



Commute



Office



Figure 4.3: The JISULIFE F8 is suitable for various environments including outdoor, commute, and office.

Pocket Design

Your Bag Essentials



Figure 4.4: Its compact pocket design makes it a perfect bag essential.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the fan's exterior. Do not use harsh chemicals or abrasive materials. Ensure the fan is off and unplugged before cleaning.
- **Storage:** Store the fan in a cool, dry place away from direct sunlight and extreme temperatures. When storing for extended periods, ensure the battery is partially charged (around 50%) to prolong its lifespan.
- **Safety:** The fan blades are made of soft TPE material. If accidentally touched while rotating, the blades will automatically stop to ensure safety.

6. TROUBLESHOOTING

Common Issues and Solutions:

- **Fan not turning on:**
 - Ensure the battery is charged. Connect to a power source and try again.
 - Verify the power button is pressed correctly.
- **Fan not charging:**
 - Check if the charging cable is securely connected to both the fan and the power source.
 - Try a different USB cable or power adapter.
 - Ensure the power source is active.
- **Flashlight not working:**
 - Ensure the battery is charged.
 - Press and hold the power button for the required duration (approx. 2 seconds).
- **Power bank not charging devices:**
 - Ensure the fan's battery has sufficient charge.
 - Check the connection between the fan's USB-A output port and your device's charging cable.
 - Try a different charging cable for your device.

If you encounter issues not listed here, please contact customer support.

7. SPECIFICATIONS

Attribute	Value
Brand	JISULIFE
Model Name	F8
Color	Blue
Electric Fan Design	Table Fan
Power Source	Battery Powered
Style	Portable Fan
Product Dimensions	1.46"D x 1.57"W x 4.72"H
Special Feature	3 IN 1 Pocket Fan with Flashlight and Power Bank Function
Recommended Uses	Travel
Noise Level	60 dB
Number of Blades	2
Blade Length	3 Inches
Voltage	5 Volts

Item Weight	0.37 Pounds (5.9 ounces)
Included Components	Cord
Indoor/Outdoor Usage	Outdoor
Blade Material	Plastic
Reusability	Rechargeable
Cordless	Yes
Number of Power Levels	2
Main Power Connector Type	Micro USB or USB Type A
UPC	779283470281
Batteries	1 Lithium Ion (included)

8. WARRANTY AND SUPPORT

JISULIFE products are manufactured to high-quality standards. For warranty information, technical support, or any inquiries regarding your JISULIFE F8 Handheld Mini Fan, please visit the official JISULIFE store or contact their customer service directly.

[Visit the JISULIFE Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question