

Domo DO716BL

DOMO DO716BL Soup Maker - User Manual

INTRODUCTION

Welcome to the world of effortless cooking with your new DOMO DO716BL Soup Maker. This versatile appliance is designed to simplify your meal preparation, allowing you to create delicious, healthy soups, plant-based milks, jams, and more with ease. Please read this manual carefully before first use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, flat, heat-resistant surface.
- Do not immerse the motor housing or power cord in water or any other liquid.
- Keep out of reach of children.
- Do not operate the appliance if the cord or plug is damaged.
- Always unplug the appliance from the power outlet when not in use, before cleaning, or if a malfunction occurs.
- Exercise caution when handling hot liquids and steam.
- Do not overfill the jug beyond the maximum fill line.
- Ensure the lid is securely closed before operating.
- The blades are sharp; handle with extreme care during cleaning.
- This appliance is for household use only.

PRODUCT OVERVIEW

The DOMO DO716BL Soup Maker features a robust stainless steel jug and a powerful motor housing with an integrated blade. The intuitive LED control panel allows for easy program selection.

Components:

- **Main Unit:** Stainless steel jug with integrated heating element.
- **Motor Housing/Lid:** Contains the motor, blade, and control panel.
- **XL-Blade:** High-performance blade for efficient blending.
- **LED Display:** Shows program status and timer.
- **Control Panel:** Buttons for program selection and start/stop.
- **Strainer:** Included for filtering plant-based milks.



The DOMO DO716BL Soup Maker, a sleek stainless steel appliance with a black base and handle, featuring an intuitive control panel on top. A bowl of soup and fresh vegetables are visible in the background, highlighting its primary function.



The DOMO DO716BL Soup Maker shown with its motor housing and blade assembly separated from the stainless steel jug, illustrating its two main detachable parts for easy cleaning and filling.



A close-up view of the underside of the DOMO DO716BL Soup Maker's motor housing, clearly showing the robust XL-blade designed for efficient blending and chopping.

SETUP

Before first use, clean all parts that will come into contact with food. Wipe the exterior of the motor housing with a damp cloth. Ensure the jug is clean and dry.

Initial Steps:

- Place the soup maker on a stable, level surface.
- Ensure the power cord is securely plugged into a grounded electrical outlet.
- Carefully place the motor housing onto the jug, ensuring it is properly seated and locked into place.

OPERATING INSTRUCTIONS

The DOMO DO716BL Soup Maker offers 7 pre-programmed functions for various preparations.

General Operation:

- Add your desired ingredients to the stainless steel jug. Ensure ingredients are cut into small pieces (approx. 2-3 cm) for optimal blending.
- Add liquid (water, broth, milk) up to the MAX fill line. Do not exceed this line.
- Securely place the motor housing/lid onto the jug.
- Plug in the appliance. The LED display will illuminate.
- Press the 'SELECT' button to cycle through the available programs.
- Once your desired program is selected, press the 'START/STOP' button to begin.
- The appliance will automatically complete the program and emit an audible signal when finished.
- **Memory Function:** If the lid is lifted during operation, the appliance has a 2-minute memory function, allowing you to replace the lid and resume the program without restarting.

Available Programs:

- **Soy/Nut Milk:** For preparing fresh plant-based milks.
- **Extra Smooth:** For very finely blended soups and purees.
- **Smooth:** For creamy soups with a smooth consistency.
- **Chunky:** For soups with larger pieces of ingredients, retaining texture.
- **Jam:** For making homemade jams and preserves.
- **Juice:** For blending fruits and vegetables into fresh juices.
- **Blend/Clean:** A versatile blending function, also used for initial cleaning.

Your browser does not support the video tag.

This video demonstrates the key features and operation of the DOMO DO716BL Soup Maker, including its 2.2L capacity, stainless steel motor housing, XL-blade, 7 programs for soups and plant-based milks, memory function, and the included strainer for filtering.



A hand pouring a stream of smooth, orange-colored soup from the DOMO DO716BL Soup Maker into a dark bowl, with fresh bell peppers and carrots in the background, illustrating the final product.



The DOMO DO716BL Soup Maker shown with a glass of plant-based milk and the included strainer, demonstrating its capability to prepare homemade nut milks.

MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your soup maker.

Cleaning Steps:

- Always unplug the appliance before cleaning and allow it to cool down completely.
- **Jug:** Rinse the inside of the stainless steel jug immediately after use. For stubborn residue, add a small amount of water and a drop of dish soap, then run the 'Blend/Clean' program. Afterwards, rinse thoroughly. Do not immerse the exterior of the jug in water.
- **Motor Housing/Lid:** Wipe the exterior of the motor housing and the control panel with a damp cloth. Do not immerse the motor housing in water. Be extremely careful around the sharp blade.
- **Strainer:** Wash the strainer with warm soapy water and rinse thoroughly.
- Dry all parts completely before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; Lid not properly closed; Overheating.	Ensure power cord is securely plugged in. Ensure lid is correctly seated and locked. Unplug and let cool for 30 minutes before restarting.
Soup is not smooth enough.	Ingredients too large; Insufficient blending time.	Cut ingredients into smaller pieces. Select 'Extra Smooth' program or run 'Blend/Clean' program for additional blending.
Soup overflows.	Overfilled jug.	Do not fill ingredients or liquid above the MAX fill line.
Loud noise during operation.	Hard ingredients; Appliance not stable.	This is normal during blending of harder ingredients. Ensure appliance is on a stable surface.
Difficulty cleaning the blade.	Food residue dried on.	Clean immediately after use. Use the 'Blend/Clean' program with water and soap. Use a brush for hard-to-reach areas, exercising extreme caution.

SPECIFICATIONS

Feature	Detail
Brand	Domo
Model Number	DO716BL
Color	Stainless Steel
Product Dimensions (L x W x H)	18 x 25 x 37 cm
Weight	2.33 Kilograms
Capacity	2.2 Liters
Power	3600 Watts
Voltage	230.0 V
Material	Stainless Steel

Feature	Detail
Noise Level	44 dB
Special Feature	Pitcher (Jug)
Number of Programs	7 (Soy/Nut Milk, Extra Smooth, Smooth, Chunky, Jam, Juice, Blend/Clean)
Memory Function	2 minutes

WARRANTY AND SUPPORT

This DOMO DO716BL Soup Maker comes with a standard manufacturer's warranty. For detailed warranty information, product support, or spare parts availability, please refer to the warranty card included with your purchase or visit the official DOMO website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question