



Manuals.plus /

- › **IKEA** /
- › IKEA UTESPELARE Gaming Desk (Model 405.003.50) Instruction Manual

IKEA 405.003.50

IKEA UTESPELARE Gaming Desk (Model 405.003.50) Instruction Manual

Brand: IKEA | Model: 405.003.50

1. INTRODUCTION

Thank you for purchasing the IKEA UTESPELARE Gaming Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new gaming desk. Please read these instructions carefully before use and retain them for future reference.



Image: The IKEA UTESPELARE Gaming Desk, featuring a black tabletop and sturdy black metal legs. The desk is designed for gaming setups, offering ample space and a sleek aesthetic.

2. SETUP AND ASSEMBLY

This product requires assembly. Ensure all parts are present and undamaged before beginning. Assembly requires basic tools, such as a screwdriver.

2.1 Package Contents

Verify that you have received the following components:

- Top Panel (Particleboard, Melamine finish, Polycarbonate/ABS plastic)
- Wire Mesh / Ladder Frame (Steel, Epoxy/polyester powder coating)
- Cable Management (100% Polyester, 100% recycled material)
- Tube Caps (Polypropylene plastic)
- All necessary screws, bolts, and assembly tools (e.g., Allen key).

2.2 Assembly Steps

1. **Attach the Legs:** Secure the main leg frames to the tabletop using the provided screws. Ensure they are aligned correctly.

2. **Install Crossbars:** Attach the crossbars between the leg frames to enhance stability. Tighten all bolts firmly.
3. **Mount Cable Management:** Position the wire mesh and cable management components under the tabletop as indicated in the detailed diagram. This helps organize cables and improve airflow for electronic devices.
4. **Insert Tube Caps:** Place the polypropylene plastic tube caps onto the ends of the frame tubes for a finished look and to protect floors.
5. **Final Tightening:** Double-check all screws and bolts to ensure they are securely tightened.

3. OPERATING INSTRUCTIONS

3.1 Height Adjustment

The desk height can be manually adjusted to 6 different levels, ranging from 68 cm (minimum) to 78 cm (maximum). To adjust the height, loosen the locking mechanisms on each leg, set the desired height, and then securely tighten the locks. It is recommended to have two people for easier and safer height adjustment.

3.2 Reversible Tabletop

The tabletop is designed to be reversible. You can choose to have the flat side facing forward or the side with a curved edge. The curved edge allows for comfortable arm support and provides a gap for routing cables between the desk and a wall, keeping your workspace tidy.

3.3 Cable Management

Utilize the metal mesh at the back of the desk and the under-desktop cable storage to manage your computer and peripheral cables. This improves ventilation for your PC and helps maintain a clean and organized gaming environment.

4. MAINTENANCE

4.1 Cleaning

- Wipe the desk surfaces with a damp cloth and a mild cleaner.
- Dry thoroughly with a clean cloth.
- Avoid abrasive cleaners or harsh chemicals that may damage the finish.

4.2 General Care

- Regularly check and tighten all assembly fittings to ensure stability.
- Avoid placing extremely hot or cold items directly on the tabletop without protective coasters.
- Do not overload the desk beyond its specified weight capacity.

5. TROUBLESHOOTING

5.1 Desk Instability

- Ensure all screws and bolts are fully tightened.
- Check that the desk is placed on a flat, even surface.
- Adjust the leveling feet (if applicable) on the bottom of the legs to compensate for uneven floors.

5.2 Difficulty Adjusting Height

- Ensure the height locking mechanisms on both legs are fully disengaged before attempting to adjust.

- If the legs feel stuck, gently rock the desk while adjusting to help free the mechanism.

6. SPECIFICATIONS

Feature	Detail
Brand	IKEA
Model Number	405.003.50
Color	Black
Dimensions (Min Height)	160 cm (Width) x 80 cm (Depth) x 68 cm (Height)
Dimensions (Max Height)	160 cm (Width) x 80 cm (Depth) x 78 cm (Height)
Weight	30.5 kg
Height Adjustment	Manual, 6 levels (68-78 cm)
Top Panel Material	Particleboard, Melamine finish, Polycarbonate/ABS plastic
Frame Material	Steel, Epoxy/polyester powder coating
Cable Management	Integrated mesh and under-desk storage (100% recycled polyester)
Assembly Required	Yes

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official IKEA website or contact your local IKEA store. Keep your purchase receipt as proof of purchase.