

manuals.plus /

› [AGPTEK](#) /

› [AGPTEK A19X Bluetooth MP3 Player Instruction Manual](#)

AGPTEK A19X

AGPTEK A19X Bluetooth MP3 Player Instruction Manual

Model: A19X

1. INTRODUCTION

The AGPTEK A19X is a versatile 2.4-inch Bluetooth MP3 player designed for high-quality audio playback and various multimedia functions. It features Bluetooth 5.3 for stable wireless connections, a 3D curved screen for clear display, and a professional digital noise reduction chip for lossless sound. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- AGPTEK A19X MP3 Player
- Carrying Case
- USB Charging Cable
- Wired Earphones
- User Manual (this document)

SIZE & PACKAGE




Image: The AGPTEK A19X MP3 player, its USB charging cable, wired earphones, and the included carrying case, illustrating the complete package contents.

3. PRODUCT OVERVIEW

The AGPTEK A19X features a sleek design with a 2.4-inch curved screen and intuitive controls. Familiarize yourself with the device's physical components:

- **2.4-inch Curved Screen:** Main display for navigation and content viewing.
- **Touch Buttons:** Capacitive buttons below the screen for navigation (e.g., Back, Menu, Play/Pause, Next/Previous).
- **Power Button:** Located on the side for turning the device on/off and screen lock.
- **Volume Buttons:** Located on the side for adjusting audio output.
- **USB Port:** For charging and data transfer.
- **Headphone Jack:** 3.5mm port for wired earphones.
- **MicroSD Card Slot:** For expanding storage capacity (supports up to 128GB).
- **Built-in Speaker:** For audio playback without headphones.

2.4"

Curved Screen



Touch button



32GB+128GB



Speaker



Image: A close-up view of the AGPTEK A19X MP3 player, highlighting its 2.4-inch curved screen, the touch-sensitive navigation buttons below the display, and indicating the built-in speaker and expandable storage.

Double Curved Surfaces

Fit the palms, just right!



Image: The AGPTEK A19X MP3 player displayed from both front and back angles, emphasizing its double curved surfaces designed for comfortable handling.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the MP3 player. Connect the included USB cable to the device's USB port and the other end to a computer's USB port or a compatible USB wall adapter (not included). The battery indicator on the screen will show charging status.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button until a power-off option appears on the screen, then confirm.
- **Screen Lock/Unlock:** Briefly press the Power button to lock or unlock the screen during operation.

4.3 Inserting a MicroSD Card

The device has internal storage and supports expandable storage via a MicroSD card (up to 128GB). Locate the MicroSD card slot on the side of the player. Gently insert the MicroSD card with the gold contacts facing down until it clicks into place. To remove, push the card in slightly until it springs out.

4.4 Connecting to a Computer

To transfer files, connect the MP3 player to your computer using the USB cable. The device will appear as a removable disk drive. You can then drag and drop music, video, photo, and e-book files into the appropriate folders on the player.

5. OPERATING THE DEVICE

5.1 Basic Navigation

The AGPTEK A19X uses physical touch buttons for navigation. Use the arrow buttons to move through menus and select options. The 'Back' or 'Return' button typically takes you to the previous screen or menu. The 'Menu' button may provide additional options within an application.

5.2 Music Playback

The player supports various music formats including MP3, WMA, APE, FLAC, WAV, AAC-LC, and ACELP. It features a professional digital noise reduction chip for high-quality, lossless sound.

- Navigate to the 'Music' icon on the main menu.
- Browse your music by Artist, Album, Songs, Playlists, or Folders.
- Select a song to begin playback.
- Use the Play/Pause, Next, and Previous buttons for control.
- The A-B repeat function allows you to loop a specific section of an audio track.

Note: The device does not directly support Audiobook and iTunes formats.

5.3 Bluetooth Connection

The AGPTEK A19X features upgraded Bluetooth 5.3 for stable and efficient wireless audio. You can pair it with Bluetooth wireless headphones or Bluetooth car speakers.

- Go to the 'Bluetooth' setting in the main menu.
- Turn Bluetooth 'On'.
- The player will scan for available Bluetooth devices.
- Select your desired device from the list to pair.

Bluetooth 5.0

Yes to BT Speaker & BT Earphones




Image: The AGPTEK A19X MP3 player wirelessly connected to a Bluetooth speaker and a pair of Bluetooth earbuds, demonstrating its Bluetooth 5.0 connectivity feature.

Important: This device is unable to directly connect to cellphones or cars via Bluetooth for file transfer or control.

5.4 Other Functions

The AGPTEK A19X offers a range of additional features:

- **Video Play:** Supports video playback on its 2.4-inch screen.
- **Voice Record:** Built-in microphone for recording audio.
- **FM Radio:** Listen to FM radio stations. (May require wired headphones to act as an antenna).
- **Photo Browsing:** View images stored on the device.
- **E-book:** Read text files (TXT format only).
- **Alarm Clock:** Set alarms.
- **Calendar:** Access a basic calendar function.
- **File Folders:** Browse and manage files directly on the device.
- **Time Screen-saver:** Customize the screen-saver display.

Incredibly Powerful



Image: The AGPTEK A19X MP3 player with a visual representation of its diverse functionalities, including music, voice recording, e-book reading, video playback, photo browsing, pedometer, alarm clock, and calendar.

6. MAINTENANCE

6.1 Cleaning the Device

Use a soft, dry, lint-free cloth to clean the screen and body of the MP3 player. Avoid using abrasive cleaners, solvents, or aerosol sprays, as these can damage the device's surface.

6.2 Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in use for extended periods.
- Store the device in a cool, dry place away from extreme temperatures.

6.3 Carrying Case Care

The included carrying case is designed to protect your MP3 player. It features a scratch-resistant and shockproof interior with an elastic strap to secure the device. The dual zippers and carabiner provide convenience and portability.



Image: A detailed view of the AGPTEK A19X carrying case, highlighting its key features including the elastic strap, double zippers, carabiner, and soft velvet interior for device protection.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery; device frozen.	Charge the device for at least 30 minutes. If frozen, press and hold the Power button for 10-15 seconds to force a restart.
Cannot connect to Bluetooth device.	Bluetooth not enabled; device out of range; pairing mode not active.	Ensure Bluetooth is enabled on both devices. Place devices closer. Put the receiving Bluetooth device into pairing mode.
No sound from headphones/speaker.	Volume too low; headphones not properly connected; corrupted audio file.	Increase volume. Re-insert headphone jack firmly. Try a different audio file.
Files not transferring to device.	USB cable issue; device not recognized by computer; insufficient storage.	Try a different USB port or cable. Ensure the device is in data transfer mode. Check available storage space.
Screen is unresponsive or frozen.	Software glitch.	Press and hold the Power button for 10-15 seconds to force a restart.

8. SPECIFICATIONS

Feature	Detail
Model Name	bluetooth mp3 player (A19X)
Screen Size	2.4 Inches (Visible screen diagonal: 3" / 7 cm)
Connectivity Technology	Bluetooth 5.3
Memory Storage Capacity	32 GB (expandable via MicroSD up to 128GB)
Supported Audio Formats	MP3, WMA, APE, FLAC, WAV, AAC-LC, ACELP
Supported E-book Format	TXT
Color	Black
Included Components	MP3 Player, Carrying Case, USB Cable, Wired Earphones

9. WARRANTY AND SUPPORT

AGPTEK products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official AGPTEK website. Keep your purchase receipt as proof of purchase for warranty claims.