

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Skagen](#) /

› [Skagen Women's Freja Quartz Watch SKW3005 Instruction Manual](#)

## Skagen SKW3005

# Skagen Women's Freja Quartz Watch SKW3005 Instruction Manual

Brand: Skagen | Model: SKW3005

## INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Skagen Women's Freja Quartz Watch, Model SKW3005. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

The Skagen Freja watch features a round stainless steel case, a two-hand analog display with quartz movement, and a LiteHide leather strap. It is designed for everyday wear with a focus on minimalist elegance.

## PRODUCT OVERVIEW

The Skagen Freja watch combines functional design with a sleek aesthetic. Key features include:

- **Case & Dial:** 26mm stainless steel case with a gray sunray dial and rose gold accents. The dial features crystal hour markers for clear readability.
- **Movement:** Accurate quartz movement with a two-hand analog display.
- **Watch Band:** Gray LiteHide genuine leather strap with a secure single prong strap buckle closure, designed for a customized fit.
- **Water Resistance:** Splash resistant up to 3 ATM (30 meters or 165 feet). Suitable for everyday splashes, but not for swimming or diving.



Front view of the Skagen Freja watch, highlighting the rose gold case and brown leather strap.





A detailed view of the watch face, showcasing the crystal hour markers and the Skagen logo.

## SETUP

---

### Setting the Time

1. Gently pull the crown (the small knob on the side of the watch case) outwards until you feel a click.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

## **Adjusting the Watch Band**

The LiteHide leather strap features a single prong buckle closure that can be adjusted for a comfortable and secure fit on your wrist.

1. Locate the buckle and the series of holes on the leather strap.
2. Insert the prong of the buckle into the hole that provides the most comfortable and secure fit without being too tight or too loose.
3. Ensure the strap is properly secured through the keeper loops.



The single prong buckle closure on the LiteHide leather strap.

### **Video: Watch Band Adjustment Demonstration**

This video demonstrates how to adjust the watch band for a comfortable fit. (Video by Lorrel Walker)

## OPERATING

---

Your Skagen Freja watch is designed for straightforward timekeeping. Once the time is set, the quartz movement ensures accurate display of the current hour and minute via the two-hand analog display.

No additional complex operations are required for daily use beyond setting the time as needed (e.g., for daylight saving changes or after battery replacement).

## MAINTENANCE

---

### Cleaning Your Watch

- To clean the watch case and crystal, use a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- For the leather strap, wipe gently with a dry or slightly damp cloth. Avoid prolonged exposure to water or direct sunlight to prevent damage and discoloration.

### Water Resistance

This watch is water resistant up to 3 ATM (30 meters / 165 feet). This means it is suitable for everyday use and can withstand splashes or brief immersion in water, such as washing hands or light rain. It is **not** suitable for showering, bathing, swimming, snorkeling, or diving.

Always ensure the crown is fully pushed in to maintain water resistance.





Side profile of the watch, illustrating its slim design and the crown.

## TROUBLESHOOTING

---

### Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in. If it is pulled out, the watch will not run.
- **Battery:** If the watch stops running, the battery may need replacement. Quartz watches typically require battery replacement every 2-3 years. It is recommended to have the battery replaced by a professional watch repair service to maintain water resistance.


### Inaccurate Time

- **Reset Time:** Follow the "Setting the Time" instructions to reset the time.
- **Battery:** A low battery can sometimes cause the watch to run slowly or erratically. Consider battery replacement.
- **Magnetic Fields:** Strong magnetic fields can affect quartz watch accuracy. Keep your watch away from strong magnets.

If you experience persistent issues, please contact Skagen customer support or an authorized service center.

## SPECIFICATIONS

Feature	Detail
Model Number	SKW3005
Case Size	26mm
Band Width	12mm
Movement	Quartz, 2-hand analog display
Dial Color	Gray sunray with rose gold accents
Strap Material	LiteHide Leather (Brown)
Water Resistance	3 ATM (30 meters / 165 feet)
Crystal	Scratch resistant mineral crystal
Product Dimensions	1.02 x 0.55 x 0.28 inches
Weight	0.74 ounces



Skagen watch case size guide for reference.

## WARRANTY AND SUPPORT

Your Skagen Freja watch comes with a presentation box. For specific warranty details, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Skagen

website.

For customer support, service inquiries, or to locate an authorized service center, please visit the [Skagen Store on Amazon](#) or the official Skagen brand website.



The Skagen watch is presented in a branded box.